Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ChooChoo MC2402-WH-NEW

ChooChoo Lighted Bathroom Medicine Cabinet with Mirror

Model: MC2402-WH-NEW

Brand: ChooChoo

1. Introduction

This manual provides essential instructions for the safe and efficient installation, operation, and maintenance of your ChooChoo Lighted Bathroom Medicine Cabinet with Mirror. Please read this manual thoroughly before assembly and use, and retain it for future reference.

2. Safety Information

Important Safety Instructions:

- Ensure proper installation near an electrical outlet for the lighting function to operate.
- Follow all included instructions carefully to avoid potential hazards during assembly and installation.
- Handle the mirror cabinet with care to prevent damage to the mirror and other components.
- Do not attempt to modify the electrical components or wiring. All electrical work should be performed by a qualified professional if modifications are necessary.
- Keep children away from the assembly area and ensure all small parts are out of their reach.

3. Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Medicine Cabinet Frame
- Mirrored Doors with Integrated LED Lighting
- Adjustable Shelves (Quantity: 1)
- Towel Bar
- Assembly Hardware (screws, anchors, etc.)
- Assembly Tools (basic tools may be included)
- Instruction Manual

4. Specifications

Feature	Detail
Brand	ChooChoo
Model Name	Medicine Cabinets
Item Model Number	MC2402-WH-NEW
Color	White
Product Dimensions (D x W x H)	5.91"D x 27.56"W x 23.62"H
Mounting Type	Wall Mount
Room Type	Bathroom, Bedroom
Door Style	Mirrored
Number of Shelves	1 (Adjustable)
Frame Material	Engineered Wood
Finish Type	Painted
Item Weight	27.3 pounds
Assembly Required	Yes



Figure 4.1: Product Dimensions

5. Setup and Installation

This medicine cabinet is designed for wall-mounted installation. It is recommended to have two people for safe and secure mounting due to the item's weight and size.

5.1 Pre-Installation

- Unpack all components and verify against the package contents list.
- Ensure you have a suitable location with a nearby electrical outlet for the LED lighting.
- Gather any additional tools not provided, such as a drill, level, and measuring tape.

5.2 Assembly Steps

1. Follow the detailed assembly instructions provided in the separate assembly guide. Parts are numbered for easy identification.
2. Assemble the cabinet frame using the included hardware.

3. Attach the mirrored doors to the cabinet frame using the adjustable hinges. Ensure doors are aligned properly.
4. Install the adjustable shelf at your desired height within the cabinet.
5. Attach the towel bar to the designated area beneath the cabinet.

5.3 Wall Mounting

1. Identify a sturdy wall location, preferably with wall studs, to support the cabinet's weight.
2. Mark the drilling points on the wall according to the assembly guide. Use a level to ensure accuracy.
3. Drill pilot holes and insert wall anchors if necessary.
4. Carefully lift the cabinet and secure it to the wall using the provided mounting hardware. Ensure it is firmly attached and level.
5. Once mounted, plug the cabinet's power cord into a nearby electrical outlet to activate the LED lighting.



Figure 5.1: Assembled Cabinet View

6. Operating Instructions

6.1 LED Lighting Control

The mirrored door features integrated LED lighting with adjustable settings:

- **Power On/Off:** Lightly touch the illuminated power icon on the mirror surface to turn the LED lights on or off.
- **Adjust Color Temperature:** With the lights on, tap the power icon repeatedly to cycle through the three available color temperatures: Cool White, Natural White, and Warm White.
- **Dimming Function:** To adjust the brightness, press and hold the power icon. The light will gradually dim or brighten. Release when the desired brightness is achieved.



Figure 6.1: Adjustable Color Temperatures



Figure 6.2: LED Mirror in Use

6.2 Storage and Organization

- **Adjustable Shelf:** The interior shelf can be repositioned to accommodate items of various heights. To adjust, remove the shelf, reposition the shelf pins to the desired height, and reinsert the shelf.
- **Tissue Slot:** A dedicated slot is provided for easy access to tissues or paper towels.
- **Towel Bar:** Use the integrated towel bar for hanging hand towels or washcloths.



Figure 6.3: Cabinet Interior with Adjustable Shelves



Figure 6.4: Tissue Slot and Towel Bar Detail

7. Maintenance

7.1 Cleaning

- **Mirror Surface:** Use a soft, lint-free cloth and a non-abrasive glass cleaner. Spray cleaner onto the cloth, not directly onto the mirror, to prevent liquid from seeping into the edges.
- **Cabinet Surfaces:** Wipe with a soft, damp cloth. For stubborn marks, use a mild, non-abrasive cleaner. Avoid harsh chemicals or abrasive materials that could damage the painted MDF finish.
- **Electrical Components:** Ensure the power is disconnected before cleaning any part of the cabinet near electrical components. Wipe gently with a dry cloth.

7.2 General Care

- Regularly check all screws and connections to ensure they remain tight.
- Avoid exposing the cabinet to excessive moisture or direct water spray, despite its water-resistant properties.

- Do not place excessively heavy items on the shelves or towel bar.

8. Troubleshooting

If you encounter any issues with your medicine cabinet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
LED lights do not turn on.	No power connection. Faulty outlet.	Check if the power cord is securely plugged into a working electrical outlet. Test the outlet with another device.
Lights are dim or flickering.	Dimming function activated. Loose connection.	Press and hold the power icon to adjust brightness. Ensure power cord is fully inserted.
Cabinet doors are misaligned.	Hinges need adjustment.	Adjust the screws on the adjustable hinges to correct door alignment. Refer to the assembly guide for detailed hinge adjustment instructions.
Cabinet feels unstable after mounting.	Improper wall mounting. Loose hardware.	Ensure the cabinet is securely fastened to wall studs or appropriate anchors. Tighten all mounting screws. If unsure, consult a professional.

9. Warranty and Support

ChooChoo stands behind the quality of its products. While specific warranty details are not provided in this manual, if you experience any issues, damage during transportation, or require assistance with your product, please do not hesitate to contact ChooChoo customer support. Have your model number (MC2402-WH-NEW) and purchase information ready when contacting support.
For support, please visit the official ChooChoo store or contact your retailer.

© 2025 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DXZSRSLV

More documents and user manuals: **https://manuals.plus/**