Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Langsdom BE17

Langsdom BE17 Bone Conduction Headphones

USER MANUAL

Introduction

Thank you for choosing the Langsdom BE17 Bone Conduction Headphones. These open-ear headphones are designed for active lifestyles, offering superior sound and comfort while keeping you aware of your surroundings. Featuring IPX8 waterproofing, 32GB built-in memory, and Bluetooth 5.4 connectivity, the BE17 provides a versatile and durable audio experience for sports, swimming, and daily use.



Image: The Langsdom BE17 Bone Conduction Headphones, showcasing their sleek, open-ear design in black.

Package Contents

Please check the box for the following items:

- Langsdom BE17 Bone Conduction Headphones
- Magnetic Charging Cable (also functions as a data cable for music transfer)
- User Manual (this document)

Product Features

Bone Conduction Technology

Experience clear, dynamic sound transmitted through your cheekbones, leaving your ears open to ambient sounds. This design is ideal for outdoor activities where situational awareness is crucial.



Image: An exploded view diagram illustrating the internal bone conduction vibrators, designed for balanced tri-frequency sound.

IPX8 Waterproof Design

The BE17 headphones are built to withstand complete submersion in water, making them suitable for swimming, intense workouts, and use in rainy conditions. This ensures unrestrained sweating during exercise.



Image: The Langsdom BE17 headphones submerged in water, demonstrating their IPX8 waterproof capability.

Built-in 32GB Memory

Store thousands of songs directly on your headphones with the integrated 32GB memory. This allows for phone-free listening, supporting MP3, WMA, WAV, APE, and FLAC audio formats.



Image: A close-up of the headphone body indicating the "32G" built-in memory, capable of storing approximately 8000 songs.

Long Playtime & Magnetic Charging

Enjoy up to 10 hours of continuous music playback on a single 2-hour charge. The dedicated magnetic charging interface ensures a fast, stable, and secure power connection, simplifying the charging process and preventing dust accumulation.



Image: Graphic showing "10h" for endurance time and "2h" for single charging time, highlighting the battery life and quick charging.

Comfortable and Durable Design

Crafted from high-strength titanium alloy, these headphones are flexible and resistant to deformation, ensuring a stable and comfortable fit during all activities. The rounded and smooth body provides a gentle, snug fit.



Image: A close-up of the headphone's rounded and smooth body, emphasizing its ergonomic design for comfortable wearing.

Setup

1. **Initial Charging**

   Before first use, fully charge your BE17 headphones. Connect the magnetic charging cable to the charging port on the headphones and plug the USB end into a power adapter (not included) or a computer USB port. The indicator light will show charging status and turn off when fully charged. A full charge takes approximately 2 hours.

2. **Bluetooth Pairing**

   1. Power On: Press and hold the Power button until the indicator light flashes blue and red, indicating pairing mode.
   2. Enable Bluetooth: On your smartphone or device, go to Bluetooth settings and turn on Bluetooth.
   3. Select Device: Look for "Langsdom BE17" in the list of available devices and select it to connect. Once connected, the indicator light will flash blue slowly.
   4. Reconnection: The headphones will automatically attempt to reconnect to the last paired device when powered on.

3. **Loading Music to Built-in Memory (MP3 Mode)**

   1. Connect to Computer: Use the provided magnetic charging cable to connect your headphones to a computer's USB port. The headphones will be recognized as a removable disk.

   2. Transfer Files: Drag and drop your audio files (MP3, WMA, WAV, APE, FLAC) into the headphone's storage folder.

   3. Disconnect Safely: Once transfer is complete, safely eject the device from your computer before disconnecting the cable.

Operating Instructions

Button/Function	Action	Result
Power Button	Press and hold (2-3 seconds)	Power On/Off
Power Button	Single press	Play/Pause music; Answer/End call
Power Button	Double press	Switch between Bluetooth Mode and MP3 Mode
Volume Up (+)	Single press	Increase Volume
Volume Up (+)	Press and hold	Next Track
Volume Down (-)	Single press	Decrease Volume
Volume Down (-)	Press and hold	Previous Track
During Call	Press and hold Power button (2 seconds)	Reject incoming call

Maintenance

- **Cleaning:** Wipe the headphones with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Exposure:** While IPX8 waterproof, it is recommended to rinse the headphones with fresh water after exposure to chlorinated or saltwater, then dry thoroughly before charging.
- **Charging Port:** Ensure the magnetic charging contacts are clean and dry before charging to prevent corrosion.

Troubleshooting

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair with Bluetooth device.	Headphones not in pairing mode; Device Bluetooth off; Too far from device.	Ensure headphones are in pairing mode (flashing red/blue). Turn on Bluetooth on your device. Move headphones closer to the device (within 10 meters).
No sound from headphones.	Volume too low; Paused music; Incorrect mode (Bluetooth/MP3).	Increase volume. Press Play/Pause. Double press Power button to switch modes.

Problem	Possible Cause	Solution
Music files not recognized in MP3 mode.	Unsupported file format; Corrupted files.	Ensure files are MP3, WMA, WAV, APE, or FLAC. Try re-transferring files.
Charging issues.	Dirty charging contacts; Faulty cable/adapter.	Clean magnetic charging contacts. Try a different USB port or power adapter.

Specifications

Feature	Detail
Model Name	BE17
Connectivity Technology	Bluetooth V5.4
Water Resistance Level	IPX8 Waterproof
Built-in Memory	32GB
Supported Audio Formats	MP3, WMA, WAV, APE, FLAC
Battery Life	Up to 10 Hours
Charging Time	Approx. 2 Hours
Audio Driver Type	Bone Conduction Driver
Frequency Range	20 Hz to 20,000 Hz
Impedance	8 Ohm
Control Type	Button Control
Item Weight	7 ounces
Manufacturer	Langsdom

Warranty and Support

Langsdom products are designed for durability and performance. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Langsdom website. For technical support, troubleshooting assistance, or any product-related inquiries, please contact Langsdom customer service through their official channels.

You can find more information and support on theLangsdom Store on Amazon.

© 2025 Langsdom. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DYHJ18Z4

More documents and user manuals: **https://manuals.plus/**