Manuals+
Q & A | Deep Search | Upload

ZAFRO 5323

ZAFRO Tower Fan User Manual

MODEL: 5323

1. Safety Instructions

Please read all safety instructions carefully before using this appliance and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Ensure the power supply voltage matches the rating label on the fan.
- Do not immerse the fan, plug, or cord in water or other liquids.
- Unplug the fan from the outlet when not in use, when moving it, or before cleaning.
- Keep the fan out of reach of children and pets.
- Do not operate the fan with a damaged cord or plug. Contact qualified service personnel for repair.
- Avoid placing the fan near curtains, loose clothing, or other objects that could be drawn into the fan.
- Do not insert fingers or foreign objects into the fan grille.
- Use the fan only on a stable, flat surface.
- This appliance is for indoor use only.

2. Package Contents

Verify that all items are present and in good condition:

- ZAFRO Tower Fan Unit
- Remote Control (with 1 C battery included)
- User Manual

3. Product Overview

Familiarize yourself with the components of your ZAFRO Tower Fan.

Image: ZAFRO Tower Fan and its remote control. The fan is black, tall, and slender, with an LED display at the top. The remote is also black with several control buttons.

Control Panel & Remote Functions

The fan features an intuitive LED control panel on top and a convenient remote control for operation.

ON/OFF Button: Powers the fan on or off.

MODE Button: Cycles through Normal, Natural, Sleep, and Auto modes.

SPEED Button: Adjusts fan speed (3 levels).

OSC (Oscillation) Button: Activates or deactivates the 90° oscillation function.

TIMER Button: Sets the automatic shut-off timer (up to 12 hours).

LIGHT Button (Remote Only): Controls the LED display light.

Image: Close-up of the ZAFRO Tower Fan's LED control panel displaying temperature and settings, alongside the remote control with clearly labeled buttons for various functions.

4. Setup

4.1 Assembly

The ZAFRO Tower Fan is designed for tool-free assembly. Simply attach the base to the main fan unit.

1. Carefully remove all components from the packaging.
2. Align the two halves of the base and snap them together.
3. Place the main fan unit onto the assembled base, ensuring the alignment tabs fit correctly.
4. Secure the base to the fan unit using the provided nut or locking mechanism, typically found on the underside of the base. Turn clockwise until tight.

4.2 Placement

For optimal performance and safety:

- Place the fan on a firm, level surface.
- Ensure there is at least 12 inches (30 cm) of clear space around the fan for proper airflow.
- Do not block air inlets or outlets.
- Avoid placing the fan in direct sunlight or near heat sources.

5. Operating Instructions

Plug the fan into a standard 120V AC electrical outlet.

5.1 Power On/Off

- Press the **ON/OFF** button on the control panel or remote to turn the fan on or off.

5.2 Mode Selection

Press the **MODE** button to cycle through the following wind modes:

- **Normal Mode:** Provides a constant airflow at the selected speed.
- **Natural Mode:** Simulates natural breeze by varying fan speed intermittently.
- **Sleep Mode:** Operates at a lower speed with reduced noise, gradually decreasing speed over time for comfortable sleep.
- **Auto Mode:** Adjusts fan speed intelligently based on the ambient room temperature to maintain a consistent

comfort level.

Image: Visual representation of the four wind modes: Normal, Natural, Sleep, and Auto, with corresponding icons.

Image: A graph illustrating how the fan speed changes with room temperature in Automatic Mode, showing intelligent adjustment for consistent comfort.

5.3 Speed Adjustment

- Press the **SPEED** button to select from 3 available fan speeds (Low, Medium, High).

5.4 Oscillation Control

- Press the **OSC** button to activate the 90° wide-angle oscillation. Press again to stop oscillation.

Image: An overhead view demonstrating the 90-degree oscillation range of the ZAFRO Tower Fan, showing wide air distribution.

5.5 Timer Function

- Press the **TIMER** button repeatedly to set the desired operating time, from 1 to 12 hours. The fan will automatically turn off after the set time.

Image: The ZAFRO Tower Fan displaying its 12-hour timer function on the LED panel, indicating customizable operation time.

5.6 Remote Control Usage

- Point the remote control directly at the fan's receiver.
- Ensure there are no obstructions between the remote and the fan.
- The remote requires one C battery (included). Replace the battery when the remote's range decreases.

6. Maintenance

Regular cleaning and proper storage will ensure the longevity and efficient operation of your fan.

6.1 Cleaning

Always unplug the fan before cleaning.

- **Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Interior/Grille:** The fan features a detachable design for easy cleaning. Carefully detach the front grille and the internal components. Wash the grille and honeycomb parts with mild soap and water. Ensure all parts are completely dry before reassembling.

6.2 Storage

- If storing the fan for an extended period, clean it thoroughly.
- Store the fan in its original packaging or a suitable box in a cool, dry place.
- Keep the power cord neatly coiled to prevent damage.

7. Troubleshooting

Refer to the following table for common issues and their solutions.

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply. Fan not plugged in correctly.	Check if the power cord is securely plugged into a working outlet. Check the circuit breaker.
Weak or no airflow.	Air inlets/outlets blocked. Fan speed set too low.	Ensure no obstructions are blocking the fan. Increase the fan speed.
Fan makes unusual noise.	Loose parts. Fan not on a level surface. Debris inside the fan.	Ensure the base is securely attached. Place the fan on a stable, flat surface. Unplug and inspect for debris; clean if necessary. If a high-pitched sound persists on the highest setting, contact customer support.
Remote control not working.	Battery depleted. Obstruction between remote and fan.	Replace the C battery in the remote control. Ensure a clear line of sight to the fan's receiver.

8. Specifications

Feature	Detail
Brand	ZAFRO
Model Name	5323
Color	Black
Electric Fan Design	Floor Fan (Tower Style)
Power Source	AC
Product Dimensions (DxWxH)	11.81"D x 11.81"W x 35.43"H
Room Type	Bedroom, Living Room, Office
Special Features	Portable, Remote Controlled, Timer, Oscillation, Multiple Modes
Noise Level	50 dB
Wattage	50 watts
Voltage	120.0 V
Item Weight	7.92 Pounds
Indoor/Outdoor Usage	Indoor
Control Method	Remote, Touch Panel
Number of Power Levels	3 Speeds (7 internal levels)
Batteries	1 C battery (included for remote)

9. Warranty and Support

ZAFRO products are manufactured to high-quality standards. For warranty information, technical support, or customer service inquiries, please refer to the contact information provided on the product packaging or the official ZAFRO website. Please have your model number (5323) and purchase date available when contacting support.