Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kruger & Matz KM0940

Kruger & Matz KM0940 4G Senior Mobile Phone User Manual

Model: KM0940

1. Introduction

Thank you for choosing the Kruger & Matz KM0940 4G Senior Mobile Phone. This device is designed for ease of use, featuring a clear display, large buttons, and essential functions for communication. This manual provides detailed instructions to help you set up and operate your new phone effectively.

2. Safety Information

- **Battery Safety:** Use only approved batteries and chargers. Do not short-circuit, puncture, or expose the battery to extreme temperatures. Dispose of batteries properly.
- **Hearing Protection:** Avoid prolonged listening at high volume levels to prevent hearing damage.
- **Driving Safety:** Do not use your phone while driving. Always prioritize road safety.
- **Medical Devices:** Maintain a safe distance between the phone and medical devices like pacemakers. Consult your physician and device manufacturer for specific guidelines.
- **Water Resistance:** This phone is not water-resistant. Avoid exposure to liquids.
- **Cleaning:** Use a soft, dry cloth to clean the phone. Do not use harsh chemicals.

3. Package Contents

Please check the box for the following items:

- Kruger & Matz KM0940 Mobile Phone
- USB Charging Cable
- Power Adapter
- User Manual



Image: The included power adapter and USB-C charging cable.

4. Device Overview

4.1 Front View





Image: Front view of the KM0940 phone, showing the display and physical keypad.

The front of the phone features a 2.4-inch display for clear visibility and a large, easy-to-use physical keypad for dialing and navigation.

4.2 Back View


10:08
19-07-2024 Pt.
Skróty Kontakty
Krüger&Matz
1
2 ABC
3 DEF
4 GHI
5 JKL
6 MNO



Image: Back view of the KM0940 phone, highlighting the camera and speaker grille.

The back of the phone includes the 0.3 Mpx camera and a speaker grille for audio output.

4.3 Side View





Image: Side view of the KM0940 phone, showing its slim profile.

The sides of the phone house the charging port (USB Type-C) and potentially a 3.5mm headphone jack, depending on the specific model variant.

5. Setup

5.1 Inserting SIM Cards and Battery

1. Carefully remove the back cover of the phone.
2. Insert your Nano SIM card(s) into the designated slot(s). The phone supports two Nano SIM cards. Ensure the gold contacts face downwards.
3. Insert the Lithium-ion battery, aligning the contacts correctly.
4. Replace the back cover until it clicks securely into place.





Image: The phone with its back cover removed, illustrating the slots for SIM cards and the battery compartment.

5.2 Charging the Battery

1. Connect the USB charging cable to the phone's USB Type-C port.

2. Plug the power adapter into a wall outlet.
3. The phone will indicate that it is charging. A full charge takes approximately 3 hours.
4. Once fully charged, disconnect the charger.

6. Basic Operation

6.1 Power On/Off

- **To Power On:** Press and hold the Power/End Call button (red button) until the screen lights up.
- **To Power Off:** Press and hold the Power/End Call button until the power-off options appear, then select 'Power off'.

6.2 Making Calls

1. From the home screen, use the keypad to dial the desired phone number.
2. Press the Call/Send button (green button) to initiate the call.
3. To end a call, press the Power/End Call button (red button).
4. To answer an incoming call, press the Call/Send button.

6.3 Sending SMS Messages

1. Navigate to the 'Messages' menu using the navigation keys.
2. Select 'New Message' or 'Create Message'.
3. Enter the recipient's phone number or select from your contacts.
4. Type your message using the keypad.
5. Press the 'Send' option to transmit the message.

7. Advanced Features

The KM0940 includes several useful features:



Image: The phone screen showing various multimedia application icons.

- **Camera:** Access the 0.3 Mpx camera from the main menu to capture photos.
- **MP3 Player:** Store and play your favorite music files. Requires a microSD card (up to 128 GB, not included).
- **Video Player:** Play video files stored on your microSD card.
- **FM Radio:** Listen to local radio stations. May require headphones to act as an antenna.
- **Flashlight:** Activate the built-in flashlight for illumination.
- **Alarm Clock:** Set multiple alarms with customizable tones.
- **Calculator:** Perform basic arithmetic calculations.
- **Internet Browser (Opera Mini):** Access basic internet functions and websites.

8. Maintenance

- Keep the phone dry. Moisture can damage electronic circuits.
- Avoid extreme temperatures. High temperatures can shorten the life of electronic devices and damage batteries.
- Do not drop, knock, or shake the phone. Rough handling can break internal circuit boards.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the phone.
- Only use the provided or approved accessories.

9. Troubleshooting

- **Phone does not turn on:** Ensure the battery is charged and correctly inserted. Try charging the phone for at least 30 minutes.
- **No network signal:** Check if the SIM card is properly inserted. Ensure you are in an area with network coverage. Contact your service provider if the issue persists.
- **Cannot make or receive calls:** Verify that your SIM card is active and has sufficient credit/plan. Check network signal

strength.

- **Charging issues:** Ensure the charger and cable are securely connected and undamaged. Try a different power outlet.
- **Sound problems:** Check the volume settings. Ensure the speaker is not blocked.

10. Specifications

Display	2.4 inches, 240 x 320 pixels
Camera	0.3 Mpx
Internal Memory	128 MB
MicroSD Card Slot	Supports up to 128 GB
SIM Support	Dual Nano SIM
Bluetooth	5.1
Network Bands	3G/4G (VoLTE)
Talk Time	Up to 7 hours
Standby Time	Up to 280 hours
Battery	1400 mAh Lithium-ion
Charging Time	Approximately 3 hours
Dimensions	131.5 x 54 x 12 mm
Weight	88.6 g (with battery)
Operating System	Proprietary

11. Warranty and Support

Your Kruger & Matz KM0940 mobile phone comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, service, or further inquiries, please contact Kruger & Matz customer service through their official website or the contact information provided with your purchase documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZ76L9W2

More documents and user manuals: **https://manuals.plus/**