Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Langsdom BE19

Langsdom AirWare Pro Running Headphones User Manual

Model: BE19

Introduction

The Langsdom AirWare Pro headphones are designed for active lifestyles, offering an open-ear, non-intrusive design for comfort and situational awareness. Featuring IP67 dust and water resistance, a lightweight build, and a long-lasting battery, these headphones are ideal for running, workouts, and daily use. They also include a built-in 32GB MP3 player for phone-free music playback.



Image: Langsdom AirWare Pro headphones, showcasing their sleek design and vibrant green accent.

What's in the Box

- Headphones
- Magnetic Charging Cable (also functions as a data cable for direct music transfer)
- USB Female to Type-C Male Adapter
- Adjustable Lanyard



Image: A visual representation of all items included in the Langsdom AirWare Pro packaging.

Setup

Power On/Off

To power on the headphones, long press the Multi-Function Button (MFB) for approximately 2 seconds. The indicator light will illuminate. To power off, long press the MFB for about 3 seconds until the indicator light turns off.

Your browser does not support the video tag.

Video: Demonstrates how to manually power on and off the Langsdom AirWare Pro headphones using the Multi-Function Button (MFB). (Relevant segment: 0:04 - 0:22)

Bluetooth Pairing

Ensure your headphones are powered on. On your device (smartphone, tablet), open Bluetooth settings and enable Bluetooth. Select "Langsdom AirWare Pro" from the list of available devices to complete the pairing process.

Your browser does not support the video tag.

Video: Illustrates the steps for pairing the Langsdom AirWare Pro headphones with a Bluetooth-enabled device. (Relevant segment: 0:22 - 0:33)

Dual Device Connectivity

The AirWare Pro supports simultaneous connection to two devices. To set this up:

1. Pair the headphones with your first device (Device A).
2. Manually disconnect the headphones from Device A via its Bluetooth settings.
3. Pair the headphones with your second device (Device B).
4. Return to Device A's Bluetooth settings and reconnect to "Langsdom AirWare Pro". The headphones should now be connected to both devices.

Your browser does not support the video tag.

Video: Shows how to establish dual device connectivity with the Langsdom AirWare Pro headphones, allowing seamless switching between two paired devices. (Relevant segment: 0:33 - 0:53)

Operating Instructions

Music Mode

- **Play/Pause:** Click the MFB once.
- **Volume Up:** Click the "+" button.
- **Volume Down:** Click the "-" button.
- **Previous Song:** Long press the "-" button for 2 seconds.
- **Next Song:** Long press the "+" button for 2 seconds.



Image: Detailed view of the physical buttons on the headphones for precise control over music and calls.

Your browser does not support the video tag.

Video: Demonstrates how to control music playback, including play/pause, volume adjustment, and track skipping. (Relevant segment: 0:53 - 1:14)

Call Mode

- **Answer/Hang Up:** Click the MFB once.
- **Reject Call:** Long press the MFB for 1 second.
- **Handle Second Call:** During an active call, double-tap the MFB to end the first call and answer the second.

Your browser does not support the video tag.

Video: Shows how to manage phone calls using the headphone controls, including answering, hanging up, rejecting, and handling multiple calls. (Relevant segment: 1:14 - 1:35)

Voice Assistant

To activate your device's voice assistant (e.g., Siri, Google Assistant), long press the MFB for approximately 2 seconds.

Your browser does not support the video tag.

Video: Demonstrates how to activate the voice assistant feature on your connected device through the headphones. (Relevant segment: 1:35 - 1:42)

MP3 Mode (Built-in 32GB Memory)

The AirWare Pro has a built-in 32GB memory for storing music directly on the headphones, allowing for phone-free listening. You can switch between sequential and shuffle playback modes:

- **Switch Playback Order:** Triple-tap the MFB button. This will toggle between sequential play and random (shuffle) play.

Your browser does not support the video tag.

Video: Explains how to switch between sequential and shuffle playback modes for music stored on the headphones' internal 32GB memory. (Relevant segment: 1:42 - 2:18)

Download Songs to MP3 Mode

The headphones support MP3, WMA, WAV, APE, and FLAC audio formats. You can transfer music directly to the headphones using the provided magnetic charging cable and USB Female to Type-C Male Adapter.

Using OTG Adapter (Android)

For Android devices, connect the magnetic charging cable to the headphones, then connect the USB end of the cable to the USB Female to Type-C Male Adapter. Plug the adapter into your Android phone's Type-C port. Open your phone's 'Files' app, navigate to your music files, select them, and copy/move them to the 'OTG' or 'USB storage' folder representing the headphones.

Your browser does not support the video tag.

Video: Detailed instructions on how to download music files from an Android phone to the Langsdom AirWare Pro headphones using the OTG adapter. (Relevant segment: 2:41 - 3:29)

Using OTG Adapter (iPhone 15 or later)

For iPhone 15 or later models (with USB-C port), connect the magnetic charging cable to the headphones, then connect the USB end of the cable to the USB Female to Type-C Male Adapter. Plug the adapter into your iPhone's USB-C port. Open the 'Files' app on your iPhone, locate the newly connected storage device (headphones), find your music files, select them, and paste them into the headphones' storage.

Your browser does not support the video tag.

Video: Step-by-step guide on transferring music files from an iPhone 15 (or later) to the Langsdom AirWare Pro headphones using the OTG adapter. (Relevant segment: 3:29 - 4:06)

Charging

To charge your Langsdom AirWare Pro headphones, locate the magnetic charging port on the device. Connect the provided magnetic charging cable to the port, ensuring a secure connection. Plug the other end of the cable into a compatible USB power source (e.g., wall adapter, computer USB port). The indicator light will show charging status.

Your browser does not support the video tag.

Video: Demonstrates how to connect the magnetic charging cable to the headphones for charging. (Relevant segment: 4:18 - 4:25)

Maintenance

The Langsdom AirWare Pro headphones are designed with IP67 dust and water resistance and skin-friendly silicone for durability and comfort. To ensure longevity and optimal performance:

- **Cleaning:** After intense workouts or exposure to sweat/rain, gently wipe the headphones with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials.
- **Drying:** Ensure the headphones are completely dry before charging or storing them, especially the magnetic charging port.
- **Storage:** Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures. Use the provided storage bag to protect them from dust and scratches.



Image: The headphones are engineered with IP67 protection, making them resistant to sweat, splashes, and rain.

Troubleshooting

Factory Reset

If you experience persistent issues with your headphones, a factory reset may resolve the problem. To perform a factory reset:

- Ensure the headphones are powered off.
- Press and hold the MFB for 10 seconds. The indicator light will flash to confirm the reset.
- After the reset, you will need to re-pair the headphones with your devices.

Your browser does not support the video tag.

Video: Demonstrates the process of performing a factory reset on the Langsdom AirWare Pro headphones. (Relevant segment: 4:06 - 4:18)

Specifications

Model Name	AirWare Pro (BE19)
Brand	Langsdom
Ear Placement	Open Ear
Connectivity Technology	Bluetooth V5.4
Water Resistance Level	IP67 Waterproof
Built-in Memory	32GB (MP3, WMA, WAV, APE, FLAC formats)
Battery Life	Up to 17.5 Hours
Charging Time	1 Hour
Weight	26g (Ultra-Light)
Material	Memory Titanium Alloy, Skin-Friendly Silicone, Plastic
Control Type	Button Control

Warranty & Support

For warranty information, technical support, or any inquiries regarding your Langsdom AirWare Pro headphones, please refer to the official Langsdom website or contact their customer service directly. Keep your purchase receipt for warranty claims.

© 2025 Langsdom. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZCSVDCF

More documents and user manuals: **https://manuals.plus/**