Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Yalissey 3 Pcs With Swivel Chairs

Yalissey 3-Piece Outdoor Furniture Set with Swivel Chairs User Manual

Model: 3 Pcs With Swivel Chairs

1. Safety Information

Warning: To prevent tip-over, avoid placing heavy objects on the furniture. Do not use the furniture if any parts are broken or missing. Keep small parts out of reach of children to prevent injury. Do not expose the furniture to extreme heat sources.

2. Product Overview

The Yalissey 3-Piece Outdoor Furniture Set is designed for comfort and durability in various outdoor settings. This set includes two swivel chairs and one tempered glass top side table, crafted with weather-resistant materials.

Key Features:

- **Durable All-Weather Construction:** Features a powder-coated steel frame wrapped in woven wicker, designed to withstand outdoor elements.
- **Plush Comfort with Enhanced Stability:** Thickly padded seat and back cushions with high-resilience sponge and PP cotton. Cushions include an innovative binding design and anti-slip fabric on the bottom for security.
- **360-Degree Smooth Swivel & Gentle Rocking Motion:** Swivel chairs offer full rotation and a gentle rocking function for versatile relaxation.
- **HDPE Armrests & Reinforced Frame:** HDPE board armrests provide ergonomic support. The reinforced frame and anti-slip feet ensure stability.
- **Tempered Glass Top Side Table:** Includes a side table with a durable tempered glass surface.



Figure 2.1: The Yalissey 3-Piece Outdoor Furniture Set, featuring two swivel chairs and a side table, set in an outdoor patio environment.

3. Components List

Please ensure all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- 2 x Swivel Chairs (with wicker frame, HDPE armrests, and swivel base)
- 2 x Seat Cushions (for swivel chairs)
- 2 x Back Cushions (for swivel chairs)
- 1 x Side Table (with wicker frame and tempered glass top)
- Assembly Hardware (bolts, washers, Allen wrench)
- Instruction Manual (this document)



Figure 3.1: An illustration showing the various components included in the furniture set, such as chair frames, cushions, and the side table.

4. Assembly Instructions

Assembly is designed to be straightforward. It is recommended to have two people for certain steps. Do not fully tighten bolts until all components are aligned.

1. Unpack all components and verify against the components list.
2. Place all parts on a soft, clean surface to prevent scratches.
3. Assemble the chair frames according to the included diagrams, ensuring all bolts are loosely fitted initially.
4. Once the chair frames are complete, gently tighten all bolts using the provided Allen wrench.
5. Attach the swivel bases to the bottom of the chairs, ensuring they are securely fastened.

6. Place the seat and back cushions onto the chairs.
7. Assemble the side table frame, then carefully place the tempered glass top into its designated slot.
8. Verify all connections are secure before use.



Figure 4.1: A diagram illustrating the dimensions of the swivel chair and side table, useful for assembly and placement.

Note: The assembly process is designed for ease, but careful attention to the diagrams will ensure proper construction.

5. Operating Instructions

5.1 Swivel Chairs

The swivel chairs are designed for 360-degree rotation and a gentle rocking motion. To operate, simply sit in the chair and gently push off the ground with your feet to initiate rocking, or rotate the chair to face your desired direction. Ensure the chair is on a flat, stable surface for optimal performance.



Figure 5.1: An image depicting the swivel chair in motion, highlighting its 360-degree rotation capability.

5.2 Side Table

The side table provides a stable surface for drinks, books, or decorative items. The tempered glass top is durable and easy to clean. Avoid placing excessively hot items directly on the glass without a protective coaster.

6. Maintenance and Care

6.1 Wicker Frame

To clean the wicker frame, wipe with a damp cloth and mild soap. Rinse thoroughly with water and allow to air dry. Avoid using harsh chemicals or abrasive cleaners, as these can damage the wicker material.

6.2 Cushions

The cushions feature removable covers for easy cleaning. Unzip and remove the covers, then machine wash them on a

gentle cycle with cold water. Air dry only; do not tumble dry. For spot cleaning, use a mild soap solution and a soft brush, then rinse and air dry.



Figure 6.1: A close-up view of the cushion material, demonstrating its texture and resilience.

6.3 Tempered Glass Top

Clean the tempered glass top with a glass cleaner and a soft cloth. Avoid using abrasive materials that could scratch the surface.

6.4 General Care

To prolong the life of your furniture set, consider covering it during prolonged periods of harsh weather or when not in use. Regularly check and tighten any loose bolts.

7. Troubleshooting

Problem	Possible Cause	Solution
Chair feels unstable or wobbly.	Loose assembly bolts or uneven surface.	Ensure all bolts are tightened. Move the chair to a flat, even surface.
Cushions slide off easily.	Improper placement or anti-slip fabric not engaged.	Ensure cushions are placed correctly with the anti-slip side down.
Swivel mechanism is stiff.	Accumulated dirt or lack of lubrication.	Clean the swivel base. Apply a silicone-based lubricant if necessary (avoid oil-based).

If you encounter issues not listed here, please contact Yalissey customer support for assistance.

8. Specifications

- **Brand:** Yalissey
- **Model:** 3 Pcs With Swivel Chairs
- **Set Name:** 3-Piece Outdoor Furniture Set
- **Color:** Navy Blue
- **Frame Material:** Powder-coated steel, Wicker (HDPE)
- **Cushion Material:** High-resilience sponge, PP cotton, Olefin fabric
- **Table Top Material:** Tempered Glass
- **Assembly Required:** Yes
- **ASIN:** B0FQBZ2K22



Figure 8.1: The Yalissey furniture set positioned by a poolside, showcasing its suitability for various outdoor environments.

9. Warranty and Support

For warranty information, missing parts, or technical support, please contact Yalissey customer service through your original point of purchase or visit the official Yalissey website. Please have your model number (3 Pcs With Swivel Chairs) and ASIN (B0FQBZ2K22) ready when contacting support.

10. Product Videos

10.1 Yalissey Patio Furniture Overview

▶ **Watch video online**
patio super furniture

This video provides a general overview of the Yalissey patio furniture, showcasing its design and features in an outdoor setting. It highlights the overall aesthetic and functionality of the set.

© 2025 Yalissey. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DZX55RD7

More documents and user manuals: **https://manuals.plus/**