Philips Beauty BRE227/00

Philips Epilator Series 2000 User Manual

Model: BRE227/00

1. Introduction

This manual provides essential instructions for the safe and effective use of your Philips Epilator Series 2000, Model BRE227/00. This corded epilator is designed for efficient hair removal on legs and body, offering smooth skin for an extended period. Please read this manual thoroughly before first use and retain it for future reference.

2. Important Safety Information

When using electrical appliances, basic safety precautions should always be followed. Read all instructions before using this appliance.

- **General Safety:** To avoid skin irritation and injury, it is crucial to use the epilator correctly. Always follow the manufacturer's instructions, clean the device after each use, and avoid using it on irritated, broken, or infected skin. Consult a doctor if you have any skin conditions or concerns.
- **Electrical Safety:** This appliance is corded. Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting. Do not use the appliance if the adapter or cord is damaged. Keep the appliance dry; it is not designed for wet use. Unplug the appliance before cleaning.
- **Children and Persons with Reduced Capabilities:** This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **Usage Areas:** The epilator is intended for hair removal on legs and body. Do not use on sensitive areas such as face, head, eyebrows, eyelashes, or intimate areas.

3. Package Contents

Verify that all items are present in the package:

- Philips Epilator Series 2000 (Model BRE227/00)

- Massage Cap
- Cleaning Brush
- Power Adapter (Corded)



Image 3.1: The Philips Epilator Series 2000, Model BRE227/00, shown with its retail packaging and included massage cap. The epilator is pink with a white power cord.

4. Product Overview

Familiarize yourself with the components of your epilator:

1. **Epilation Head:** Contains the tweezers for hair removal.
2. **On/Off Switch:** Controls the power to the device.
3. **Power Socket:** For connecting the power cord.
4. **Massage Cap:** An attachment designed to soothe the skin during epilation, particularly useful for beginners.

5. **Cleaning Brush:** Used for removing hairs from the epilation head.

5. Setup

Before your first use, prepare the epilator and your skin.

1. **Connect Power:** As this is a corded device, ensure it is plugged into a suitable power outlet using the provided adapter.
2. **Attach Massage Cap (Optional):** For a gentler experience, especially if you are new to epilation, attach the massage cap to the epilation head. Align the cap with the head and press until it clicks into place.
3. **Skin Preparation:** For best results, ensure your skin is clean and dry. Exfoliating your skin a day before epilation can help prevent ingrown hairs. Hair length should ideally be between 0.5mm and 3-4mm for optimal removal.




Image 5.1: The Philips Epilator Series 2000 connected to its power source, indicating readiness for use. The device is compact and designed for easy handling.

6. Operating Instructions

Follow these steps for effective hair removal:

1. **Turn On:** Switch the epilator to the 'On' position. The device operates at a single speed setting.
2. **Positioning:** Hold the epilator at a 90-degree angle to your skin.
3. **Skin Tautness:** Use your free hand to pull the skin taut in the area you are epilating. This helps the epilator glide smoothly and reduces discomfort.
4. **Epilation Movement:** Move the epilator slowly against the direction of hair growth. Apply light pressure. Do not press too hard.
5. **Coverage:** Ensure you cover the entire area, overlapping strokes slightly to catch all hairs. The efficient epilation system with 20 tweezers is designed to remove hairs as short as 0.5mm.
6. **Post-Epilation:** After epilation, turn off the device and unplug it. Moisturize the treated area to soothe the skin and minimize irritation.



Image 6.1: A user demonstrating the correct technique for epilating the leg, holding the skin taut and moving the device against hair growth.



Image 6.2: The epilator with its massage cap attached, shown in use on a leg. The massage cap helps to reduce the sensation of epilation.



Image 6.3: A user gently removing hair from her lower leg with the Philips Epilator, illustrating the smooth motion required for effective use.

7. Cleaning and Maintenance

Regular cleaning ensures optimal performance and hygiene.

1. **Disconnect Power:** Always unplug the epilator from the power outlet before cleaning.
2. **Remove Epilation Head:** Detach the epilation head from the main body of the appliance.
3. **Clean Epilation Head:** Use the provided cleaning brush to remove any trapped hairs from the tweezers and the epilation head. The epilation head is washable; you can rinse it under running water. Ensure it is completely dry before reattaching.
4. **Clean Body:** Wipe the body of the epilator with a dry cloth. Do not immerse the main body in water.
5. **Reassemble:** Once all parts are clean and dry, reattach the epilation head to the main body.
6. **Storage:** Store the epilator in a dry, safe place, away from direct sunlight and extreme temperatures.

8. Troubleshooting

If you encounter issues with your epilator, refer to the following common solutions:

Problem	Possible Cause	Solution
Epilator does not turn on.	Not properly plugged in; power outlet issue.	Ensure the power cord is securely plugged into both the epilator and a working electrical outlet.
Hair is not removed effectively.	Incorrect technique; hair too short/long; epilation head dirty.	Move the epilator slowly against hair growth. Ensure hair length is optimal (0.5mm to 3-4mm). Clean the epilation head thoroughly.
Discomfort or pain during epilation.	First-time use; sensitive skin; skin not taut enough.	Use the massage cap. Pull skin taut during use. Discomfort often decreases with regular use. Ensure skin is clean and dry.
Redness or irritation after epilation.	Normal skin reaction; sensitive skin; lack of post-epilation care.	Apply a soothing, alcohol-free moisturizer after epilation. Redness typically subsides within a few hours. If irritation persists, discontinue use and consult a doctor.
Ingrown hairs.	Lack of exfoliation; hair growing back incorrectly.	Regularly exfoliate your skin (e.g., 2-3 times a week) to help prevent ingrown hairs.

9. Specifications

Feature	Detail
Model Number	BRE227/00
Brand	Philips Beauty
Power Source	Corded Electric
Epilation System	Efficient epilation system with 20 tweezers
Speed Settings	1 speed setting
Washable Head	Yes
Included Accessories	Massage cap, Cleaning brush
Product Dimensions	4.72 x 2.36 x 0.1 inches
Item Weight	2.42 ounces
UPC	075020110763

10. Warranty and Support

For warranty information, product registration, or technical support, please refer to the warranty card included with your purchase or visit the official Philips website. Keep your proof of purchase for any warranty claims.
Online Support: www.philips.com/support

© 2025 Philips. All rights reserved. Model BRE227/00.