Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DUMOS CJ3L-1P

DUMOS End Table User Manual

Model: CJ3L-1P

1. Introduction

Thank you for choosing the DUMOS 3-Tier End Table. This versatile and compact furniture piece is designed to enhance your living space with its functional storage and modern aesthetic. This manual provides essential information for safe assembly, proper usage, and effective maintenance of your new end table.





Figure 1.1: The DUMOS 3-Tier End Table, showcasing its design and potential use with a lamp, clock, and books on its shelves.

Key Features:

- **Multi-Functional Design:** Serves as an end table, nightstand, or temporary tabletop, suitable for living rooms, bedrooms, and offices.
- **Compact Size:** Ideal for small spaces, providing ample storage without occupying excessive floor area.
- **Adjustable Feet:** Ensures stability on uneven surfaces and protects floors from scratches.
- **Sturdy Construction:** Crafted from premium particleboard and a durable metal frame for long-lasting use.
- **Easy Assembly:** Simple structure with clear instructions for quick setup.

2. Safety Information

Please read all safety warnings and instructions carefully before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Always assemble the table on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as needed.
- Do not exceed the maximum weight capacities:

- Top Shelf: 22 KG (49 pounds)
- Lower Two Shelves (each): 20 KG (44 pounds)

- Distribute weight evenly on shelves to maintain stability.
- Keep small parts and packaging materials away from children and pets during assembly.
- Do not stand or climb on the table.
- Avoid placing hot items directly on the surface without protection.



Figure 2.1: Detailed dimensions and maximum load capacities for each tier of the end table.

3. Package Contents

Before beginning assembly, please verify that all parts are present and undamaged. If any parts are missing or damaged, please contact customer support.

Part	Description	Quantity
A	Top Shelf	1
B	Middle Shelf	1
C	Bottom Shelf	1
D	Long Metal Legs	4
E	Short Metal Legs	4
F	Adjustable Feet	4
G	Screws/Bolts	(Various)
H	Allen Key (Hex Wrench)	1
I	Assembly Guide	1

Note: The exact quantity of screws/bolts (Part G) may vary. Refer to the included Assembly Guide (Part I) for precise counts and identification.

4. Setup and Assembly

Assembly is straightforward and typically takes 5-10 minutes. Follow these steps carefully:

1. **Prepare the Area:** Clear a spacious, clean, and soft area (e.g., a carpet or blanket) to prevent scratching the table parts during assembly.
2. **Identify Parts:** Lay out all components and identify them using the provided labels (A, B, C, D, E, F, G, H, I) and the included Assembly Guide.
3. **Attach Adjustable Feet:** Screw the adjustable feet (F) into the bottom of the four long metal legs (D). Ensure they are finger-tight.
4. **Assemble Lower Section:** Attach the bottom shelf (C) to the four long metal legs (D) using the appropriate screws (G) and the Allen key (H). Do not fully tighten screws yet.
5. **Attach Short Legs:** Connect the middle shelf (B) to the top of the long metal legs (D) and the bottom of the short metal legs (E) using screws (G).
6. **Attach Top Shelf:** Secure the top shelf (A) to the top of the short metal legs (E) using screws (G).
7. **Final Tightening:** Once all parts are loosely assembled, place the table upright on a flat surface. Systematically tighten all screws (G) firmly with the Allen key (H). Ensure the table is stable and level.
8. **Adjust Leveling:** If the table wobbles, adjust the height of the adjustable feet (F) by twisting them until the table is stable and level on your floor.



Figure 4.1: Detail of the adjustable feet, designed to provide stability and protect flooring.

5. Operating and Usage

Your DUMOS End Table is designed for versatile use in various settings:

- **End Table:** Place next to a sofa or armchair to hold drinks, remote controls, books, or decorative items.
- **Nightstand:** Use beside your bed for a lamp, alarm clock, phone, and other bedside essentials.
- **Storage Shelf:** Utilize the three tiers for organizing books, magazines, small baskets, or display items.
- **Small Space Solution:** Its compact footprint makes it ideal for apartments, dorm rooms, or any area where space is limited.



Figure 5.1: The end table positioned beside a sofa, demonstrating its use in a living room environment.



Figure 5.2: The end table fitting perfectly into a compact area, illustrating its space-saving design.

6. Maintenance and Care

To ensure the longevity and appearance of your DUMOS End Table, follow these simple care instructions:

- **Cleaning:** Wipe the surfaces with a dry, soft cloth. For stubborn marks, a slightly damp cloth can be used, followed immediately by a dry cloth. Avoid abrasive cleaners or harsh chemicals.
- **Spills:** Clean up spills immediately to prevent staining, especially on the engineered wood surfaces.
- **Heat Protection:** Always use coasters or protective pads under hot items to prevent heat damage to the surface.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure, which can cause fading or discoloration over time.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.



Figure 6.1: The table's modern surface, which is waterproof and scratch-resistant, and its stable steel frame.

7. Troubleshooting

If you encounter any issues with your DUMOS End Table, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Table wobbles or is unstable.	Uneven floor; loose screws; adjustable feet not properly set.	Ensure all screws are fully tightened. Adjust the height of the adjustable feet until the table is level and stable. Move the table to a flat surface.
Parts do not fit together.	Incorrect orientation of parts; manufacturing defect.	Double-check the Assembly Guide to ensure parts are oriented correctly. If parts are still not fitting, contact customer support.

Problem	Possible Cause	Solution
Missing or damaged parts.	Packaging error; shipping damage.	Do not attempt to force assembly. Contact DUMOS customer support immediately for replacement parts.

8. Specifications

Attribute	Detail
Brand	DUMOS
Model Name	End Table
Model Number	CJ3L-1P
Product Dimensions (D x W x H)	13.4"D x 11.8"W x 22.8"H
Item Weight	8.8 Pounds
Material Type	Engineered Wood, Metal
Color	Rustic Brown
Maximum Weight Capacity (Top Shelf)	22 KG (49 pounds)
Maximum Weight Capacity (Lower Shelves, each)	20 KG (44 pounds)
Included Components	Assembly Guide
Recommended Tools for Assembly	Screw Driver (Allen Key included)
Product Care Instructions	Wipe with Dry Cloth

9. Warranty and Support

Warranty Information: DUMOS products are manufactured to high-quality standards. For specific warranty details regarding your end table, please refer to the warranty card included with your purchase or visit the official DUMOS website. Keep your proof of purchase for any warranty claims.

Customer Support: If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact DUMOS customer support. You can typically find contact information on the product packaging, the included assembly guide, or the DUMOS brand store on Amazon:

Visit the DUMOS Store on Amazon

Please have your model number (CJ3L-1P) and purchase date ready when contacting support.

© 2025 DUMOS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F2855JK2

More documents and user manuals: **https://manuals.plus/**