AMBITFUL Ambitful T14 PRO

Ambitful T14Pro 14-inch Teleprompter User Manual

Model: Ambitful T14 PRO | Brand: AMBITFUL

1. INTRODUCTION

The Ambitful T14 PRO is a 14-inch teleprompter designed for professional video recording, interviews, live streaming, and online teaching. It features an ultra-high perspective and a crystal-clear reflective optical glass lens with 97% light transmission, ensuring your script is clearly visible without distortion. This teleprompter is foldable for easy setup and portability, requiring no complex assembly. It supports a wide range of devices, including cameras, iPads, Android tablets, and smartphones up to 12.9 inches, and offers smart app control via Bluetooth for seamless script management.

Image 1.1: Ambitful T14Pro Teleprompter and included accessories.

2. WHAT'S IN THE BOX

Please verify that all the following components are included in your package:

- Teleprompter x 1
- Storage Box x 1
- Remote Control x 1
- L-Bracket x 1
- Wrench Screw x 2
- Dust Cloth x 1
- Manual x 1

What's in the Box

Teleprompter ×1 Storage Box ×1 Remote Control ×1
L-Bracket ×1 Wrench Screw ×2 Dust Cloth ×1
Manual ×1

Image 2.1: Visual representation of all items included in the product package.

3. SETUP

The Ambitful T14 PRO teleprompter is designed for quick setup with no complex assembly required. Follow these steps to prepare your teleprompter for use:

1. **Unfold the Teleprompter:** Gently unfold the teleprompter from its compact storage position.

2. **Mount on Tripod:** Attach the teleprompter to a tripod using the integrated 1/4-inch or 3/8-inch threads on its base. Ensure it is securely fastened for stability during recording.

3. **Adjust Screen Height (Lift Gimbal):** The teleprompter is equipped with a screen head that allows you to adjust the height of the reflective screen. The camera height can also be adjusted by installing a camera lifting head, providing approximately 8cm of vertical adjustment range.

Lift Gimbal

The teleprompter is equipped with a screen head to adjust the height of the screen; the camera height can also be adjusted by installing a camera lifting head.

Range ≈ 8cm

Image 3.1: Adjusting the screen and camera height using the lift gimbal.

4. **Insert Your Device:** The teleprompter's telescopic splint can be adjusted to accommodate mobile phones or tablets up to 12.9 inches. Extend the splint to fit your device securely.

Expandable Splints

The adjustable range of the teleprompter clipboard is about 21.5cm or less, and supports mobile phones or tablet teleprompters up to12.9" (tablet teleprompters are recommended for better results).

Image 3.2: The adjustable splints accommodate various mobile devices.

5. **Mount Your Camera:** Position your camera behind the teleprompter. The teleprompter supports both vertical and horizontal shooting styles, which can be achieved by changing the position of the L-shaped quick release plate mounted on the camera.

Double Shooting Style

The teleprompter can cater for both vertical and horizontal shots, which can be achieved by changing the position of the L-shaped quick release plate mounted on the camera.

Image 3.3: The teleprompter supports both vertical and horizontal camera orientations.

4. OPERATION

Operating your Ambitful T14 PRO teleprompter is intuitive, especially with the dedicated app control.

4.1. Display and Clarity

The 14-inch ultra-high perspective display and crystal-clear reflective optical glass lens ensure your script is reflected with remarkable clarity. With a 97% light transmission rate, you can effortlessly read your script without any visual obstruction or impurities.

14-inch Large Sceen

Ultra-high transmittance and clear reflection optical glass lenses, light transmission rate of 97%, reflection without impurities vision is not blocked. Coated lenses through the light does not refract, the font through the glass reflection complete and clear.

Image 4.1: The 14-inch screen provides clear and readable text.

4.2. Smart App Control

Enhance your teleprompting experience by pairing your smartphone or tablet with the Ambitful teleprompter app via Bluetooth. The app allows for comprehensive control over your script:

- **Play/Pause:** Start or stop the script scrolling.
- **Adjust Scrolling Speed:** Control the pace of the text to match your speaking speed.
- **Turn Pages:** Navigate through your script.
- **Change Font Size:** Adjust text size for optimal readability.
- **Change Background Color:** Customize the background for better contrast.

Image 4.2: The included remote control facilitates app-based script management.

4.3. Wide-Angle Lens Support

The teleprompter supports wide-angle lens shooting with a focal length of no less than 35mm, providing a bigger field of view and capturing larger scenes without dark corners in the picture.


Image 4.3: The teleprompter is compatible with wide-angle lenses for broader shots.

4.4. Applicable Scenarios

The Ambitful T14 PRO teleprompter is versatile and suitable for various professional applications:

- Video Recording
- Interviews
- Live Streaming
- Online Courses
- Speeches and Presentations
- News Broadcasts
- Tutorials

Image 4.4: Examples of the teleprompter in use across different professional settings.

5. MAINTENANCE

Proper care and maintenance will ensure the longevity and optimal performance of your Ambitful T14 PRO teleprompter.

- **Cleaning the Reflective Glass:** Use the provided dust cloth or a soft, lint-free microfiber cloth to gently wipe the reflective glass. For stubborn smudges, a small amount of lens cleaning solution designed for optical surfaces can be applied to the cloth (not directly to the glass). Avoid abrasive materials or harsh chemicals.

- **Cleaning the Body:** Wipe the exterior surfaces of the teleprompter with a soft, damp cloth. Do not use excessive moisture or immerse any part of the device in water.

- **Storage:** When not in use, fold the teleprompter flat and store it in the provided carrying case. This protects the optical components and prevents dust accumulation. Store in a cool, dry place away from direct sunlight and extreme temperatures.

- **Avoid Impact:** Handle the teleprompter with care to prevent drops or impacts, which could damage the optical glass or internal components.

6. TROUBLESHOOTING

If you encounter issues with your Ambitful T14 PRO teleprompter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Text appears blurry or unclear on the screen.	Dust or smudges on the reflective glass; incorrect device placement.	Clean the reflective glass with the provided dust cloth. Ensure your tablet/phone is placed correctly and securely on the splint.
Remote control not connecting to the app.	Bluetooth not enabled; remote battery low; app not open or paired.	Ensure Bluetooth is enabled on your device. Check remote battery and replace if necessary. Open the Ambitful teleprompter app and follow pairing instructions.
Device (phone/tablet) does not fit the splint.	Device size exceeds maximum compatibility.	The teleprompter supports devices up to 12.9 inches. Ensure your device is within this size limit.
Camera view shows dark corners (vignetting).	Using a lens with a focal length less than 35mm.	Use a wide-angle lens with a focal length of 35mm or greater to avoid vignetting.

7. SPECIFICATIONS

Product Name	Ambitful T14 PRO Teleprompter
Model Number	Ambitful T14 PRO

Display Size	14 inches
Light Transmission Rate	97%
Compatible Device Size	Mobile phones or tablets under 12.9 inches (telescopic splint adjustable up to 21.5 cm)
Connectivity	Bluetooth (for app control)
Mounting Threads	1/4-inch and 3/8-inch
Product Dimensions	20 x 14 x 14 inches (approximate assembled)
Item Weight	6.84 pounds (approx. 3.1 kg)
Manufacturer	AMBITFUL

Image 7.1: Key dimensions of the Ambitful T14Pro Teleprompter.

8. WARRANTY & SUPPORT

For detailed warranty information and customer support, please refer to the official AMBITFUL website or contact their customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.

For further assistance, you may visit the AMBITFUL store on Amazon:AMBITFUL Store

Related Documents - Ambitful T14 PRO

	[AMBITFUL A2 LED Fill Light: Features, Specifications, and Usage Guide](#) Comprehensive overview of the AMBITFUL A2 LED fill light, detailing its features, component descriptions, operational modes, app control, product parameters, and FCC compliance information.
	[Roland GO:MIXER PRO-X: Using with Smartphone Apps](#) A guide to using the Roland GO:MIXER PRO-X with various smartphone applications for online lessons, streaming, and multitrack recording. Covers apps like ZOOM Cloud Meetings, Skype, FaceTime, GarageBand, and more.
	[ATEN UC9040 StreamLIVE™ PRO Multi-Channel AV Mixer User Manual](#) User manual for the ATEN UC9040 StreamLIVE™ PRO, an all-in-one multi-channel AV mixer for professional live streaming. Learn about its features, setup, app control, and operation.
	[iPad User Guide: Everything You Need to Know](#) Comprehensive user guide for iPad, covering features like multitasking, file management, notes, Apple Pay, FaceTime, iCloud, and basic setup for iOS 11.3.
	[KDD Tablet Mount User Manual: Installation and Specifications](#) User manual for the KDD Tablet Mount (Model KDD-023), covering product introduction, dimensions, specifications, angle adjustment, installation steps, and important usage notes. Features an all-aluminum alloy design for phones and tablets.
	[Metapen Pencil A11 User Manual and Specifications](#) Comprehensive guide for the Metapen Pencil A11, detailing its features, specifications, setup, and usage for compatible iPad models. Includes quick start, troubleshooting, and safety information.