**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Kisonli K13**

# Kisonli K13 Portable Bluetooth Speaker User Manual

Model: K13
Brand: Kisonli

## 1. Introduction

Thank you for choosing the Kisonli K13 Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.



*Image 1.1: Front view of the Kisonli K13 Portable Bluetooth Speaker, showcasing its robust design and integrated RGB lighting.*

## 2. Important Safety Information

To prevent damage to your speaker or injury to yourself and others, please observe the following safety precautions:

- Do not expose the speaker to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the speaker to strong impacts.
- Do not disassemble, repair, or modify the speaker yourself. Refer all servicing to qualified personnel.
- Keep the speaker away from water and other liquids.
- Use only the specified charging cable and power adapter.
- Keep out of reach of children.

## 3. Package Contents

Please check that all items are present in your package:

- Kisonli K13 Portable Bluetooth Speaker
- USB Charging Cable
- User Manual

## 4. Product Overview and Features

The Kisonli K13 speaker delivers powerful stereo sound with dynamic RGB lighting, designed for an immersive audio experience.

### Key Features:

- **Powerful Audio Output:** Enjoy clear and robust sound with a 20W stereo configuration (2x10W speakers).
- **Dynamic RGB Lighting:** Enhance your listening experience with customizable, vibrant RGB light effects.
- **Deep Bass:** Engineered for rich, resonant bass.
- **Bluetooth Connectivity:** Seamless wireless connection to your devices.
- **Portable Design:** Easy to carry with a convenient handle.




*Image 4.1: The Kisonli K13 speaker highlighting its 20W audio output capability.*




*Image 4.2: Close-up view of the Kisonli K13 speaker's visible RGB colorful lighting feature.*

## 5. Setup Guide

### 5.1 Charging the Speaker

1. Connect the USB charging cable to the charging port on the speaker.
2. Connect the other end of the USB cable to a compatible USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate, typically red, during charging.
4. Once fully charged, the indicator light will change or turn off (refer to specific product behavior).

### 5.2 Powering On/Off

- **To Power On:** Press and hold the Power button for approximately 3 seconds until you hear an audible prompt and the indicator lights turn on.
- **To Power Off:** Press and hold the Power button for approximately 3 seconds until you hear an audible prompt and the indicator lights turn off.

## 6. Operating Instructions

### 6.1 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing blue LED). If not, press the Mode button to switch to Bluetooth mode.
2. On your smartphone, tablet, or other Bluetooth-enabled device, go to the Bluetooth settings.
3. Search for available devices and select "Kisonli K13" from the list.

4. Once paired, the speaker will emit an audible confirmation, and the Bluetooth indicator light will become solid blue.
5. The speaker will automatically attempt to reconnect to the last paired device when powered on.

### 6.2 Button Functions

- **Power Button:** Press and hold to power on/off.
- **Play/Pause Button:** Press once to play or pause audio.
- **Volume Up (+):** Press once to increase volume. Press and hold for next track.
- **Volume Down (-):** Press once to decrease volume. Press and hold for previous track.
- **Mode Button (M):** Press to cycle through available input modes (e.g., Bluetooth, AUX, USB if supported).
- **RGB Light Button:** Press to change RGB lighting modes or turn lights on/off.

## 7. Maintenance

### 7.1 Cleaning

Wipe the speaker with a soft, dry, lint-free cloth. Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the surface.

### 7.2 Storage

When not in use for extended periods, store the speaker in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to charge the battery periodically to maintain its health.

### 7.3 Battery Care

To prolong battery life, avoid fully discharging the speaker frequently. Charge the speaker when the battery level is low.

## 8. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Speaker does not turn on. | Battery is depleted. | Charge the speaker for at least 30 minutes. |
| Cannot pair via Bluetooth. | Speaker not in pairing mode; device Bluetooth off; too far from speaker. | Ensure speaker is in Bluetooth pairing mode. Turn Bluetooth on/off on your device. Move device closer to speaker. |
| No sound. | Volume too low; device not connected; incorrect input mode. | Increase speaker and device volume. Re-pair Bluetooth. Press Mode button to select correct input. |
| RGB lights not working. | Lights turned off; malfunction. | Press the RGB Light button to cycle through modes. If issue persists, contact support. |

## 9. Specifications

| Feature | Detail |
|---|---|

| Feature | Detail |
|---|---|
| Product Dimensions | 10 x 10 x 10 cm; 10 g |
| Connectivity Technology | Bluetooth |
| Audio Output Mode | Stereo |
| Speaker Maximum Output Power | 55 Watts |
| Frequency Response | 44 GHz |
| Mounting Type | Tabletop |
| Speaker Type | Portable Bluetooth Speaker |
| Recommended Uses | For Smartphones or Tablets, For Music Players |
| Compatible Devices | Smartphone, Tablet, Laptop, Television |
| Unit Count | 1 Count |
| Country of Origin | China |




*Image 9.1: Diagram illustrating the dimensions of the Kisonli K13 Portable Bluetooth Speaker.*

## 10. Warranty and Support

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact your retailer or the manufacturer's customer service.

**Customer Support:** Please refer to the contact information provided with your purchase or on the product packaging.

© 2025 Kisonli. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B0F4PGRR4K**

More documents and user manuals: **https://manuals.plus/**