Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Langsdom AirWave Pro & AirFit

Langsdom AirWave Pro & AirFit Open Ear Headphones User Manual

Model: AirWave Pro & AirFit

1. Introduction

This manual provides detailed instructions for the Langsdom AirWave Pro and AirFit Open Ear Headphones. These headphones are designed to enhance your active lifestyle, offering a unique open-ear experience for safety and comfort during various activities like running and workouts. Please read this manual thoroughly to ensure proper use and maintenance of your devices.



Image: The Langsdom AirWave Pro (top) and AirFit (bottom) headphones, showcasing their distinct designs. The AirWave Pro features a neckband style, while the AirFit are compact earbuds with ear hooks.

2. Product Overview

2.1 AirWave Pro

The AirWave Pro is an open-ear headphone designed for robust performance and extended use. It features a secure fit, ideal for intense physical activities, and allows ambient sound awareness for safety.

- **Open-Ear Design:** Non-intrusive, allowing awareness of surroundings.
- **Built-in MP3 Storage:** 32GB internal memory for music playback without a phone.
- **Extended Battery Life:** Up to 17.5 hours of continuous playback.
- **IP67 Waterproof Rating:** Resistant to sweat, rain, and dust.



Image: The Langsdom AirWave Pro headphones, highlighting their design and suitability for outdoor environments.



Image: A visual summary of AirWave Pro features, including IP67 waterproof rating, soft silicone material, 26g lightweight design, built-in 32GB memory, and 17.5 hours of battery life.

2.2 AirFit

The AirFit earbuds are ultra-lightweight and designed for comfortable, secure fit during high-intensity activities. They offer clear audio and are washable for easy maintenance.

- **Open-Ear Earbuds:** Washable and cloud-comfy for extended wear.
- **Ultra-Light Design:** Weighing only 7g for minimal ear fatigue.
- **Total 24H Battery Life:** With the included charging case.
- **IPX5 Waterproof Rating:** Resistant to sweat and splashes.



Image: The Langsdom AirFit earbuds and their charging case, emphasizing their lightweight and portable design.



Image: A visual summary of AirFit features, including IPX5 waterproof rating, soft silicone material, 7g ultra-light design, clear calls, and 24 hours of total battery life with the charging case.

3. Features

- **Open-Ear, Non-Intrusive Design:** Both AirWave Pro and AirFit allow you to enjoy audio while remaining aware of your surroundings, enhancing safety during outdoor activities. This design provides a comfortable, cloud-like wearing experience.
- **Superior Audio Performance:** Experience rich, dynamic sound with advanced bass enhancement and directional audio technology, ensuring clear and full-bodied music playback.
- **Extreme Durability:** The AirWave Pro boasts an IP67 waterproof and dust-resistant rating, while the AirFit has an IPX5 rating. Both are built to withstand sweat, rain, and various outdoor challenges.



Image: The AirFit earbuds being rinsed, demonstrating their IPX5 water resistance and ease of cleaning after workouts.

- **Extended Battery Life with On-The-Go Music Storage:** The AirWave Pro offers up to 17.5 hours of continuous playback and includes built-in 32GB MP3 storage. The AirFit provides long-lasting performance with its charging case, offering a total of 24 hours of battery life.



Image: A user wearing the AirWave Pro, illustrating the MP3 mode feature with a 32GB TF card. It also shows how to download music via an OTG adapter from a phone or computer.

- **Seamless Connectivity & Versatile Use:** Both models benefit from advanced Bluetooth 5.4 technology for uninterrupted music and calls. The AirWave Pro supports dual device connectivity, allowing easy switching between your gadgets, ideal for diverse workout scenarios.

4. Setup

4.1 Initial Charging

Before first use, fully charge your headphones.

- **AirWave Pro:** Connect the charging cable to the headphone's charging port and a USB power source. The LED indicator will show charging status.
- **AirFit:** Place the earbuds into their charging case. Connect the charging case to a USB power source using the provided cable. The case's indicators will show charging status for both the case and earbuds.

4.2 Bluetooth Pairing

To connect your headphones to a device via Bluetooth:

1. Ensure the headphones are charged and powered off.
2. **AirWave Pro:** Press and hold the power button until the LED indicator flashes blue and red, indicating pairing mode.
3. **AirFit:** Open the charging case. The earbuds will automatically enter pairing mode (if not already paired), indicated by flashing lights.
4. On your device (smartphone, tablet, etc.), go to Bluetooth settings and turn Bluetooth on.
5. Select "Langsdom AirWave Pro" or "Langsdom AirFit" from the list of available devices.
6. Once connected, the LED indicator on the headphones will typically show a solid blue light or turn off.

4.3 MP3 Mode (AirWave Pro Only)

The AirWave Pro has 32GB of built-in storage for MP3 files. To transfer music:

- Connect the AirWave Pro to your computer using the provided USB-C cable. It will appear as a removable disk.
- Drag and drop your music files (MP3, WAV, WMA, FLAC, AAC, M4A) into the headphone's storage folder.
- Alternatively, use an OTG adapter to connect the headphone to a compatible smartphone for direct file transfer.
- To switch to MP3 mode, refer to the operating instructions section.

5. Operating Instructions

5.1 Wearing Your Headphones

- **AirWave Pro:** Place the neckband behind your head, with the ear hooks resting comfortably over your ears and the transducers positioned in front of your ear canals.
- **AirFit:** Insert each earbud into the corresponding ear, ensuring the ear hook is securely placed over the top of your ear. Adjust for a snug and comfortable fit.



Image: A man wearing the Langsdom AirWave Pro headphones, demonstrating the proper fit with the neckband behind the head and ear hooks over the ears.

5.2 Basic Controls

Controls may vary slightly between models. Refer to the specific button layout on your device.

Function	Action (AirWave Pro)	Action (AirFit)
Power On/Off	Press and hold Power button	Open/Close charging case (auto) or long press touch area
Play/Pause	Single press Multi-function button	Single tap either earbud
Volume Up	Single press Volume + button	Tap right earbud once
Volume Down	Single press Volume - button	Tap left earbud once
Next Track	Double press Multi-function button	Double tap right earbud

Function	Action (AirWave Pro)	Action (AirFit)
Previous Track	Triple press Multi-function button	Double tap left earbud
Answer/End Call	Single press Multi-function button	Single tap either earbud
Reject Call	Press and hold Multi-function button	Long tap either earbud
Activate Voice Assistant	Press and hold Volume + button	Triple tap either earbud
Switch Bluetooth/MP3 Mode	Press and hold Volume - button	N/A (AirFit does not have MP3 mode)

6. Maintenance

Proper maintenance ensures the longevity and optimal performance of your headphones.

- **Cleaning:** After workouts, especially if exposed to sweat or rain, gently rinse the headphones with clean water. For AirFit, simply rinse to refresh. For AirWave Pro, wipe down with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Drying:** Ensure headphones are completely dry before charging or storing them.
- **Storage:** Store your headphones in a cool, dry place away from direct sunlight and extreme temperatures. For AirFit, always store them in their charging case when not in use.
- **Charging:** Use only the provided charging cables and a compatible USB power adapter. Avoid overcharging.

7. Troubleshooting

If you encounter issues with your Langsdom headphones, try the following solutions:

Problem	Possible Solution
Headphones won't power on	Ensure the headphones are fully charged.
Cannot pair with device	Make sure headphones are in pairing mode. Turn off and on Bluetooth on your device. Forget previous pairings and try again. Move closer to the device.
No sound or low volume	Check volume levels on both headphones and connected device. Ensure headphones are connected. For AirWave Pro, check if it's in MP3 mode instead of Bluetooth.
Intermittent connection	Reduce distance between headphones and device. Avoid obstacles. Ensure no other strong wireless signals are interfering.
MP3 files not playing (AirWave Pro)	Ensure files are in supported formats (MP3, WAV, WMA, FLAC, AAC, M4A). Verify files were transferred correctly. Switch to MP3 mode.
Charging issues	Check charging cable and adapter. Ensure charging ports are clean and free of debris. Try a different power source.

If the problem persists, please contact Langsdom customer support.

8. Specifications

Feature	AirWave Pro	AirFit
Model Style	AirWave Pro	AirFit
Connectivity	Bluetooth 5.4	Bluetooth 5.4
Waterproof Rating	IP67	IPX5
Internal Storage	32GB (MP3, WAV, WMA, FLAC, AAC, M4A)	N/A
Battery Life (Continuous Playback)	Up to 17.5 hours	Up to 24 hours (with charging case)
Weight	26g	7g (per earbud)
Material	Silicone, Plastic	Silicone, Plastic
Included Components	Earphones, Charging Cable	Earphones, Charging Case, Charging Cable
Specific Uses	Fitness, Running, Workout	Fitness, Running, Workout

9. Warranty and Support

Langsdom products are manufactured with high quality standards. For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Langsdom website. You can also contact Langsdom customer service directly for assistance with product inquiries, troubleshooting, or warranty claims.
For more information, visit the Langsdom Store on Amazon.

© 2025 Langsdom. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F4R3HLY5

More documents and user manuals: **https://manuals.plus/**