Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Wildgame Innovations FC-CR1_K98

Wildgame Innovations Terra XT 2.0 Cellular Camera User Manual

Introduction

This manual provides detailed instructions for the Wildgame Innovations Terra XT 2.0 24MP Cellular Camera. It covers setup, operation, maintenance, and troubleshooting to ensure optimal performance of your device.

The Terra XT 2.0 is designed for capturing high-quality 24MP photos and 720p videos, featuring cellular connectivity for remote monitoring via the Huntsmart App.

Package Contents

Verify that all items listed below are included in your package:

- Wildgame Innovations Terra XT 2.0 24MP Cellular Camera (Gray)
- 32GB Ultra SDHC UHS-I Memory Card
- All-In-One High Speed Card Reader

Image: Wildgame Innovations Terra XT 2.0 Cellular Camera bundle, including the camera, a 32GB SD card, and a USB card reader.

Image: A visual representation of the 'What's in the Box' for the Terra XT 2.0, showing the camera, SD card, and card reader.

Setup

1. Battery Installation

The Terra XT 2.0 requires 8 AA batteries (not included). Open the battery compartment and insert the batteries, ensuring correct polarity. For extended use, a 12V DC auxiliary jack is available for external power packs.

2. Memory Card Insertion

Insert the provided 32GB SDHC memory card into the designated slot. Ensure the card is inserted correctly until it clicks into place.

3. Mounting the Camera

Utilize the integrated multi-position mount or the 1/4-20 threaded insert for versatile mounting options. A Python cable provision is included for enhanced security.

Image: The Terra XT 2.0 camera securely mounted on a pole in a natural, wooded setting.



Image: The Terra XT 2.0 camera attached to a tree trunk in a snowy forest, demonstrating its outdoor use.

4. App Integration (Huntsmart App)

Download the Huntsmart App on your mobile device. Follow the in-app instructions to connect and register your Terra XT 2.0 camera for remote control and photo/video on demand features.

Operation

1. Powering On/Off

Locate the power switch on the camera and slide it to the 'ON' position to activate the device. To power off, slide the switch to 'OFF'.

2. Basic Settings

The camera offers customizable settings including:

- **Photo Resolution:** Up to 24MP
- **Video Resolution:** 720p
- **Trigger Speed:** 0.5 seconds
- **Burst Mode:** 1-3 photos per trigger
- **Time-out Delays:** Adjustable from 2-59 seconds or 1-59 minutes between captures.

Refer to the Huntsmart App for detailed configuration of these settings.

Image: An infographic detailing key features of the Terra XT 2.0, such as 24MP resolution, fast trigger speed, and 80ft flash range.

Image: A table outlining the product features of the Terra XT 2.0, including resolutions, trigger speed, and power options.

3. Remote Monitoring with Huntsmart App

Once connected, the Huntsmart App allows you to:

- View captured photos and videos remotely.
- Request photos and videos on demand.
- Adjust camera settings from your mobile device.

Maintenance

To ensure the longevity and optimal performance of your Terra XT 2.0 camera, follow these maintenance guidelines:

- **Cleaning:** Gently wipe the camera lens and housing with a soft, dry cloth. Avoid abrasive cleaners.
- **Battery Check:** Regularly check battery levels, especially before extended deployment. Replace depleted batteries

promptly to prevent corrosion.

- **Storage:** When not in use, store the camera in a cool, dry place, away from direct sunlight and extreme temperatures. Remove batteries during long-term storage.
- **Firmware Updates:** Check the Wildgame Innovations website or Huntsmart App for any available firmware updates to ensure your camera has the latest features and bug fixes.

Troubleshooting

If you encounter issues with your Terra XT 2.0 camera, refer to the following common solutions:

- **Camera Not Powering On:** Ensure batteries are correctly installed and fully charged. Check for corrosion in the battery compartment. If using an external power source, verify its connection and functionality.
- **No Photos/Videos Captured:** Verify the SD card is properly inserted and not full. Check camera settings for trigger delays and burst mode. Ensure the detection range is clear of obstructions.
- **Poor Image Quality:** Clean the camera lens. Ensure the camera is securely mounted to prevent movement. Check lighting conditions and adjust camera placement if necessary.
- **Cellular Connectivity Issues:** Confirm your camera is registered with the Huntsmart App. Check cellular signal strength in the camera's location. Ensure your data plan is active.
- **App Connection Problems:** Ensure your mobile device has an active internet connection. Restart the Huntsmart App and your camera.

For further assistance, contact Wildgame Innovations customer support.

Specifications

Feature	Detail
Model Number	FC-CR1_K98
Photo Resolution	Up to 24MP
Video Resolution	720p
Trigger Speed	0.5 seconds
Detection & Flash Range	80 feet
Burst Mode	1-3 photos per trigger
Power Source	8 AA Batteries (not included), 12V DC Auxiliary Jack
App Compatibility	Huntsmart App
Product Dimensions	10.4 x 8.4 x 6.6 inches
Item Weight	1.62 pounds
UPC	196271281399

Warranty and Support

For warranty information and customer support, please visit the official Wildgame Innovations website or contact their

customer service department. Keep your purchase receipt for warranty claims.

Manufacturer: Wildgame Innovations

Website: Wildgame Innovations Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F4SV24LT

More documents and user manuals: **https://manuals.plus/**