ZAQE M4

ZAQE M4 MP3 Player with Bluetooth 5.3 User Manual

Model: M4

INTRODUCTION

This manual provides detailed instructions for the operation and maintenance of your ZAQE M4 MP3 Player. Please read this manual thoroughly before using the device to ensure proper functionality and longevity.

Image: Front view of the ZAQE M4 MP3 Player with its touch screen displaying various app icons (Music, Movie, Radio, Bluetooth, EBook, Settings, Record, Folder, Photo) and wired earbuds connected.

PACKAGE CONTENTS

Verify that all items are present in the package:

- ZAQE M4 MP3 Player
- USB Type-C Charging Cable
- Wired Earphones
- User Manual

Image: A visual representation of the ZAQE MP3 Player and its included accessories: the player itself, a charging cable, wired earphones, and the user manual.

DEVICE OVERVIEW

2.4" Curved Color TouchScreen

Volume+

Volume-

Power ON/OFF

Type-C

Reset

3.5mm
Headphone Jack

TF Card Slot

Image: Side view of the ZAQE M4 MP3 Player, highlighting its physical features: Volume+ button, Volume- button, Power ON/OFF button, Type-C port, Reset button, 3.5mm Headphone Jack, and TF Card Slot.

- **Volume +:** Increase volume.
- **Volume -:** Decrease volume.
- **Power ON/OFF:** Press and hold to power on/off. Short press to turn screen on/off.
- **Type-C Port:** For charging and data transfer.
- **Reset Button:** Small pinhole for device reset.
- **3.5mm Headphone Jack:** Connect wired headphones.
- **TF Card Slot:** Insert a MicroSD card for expanded storage (up to 128GB).

SETUP

1. Charging the Device

Before first use, fully charge the MP3 player. Connect the provided Type-C USB cable to the player's Type-C port and the other end to a USB power adapter (not included) or a computer's USB port. The battery indicator on the screen will show charging status.

Image: The ZAQE M4 MP3 Player connected via its Type-C port to a charging cable, indicating the charging process.

2. Inserting a MicroSD Card (Optional)

To expand storage, insert a MicroSD card (up to 128GB) into the TF Card Slot. Ensure the card is inserted correctly until it clicks into place.

3. Powering On/Off

- **Power On:** Press and hold the Power ON/OFF button for a few seconds until the screen lights up.
- **Power Off:** Press and hold the Power ON/OFF button for a few seconds. A power-off prompt will appear; confirm to shut down.
- **Screen On/Off:** Short press the Power ON/OFF button to turn the screen on or off without powering down the device.

OPERATING INSTRUCTIONS

Navigation

The device features a 2.4-inch full touch screen. Swipe left/right or tap icons to navigate through menus and applications.

1. Music Playback

1. **Transferring Music:** Connect the MP3 player to a computer using the Type-C cable. The player will appear as a removable disk. Drag and drop music files (MP3, WAV, WMA, APE, FLAC, AAC) into the "Music" folder on the device or MicroSD card.

2. **Playing Music:** Tap the "Music" icon on the home screen. Browse by artist, album, genre, or all songs. Tap a song to begin playback.

3. **Playback Controls:** Use the on-screen controls for play/pause, next/previous track, shuffle, and repeat. Volume can be adjusted using the side buttons.


Image: The ZAQE M4 MP3 Player screen showing a music playback interface with album art, song title, artist, progress bar, and control buttons.

Your browser does not support the video tag.

Video Description: A short clip demonstrating the music playback interface and controls on the ZAQE M4 MP3 Player.

2. Bluetooth Connectivity

The player supports Bluetooth 5.3 for wireless audio output.

1. **Enable Bluetooth:** Tap the "Bluetooth" icon on the home screen or go to "Settings" > "Bluetooth" and turn it on.

2. **Pairing:** The player will automatically search for nearby Bluetooth devices. Select your desired device (e.g.,

headphones, speaker) from the list to pair.

3. **Connection Range:** The effective range for Bluetooth connection is approximately 10-15 meters in open areas.

Image: The ZAQE M4 MP3 Player shown next to a laptop and wireless earbuds, illustrating its Bluetooth 5.3 connectivity for faster and more stable connections.

Your browser does not support the video tag.

Video Description: A short clip demonstrating the Bluetooth pairing process on the ZAQE M4 MP3 Player with wireless earbuds.

3. FM Radio

To use the FM Radio function, connect wired headphones to the 3.5mm jack, as they act as the antenna.

1. Tap the "Radio" icon.
2. Use the on-screen controls to scan for stations or manually tune to a frequency.

Image: The ZAQE M4 MP3 Player screen showing the FM Radio interface with frequency display and controls, next to a pair of wired headphones.

4. Video Playback

The player supports AMV and AVI video formats.

1. **Transferring Videos:** Connect the player to a computer and transfer AMV or AVI video files to the "Video" folder.
2. **Playing Videos:** Tap the "Movie" icon on the home screen. Select a video file to play.

Image: The ZAQE M4 MP3 Player screen displaying a video scene, demonstrating its video playback capability.

Your browser does not support the video tag.

Video Description: A short clip demonstrating video playback on the ZAQE M4 MP3 Player.

5. Voice Recorder

1. Tap the "Record" icon.
2. Tap the record button to start recording. Tap again to pause/stop.
3. Recordings are saved and can be accessed from the "Folder" or "Record" menu.

Image: The ZAQE M4 MP3 Player screen showing the voice recording interface with a microphone icon and recording controls.

6. E-Book Reader

The player supports e-book functionality.

1. Transfer compatible e-book files to the device.
2. Tap the "EBook" icon to access your e-book library.

Image: The ZAQE M4 MP3 Player screen displaying text from an e-book, next to an open physical book, illustrating its e-book reading feature.

7. Settings

Access the "Settings" menu to configure various device options, including:

- Display brightness and timeout
- Date and time
- Language
- Storage management
- System information

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the device. Avoid liquid cleaners or abrasive materials.
- **Storage:** Store the player in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.
- **Software Updates:** Check the manufacturer's website for any available firmware updates to ensure optimal performance.

TROUBLESHOOTING

Problem	Solution
Device does not power on.	Ensure the device is fully charged. If unresponsive, press the reset button with a thin pin.
Cannot connect to Bluetooth device.	Ensure Bluetooth is enabled on both devices and they are within range. Try unpairing and re-pairing.
Music/Video files not playing.	Verify that the file format is supported (MP3, WAV, WMA, APE, FLAC, AAC for audio; AMV, AVI for video). Ensure files are transferred to the correct folders.
Screen is unresponsive.	Try restarting the device. If the issue persists, use the reset button.
FM Radio not working.	Ensure wired headphones are connected, as they serve as the antenna.

SPECIFICATIONS

Feature	Detail
Model	M4
Brand	ZAQE
Display	2.4-inch Full Touch IPS Screen
Internal Storage	64 GB
Expandable Storage	Up to 128 GB via MicroSD card (TF Card Slot)
Bluetooth Version	5.3
Audio Formats	MP3, WAV, WMA, APE, FLAC, AAC
Video Formats	AMV, AVI
Battery Life	Up to 40 hours (audio playback)
Connectivity	Bluetooth, USB Type-C, 3.5mm Audio Jack
Dimensions	5.75 x 5.75 x 0.75 inches (Package)
Weight	7 ounces (Item)

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the contact details provided with your purchase or visit the official ZAQE website. Keep your proof of purchase for warranty claims.

Manufacturer: ZAQE

ASIN: B0F5MLDM9Q

Related Documents - M4

ZAQE USER MANUAL Digital Player	**ZAQE P30 User Manual: High-Resolution Digital Audio Player Guide** User manual for the ZAQE P30 high-resolution digital audio player. This guide covers setup, operation, features like Bluetooth and WiFi, system settings, troubleshooting, and detailed product specifications for the ZAQE P30.
ZAQE USER MANUAL Voice recorder	**ZAQE-A55 Digital Voice Recorder User Manual** This user manual provides comprehensive instructions for operating the ZAQE-A55 Digital Voice Recorder, covering basic operations, recording features, music playback, settings, and technical specifications.
ZAQE USER MANUAL DIGITAL PLAYER	**ZAQE M505 Pro Digital Player User Manual** Comprehensive user manual for the ZAQE M505 Pro Digital Player, covering setup, features, troubleshooting, and specifications. Learn how to download music, manage settings, and get the most out of your device.
ZAQE USER MANUAL DIGITAL PLAYER	**ZAQE M505 Pro Digital Player User Manual** Comprehensive user manual for the ZAQE M505 Pro digital player, covering setup, features, troubleshooting, and specifications. Learn how to download music, manage playlists, and use various device settings.
USER MANUAL Voice Recorder	**V66 Voice Recorder User Manual** User manual for the V66 Voice Recorder by ZAQE, detailing its basic operations, app integration, recording functions, file management, and technical specifications.
USER MANUAL	**M4 Portable MP3 Player User Manual** Comprehensive user manual for the M4 portable MP3 player, detailing features, operation, charging, data transfer, music playback, video, FM radio, Bluetooth connectivity, and specifications. Learn to use your M4 music player effectively.