Manuals+
Q & A | Deep Search | Upload

wowlink W210

wowlink W210 Mini Projector User Manual

Model: W210

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your wowlink W210 Mini Projector. Please read this manual thoroughly before using the product to ensure proper function and to maximize your viewing experience. Keep this manual for future reference.

Important Safety Information

- Do not expose the projector to rain or moisture to prevent fire or electric shock.
- Do not open the casing. Refer all servicing to qualified personnel.
- Ensure proper ventilation. Do not block ventilation openings.
- Avoid direct eye exposure to the projector lens when the lamp is on.
- Use only attachments/accessories specified by the manufacturer.
- Operate the projector in a dark environment for optimal image quality.

Package Contents

Verify that all items listed below are included in your package:

- wowlink W210 Mini Projector
- Remote Control (with Air Remote function)
- Power Adapter
- HDMI Cable
- User Manual (this document)

Product Overview

The wowlink W210 is a portable mini projector featuring WiFi 6, Bluetooth 5.4, and built-in streaming applications. It supports 4K video playback with a native 720P resolution and offers 180° rotation for versatile projection.

Image: The wowlink W210 Mini Projector, shown with its remote control and an optional mouse, projecting content from various streaming services.

Key Features:

- **Air Remote Function:** Gyroscope-based remote for intuitive screen control.
- **Built-in Applications:** Pre-installed Netflix, Prime Video, YouTube, and D+.
- **Display:** Native 720P resolution, supports 4K HDR video, 200 ANSI lumens, 10000:1 contrast ratio.
- **Connectivity:** Dual-band WiFi 6 (2.4GHz/5GHz) and Bluetooth 5.4.
- **Audio:** Built-in immersive base-type stereo speaker.
- **Versatility:** 180° rotatable design for wall or ceiling projection, 0.25-inch screw hole for tripod/mount.
- **Auto Keystone:** Automatic image correction.

Setup Guide

1. Power Connection

1. Connect the power adapter to the projector's power input port.
2. Plug the power adapter into a wall outlet. The projector will power on or enter standby mode.

2. Placement and Projection Angle

The W210 projector features a 180° rotatable design, allowing flexible placement and projection onto walls or ceilings.

Image: The projector demonstrating its 180° rotation capability for projecting onto various surfaces, including walls and ceilings.

- Place the projector on a stable surface.
- Adjust the projector's angle by rotating its body to direct the image onto your desired surface (wall, screen, or ceiling).

- For ceiling or wall mounting, use the 0.25-inch screw hole at the bottom with a compatible tripod or mount (sold separately).

3. Auto Keystone Correction

The projector automatically corrects trapezoidal distortion to ensure a rectangular image.

Image: The projector automatically adjusting the image to a perfect rectangle using its auto keystone correction feature, shown with a large screen display.

- After positioning the projector, the auto keystone function will activate to square the image.
- If manual adjustment is needed, navigate to the settings menu using the remote control.

4. Remote Control Pairing (Air Remote)

The remote control features an Air Remote function for intuitive navigation.

Image: A visual guide demonstrating the steps to pair the Air Mouse Remote Control with the projector.

1. Ensure Bluetooth is enabled on the projector (usually enabled by default).
2. Press and hold the Left and Right arrow buttons on the remote simultaneously until the projector beeps.
3. Press the "mouse" icon button on the remote to activate Air Mouse mode.
4. Shake your wrist to move the cursor on the screen. Press the "OK" button to select.

5. Network Connection (WiFi 6)

Connect your projector to a wireless network for internet access and streaming.

- Navigate to the "Settings" menu on the projector.
- Select "Network" or "Wi-Fi Settings".
- Choose your desired Wi-Fi network from the list.
- Enter the password if prompted and confirm the connection.

6. Bluetooth Connection

Connect external Bluetooth devices like speakers or headphones.

- Go to "Settings" and select "Bluetooth".
- Ensure Bluetooth is turned on.
- Put your Bluetooth device into pairing mode.
- Select your device from the list of available devices on the projector screen to pair.

7. External Device Connection

The projector supports HDMI and USB connections.

Image: An illustration detailing the various devices that can be connected to the projector via HDMI (laptops, PCs, TV sticks, gaming consoles) and USB (USB drives, phones).

- **HDMI:** Connect laptops, PCs, TV sticks, or gaming consoles using an HDMI cable. Select the HDMI input source from the projector's menu.
- **USB:** Insert USB drives for media playback. Select the USB input source from the projector's menu.

Operating Instructions

1. Navigating the Interface

- Use the directional buttons on the remote control to move between menu items.
- Press the "OK" button to select an item.
- Use the "Back" button to return to the previous screen.
- Activate the Air Remote function for a mouse-like cursor experience.

2. Using Built-in Applications

The projector comes with pre-installed streaming apps like Netflix, Prime Video, YouTube, and D+.



Image: The projector displaying its home screen with various built-in Android TV applications, including Netflix, Prime Video, and YouTube.

- Ensure the projector is connected to Wi-Fi.
- From the home screen, select the desired application icon.
- Log in with your account credentials if required by the application.
- Browse and play content directly.

3. Screen Mirroring (Wireless Projection)

Wirelessly project content from your smartphone, tablet, or computer.

- Ensure both the projector and your device are connected to the same Wi-Fi network.
- On the projector, select the "Screen Mirroring" or "Wireless Projection" option.
- On your mobile device (Android/iOS) or computer (Windows/macOS), activate its screen mirroring feature (e.g., Miracast, AirPlay, or equivalent).
- Select the projector from the list of available devices.

4. Adjusting Settings

Access the settings menu to customize image, sound, and system preferences.

- **Image Settings:** Adjust brightness, contrast, color, and aspect ratio.
- **Sound Settings:** Control volume, audio output (internal speaker or Bluetooth), and sound modes.
- **System Settings:** Manage network connections, language, date/time, and software updates.

Maintenance

1. Cleaning the Lens

- Use a soft, lint-free cloth specifically designed for optical lenses.
- Gently wipe the lens in a circular motion. Do not use abrasive cleaners or excessive force.

2. General Care

- Keep the projector in a clean, dry environment.
- Avoid placing the projector near heat sources or in direct sunlight.
- Ensure ventilation openings are clear of obstructions to prevent overheating.
- When not in use, cover the lens with its cap to protect it from dust.

Troubleshooting

Problem	Possible Solution
No image or blurry image	• Ensure the power cable is securely connected. • Check if the lens cap is removed. • Verify the input source is correctly selected (HDMI, USB, or built-in apps). • Allow auto keystone correction to complete. If needed, manually adjust focus in settings. • Ensure the projection surface is flat and clear.
No sound	• Increase the volume on the projector and the source device. • Check if the projector is connected to external Bluetooth speakers. If so, ensure they are powered on and paired correctly. • If using HDMI, ensure the audio output from the source device is enabled.
Wi-Fi connection issues	• Ensure the projector is within range of your Wi-Fi router. • Verify the Wi-Fi password is entered correctly. • Restart the projector and your Wi-Fi router. • Check for any network interference.

Problem	Possible Solution
Remote control not responding	• Ensure the remote control has fresh batteries. • Re-pair the remote control following the "Remote Control Pairing" instructions in the Setup Guide. • Ensure there are no obstructions between the remote and the projector.

Specifications

Feature	Detail
Brand	wowlink
Model	W210
Native Resolution	1280 x 720 pixels (720P)
Supported Resolution	Up to 3840 x 2160 pixels (4K)
Brightness	200 ANSI Lumens
Contrast Ratio	10000:1
Display Type	LCD
Connectivity	Bluetooth 5.4, HDMI, Wi-Fi 6 (Dual-band 2.4GHz/5GHz)
Built-in Apps	Netflix, Prime Video, YouTube, D+
Dimensions (L x W x H)	3.66 x 3.66 x 6.97 inches
Weight	13 ounces

Warranty and Support

wowlink is committed to providing high-quality products and customer service.

- **Manufacturer Warranty:** Your wowlink W210 Mini Projector is covered by a **24-month manufacturer warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.
- **Technical Support:** We offer **lifetime technical support** for your product. If you encounter any issues or have questions, please contact our customer support team.
- **Returns and Exchanges:** A **30-day free return and exchange** policy is available from the date of purchase.
- **Customer Support:** For assistance, please refer to the contact information provided on the wowlink official website or your purchase platform. Our customer support is available 24 hours.

Related Documents - W210

	Lyngdorf W210 Owner's Manual Owner's manual for the Lyngdorf W210 BassDirect speaker, covering placement, connection, setup, cleaning, and technical specifications.
	Fuers W100/W200 Series Intelligent Double Network Alarm System: Instruction Manual Comprehensive instruction manual for the Fuers W100 and W200 Series Intelligent Double Network Alarm Systems, covering setup, features, networking, and technical specifications.
	Premio AIO-W210-ADL Industrial Touchscreen Computer Getting Started Guide for AWS IoT Greengrass A comprehensive getting started guide for the Premio AIO-W210-ADL 10.1" IP65 All-In-One Industrial Touchscreen Computer, focusing on setup for AWS IoT Greengrass. Includes hardware overview, development environment setup, AWS account configuration, and component creation.
	Premio AIO-W210-ASL-3L 10.1-inch IP65 All-in-One Touchscreen Computer Datasheet Detailed technical specifications, features, and compliance information for the Premio AIO-W210-ASL-3L, a rugged 10.1-inch WXGA IP65 all-in-one touchscreen computer powered by Intel N97 or Atom x7835RE processors, designed for industrial applications.
	Premio AIO-200-ROK Series All-in-One Touchscreen Computer User Manual Comprehensive user manual for the Premio AIO-200-ROK Series All-in-One Touchscreen Computers, covering hardware specifications, system setup, firmware flashing, and mounting instructions. Includes details on models AIO-W210-RK3568J and AIO-W215-RK3568J.
	Videofied Centrale D'Alarme W et WIP Installation Manual Comprehensive installation manual for the Videofied Centrale D'Alarme W et WIP alarm system, covering setup, configuration, programming, functions, safety notes, and technical specifications.

[pdf]

W O L I N K 2 1 0wowlinkw210 hc enhcinema de wowlinkw210 en |||

Wowlink **W210** WOWLINK **W210** Screen Projector Brief Introduction Beta 2.5 Display Type Ansi-Lumen Contrast Black Level Offset Resolution Video Modes Application Light Source Light Life Operating Costs Focus Zoom Objective Throw Ratio Audio Connections Brief introduction to the Wowlink **W210**. The LCD ...

lang:en score:22 filesize: 612.63 K page_count: 2 document date: 2025-08-25