Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MERACH MR-R23

MERACH R23 Eco Water Rowing Machine User Manual

Model: MR-R23 | Brand: MERACH

1. Introduction

Thank you for choosing the MERACH R23 Eco Water Rowing Machine. This manual provides essential information for the safe assembly, operation, and maintenance of your new fitness equipment. The R23 Eco is designed to deliver an immersive, full-body workout experience, combining the natural feel of water resistance with a durable, space-saving design. Please read this manual thoroughly before use.

2. Safety Information

Before beginning any exercise program, consult with your physician. It is crucial to follow all safety instructions to prevent injury and ensure proper operation of the machine.

- Ensure the rowing machine is placed on a flat, stable surface.
- Keep children and pets away from the machine during operation.
- Inspect the machine for any loose parts or damage before each use. Do not use if damaged.
- The maximum user weight capacity for this machine is 350 lbs (158 kg).
- Wear appropriate athletic footwear and clothing during workouts.
- Do not overfill the water tank.
- Use caution when folding or unfolding the machine to avoid pinching.

3. Package Contents

Carefully unpack all components and verify that you have received the following items:

- R23 Wood Rowing Machine x 1
- User Manual x 1
- Parts Kit x 1 (includes all necessary hardware for assembly)
- Electric Water Pump x 1
- Water Blue Pills x 1 (for water treatment)



Image: The MERACH R23 Eco Water Rowing Machine, showcasing its design and foldable capability.

4. Setup and Assembly

The MERACH R23 Eco Water Rowing Machine arrives 98% pre-assembled, allowing for a quick setup in approximately 10-15 minutes. Refer to the included User Manual and Parts Kit for detailed step-by-step instructions.

4.1 Initial Assembly

Follow the graphical instructions in the provided user manual to connect the main components using the hardware from the Parts Kit. Ensure all bolts and screws are securely tightened before proceeding.

4.2 Filling the Water Tank

Use the electric water pump to fill the water tank. The tank has a 15L capacity. Do not overfill. Add one water blue pill to the tank to help keep the water clean and prevent algae growth. Repeat this treatment every 6 months or as needed.

4.3 Folding and Storage

The R23 Eco features an innovative foldable design for convenient storage. Simply lift the rear section of the rower to fold it upright. The built-in wheels allow for easy one-handed movement and compact vertical storage, taking up minimal floor space.



Image: The MERACH R23 Eco Water Rowing Machine in its folded, upright storage position.

5. Operating Instructions

5.1 Understanding Water Resistance

The MERACH R23 Eco utilizes natural water resistance, providing a smooth and consistent rowing feel. The resistance level is dynamic and increases with the intensity of your stroke. The 12-blade design ensures consistent contact with water, offering a realistic and immersive experience.



Image: Detailed view of the water tank and 12-blade impeller system.

5.2 Using the Dedicated Monitor

The LCD-backlit display tracks key workout metrics in real-time, including:

- Time
- Distance
- Calories Burned
- Strokes per Minute

Refer to the monitor's specific instructions in the main user manual for navigation and reset functions.

5.3 App Connectivity (Bluetooth)

Enhance your rowing experience by connecting your machine via Bluetooth to the free MERACH App on your smartphone or tablet. The app allows for real-time data syncing, personalized workout plans, and interactive features to keep you motivated.

- Download the MERACH App from the App Store (iOS) or Google Play Store (Android).

- Enable Bluetooth on your device.
- Open the MERACH App and follow the on-screen instructions to pair with your rowing machine.



Image: The MERACH App interface for workout planning and tracking.

5.4 Ergonomic Features

The R23 Eco is designed for comfort and safety:

- **Elevated Rail Height:** Provides a more comfortable experience, especially for taller users (up to 6ft8in).
- **Upgraded Leather Handle:** Soft and contoured to prevent blisters and improve grip.
- **Adjustable Foot Straps:** Customizable to fit various foot shapes, with Achilles tendon support to prevent chafing.



Image: Details of the ergonomic handle and foot straps.

6. Maintenance

Regular maintenance will ensure the longevity and optimal performance of your MERACH R23 Eco Water Rowing Machine.

- **Water Treatment:** Add one water blue pill to the tank every 6 months to prevent algae and keep the water clear.
- **Cleaning:** Wipe down the wood frame and other surfaces with a soft, damp cloth after each use. Avoid abrasive cleaners.
- **Inspection:** Periodically check all bolts, nuts, and moving parts for tightness and wear. Tighten as necessary.
- **Storage:** Store the machine in a dry, cool place away from direct sunlight and extreme temperatures.

7. Troubleshooting

If you encounter any issues with your MERACH R23 Eco Water Rowing Machine, please refer to the following common solutions:

Problem	Possible Cause	Solution
Monitor not turning on	Dead batteries	Replace the 2 AAA batteries.
No resistance or inconsistent resistance	Insufficient water level in tank	Add water to the tank using the electric pump.
Squeaking or unusual noises	Loose connections or dry moving parts	Check and tighten all bolts. Apply a small amount of silicone lubricant to moving parts if necessary.
Bluetooth connectivity issues	Bluetooth off on device or app not updated	Ensure Bluetooth is enabled and the MERACH App is updated to the latest version. Restart both devices.

If the problem persists, please contact MERACH customer support for assistance.

8. Specifications

Feature	Detail
Brand	MERACH
Model Name	MR-R23
Style	R23 Eco - Rubberwood
Frame Material	Wood (Solid Wood)
Color	SOLID WOOD
Resistance Mechanism	Water
Product Dimensions (LxWxH)	71"D x 16"W x 16"H (180cm x 40.6cm x 40.6cm)
Item Weight	70 Pounds (31.75 kg)
Maximum Weight Recommendation	350 Pounds (158 kg)
Tension Level	Adjustable (based on stroke intensity and water level)
Power Source	Manual (monitor requires batteries)
Number of Batteries	2 AAA batteries required (for monitor)
Display Type	LCD
Special Feature	Foldable, Easy Assembly, Adjustable Footpad

9. Warranty and Customer Support

MERACH is committed to providing excellent customer service and product quality.

9.1 Product Warranty

This MERACH R23 Eco Water Rowing Machine comes with a 12-month warranty from the date of purchase, covering

manufacturing defects. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For any questions, technical assistance, or warranty inquiries, please contact MERACH customer support. We provide 24/7 customer support and lifetime technical support on Amazon to ensure a superior experience.
You can typically find contact information on the MERACH official website or through your purchase platform.

© 2025 MERACH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F6L8V9JF

More documents and user manuals: **https://manuals.plus/**