Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DUMOS X10DBK

DUMOS Countertop Ice Maker User Manual - Model X10DBK

Introduction

This manual provides detailed instructions for the safe and efficient operation of your DUMOS Countertop Ice Maker, Model X10DBK. Please read this manual thoroughly before first use and retain it for future reference. This appliance is designed to produce bullet-shaped ice cubes for various uses, offering convenience and portability.

Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using electrical appliances.

- Read all instructions before use.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Ensure the appliance is placed on a stable, level surface, away from heat sources and direct sunlight.
- This appliance is for household use only.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Keep children away from the appliance.
- Use only potable water in the ice maker.
- Do not block ventilation openings.
- Do not use abrasive cleaners or sharp objects to clean the interior.

Package Contents

Verify that all items are present upon unpacking:

- DUMOS Countertop Ice Maker
- Ice Scoop
- Removable Ice Basket

Product Overview

Familiarize yourself with the components of your DUMOS Countertop Ice Maker.



Image: The DUMOS Countertop Ice Maker, showing its compact black design, transparent lid, and an external ice basket with an ice scoop.



Image: Close-up of the DUMOS Ice Maker's control panel, highlighting the 'ICEFULL', 'ADD WATER', 'POWER' indicators, and 'SELEC', 'ON/OFF CLEAN' buttons, along with 'LARGR' and 'SMALL' ice size options.

Setup Instructions

1. **Unpack the Appliance:** Carefully remove the ice maker from its packaging.
2. **Placement:** Place the ice maker on a flat, stable surface. Ensure there is adequate ventilation around the unit (at least 4 inches of space on all sides). Avoid placing it near heat sources or in direct sunlight.
3. **Initial Cleaning:** Before first use, clean the interior of the ice maker. Refer to the "Maintenance" section for detailed cleaning instructions.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.
5. **Water Fill:** Open the lid and remove the ice basket. Fill the water reservoir with potable water up to the MAX fill line. Do not overfill.

Operating Instructions

Follow these steps to produce ice with your DUMOS Countertop Ice Maker.

1. **Power On:** Press the **ON/OFF CLEAN** button to turn on the ice maker. The **POWER** indicator light will illuminate.
2. **Select Ice Size:** Press the **SELEC** button to choose between small (SMALL) or large (LARGR) ice cubes. The corresponding indicator light will illuminate. Small ice cubes are approximately 22x24mm, and large ice cubes are approximately 25x26mm.
3. **Ice Production:** The ice maker will begin the ice-making cycle. The first batch of ice cubes will be ready in approximately 6-9 minutes, depending on the selected size and ambient temperature.



Image: The DUMOS Ice Maker actively producing bullet-shaped ice cubes, demonstrating its fast ice-making capability.

4. **Ice Full Indicator:** When the ice basket is full, the **ICEFULL** indicator light will turn on, and the ice making process will pause. Remove ice from the basket to resume production.
5. **Add Water Indicator:** If the water level in the reservoir is too low, the **ADD WATER** indicator light will illuminate. Add more potable water to the reservoir to continue ice production.
6. **Power Off:** To stop the ice maker, press the **ON/OFF CLEAN** button again.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and hygiene of your ice maker.

Daily Cleaning

- After each use, drain any remaining water from the reservoir.
- Wipe the interior with a soft cloth and mild detergent. Rinse thoroughly.
- Clean the ice scoop and ice basket with warm, soapy water.

Self-Cleaning Function

The DUMOS ice maker features a self-cleaning function for effortless maintenance.

1. Ensure the water reservoir is filled with clean water.
2. Press and hold the **ON/OFF CLEAN** button for approximately 5 seconds. The self-cleaning cycle will begin.
3. The cycle typically lasts for 15 minutes. During this time, the machine will circulate water to clean internal components.
4. Once the cycle is complete, drain the water from the reservoir and wipe the interior dry.



Image: The DUMOS Ice Maker undergoing its self-cleaning cycle, showing water circulating within the reservoir for thorough cleaning.

Long-Term Storage

- Perform a thorough cleaning and drying of the entire unit.
- Ensure all water is drained from the reservoir and internal components.
- Store the ice maker in a cool, dry place, away from direct sunlight.

Troubleshooting Guide

Refer to this section for solutions to common issues you may encounter.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Ice maker not producing ice.	No water in reservoir. Power not connected. Ambient temperature too high.	Add water to the MAX fill line. Ensure the power cord is securely plugged in. Operate in a cooler environment.
"ADD WATER" indicator is on.	Water level is low.	Refill the water reservoir with potable water.
"ICEFULL" indicator is on.	Ice basket is full.	Remove ice from the basket.
Ice cubes are too small or clumpy.	Insufficient water or mineral buildup. Water temperature too high.	Ensure reservoir is filled. Perform self-cleaning. Use colder water.
Unusual noise during operation.	Normal operation sounds (compressor, water pump). Unit not level.	Ensure the unit is on a stable, level surface. If noise is excessive or unusual, contact customer support.

Specifications

Feature	Detail
Model Name	DUMOS Countertop Ice Maker
Model Number	X10DBK
Product Dimensions (D x W x H)	11.4"D x 8.7"W x 10.6"H
Capacity	1.5 Liters (Water Reservoir)
Ice Production Rate	Up to 26.5 lbs per 24 hours
Ice Production Cycle	9 bullet ice cubes in 6-9 minutes
Voltage	115 Volts
Refrigerant	R600a
Item Weight	15.43 pounds
Material	Alloy Steel, Plastic
Noise Level	Under 40dB



Image: Diagram illustrating the compact dimensions of the DUMOS Ice Maker: 11.4 inches deep, 8.9 inches wide, and 10.6 inches high.

Warranty and Support

For product support, troubleshooting assistance, or warranty information, please refer to the official DUMOS website or contact their customer service.

Additional protection plans may be available for purchase:

- 2-Year Protection Plan
- 3-Year Protection Plan

A digital version of this user manual is available for download:DUMOS Countertop Ice Maker User Manual (PDF)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question