Manuals+
Q & A | Deep Search | Upload

WUPRO G1

WUPRO Cinema G1 Smart Projector Instruction Manual

Model: G1

1. Introduction

This manual provides essential information for the safe and efficient operation of your WUPRO Cinema G1 Smart Projector. Please read it thoroughly before use and retain it for future reference.

Image 1.1: The WUPRO Cinema G1 Smart Projector, a compact and portable device designed for home cinema.

2. Important Safety Instructions

To ensure safe operation and prevent damage, observe the following precautions:

- Read all instructions before operating the projector.
- Do not use this apparatus near water or in excessively humid environments.
- Clean the projector only with a dry cloth. Avoid liquid or aerosol cleaners.
- Do not block any ventilation openings. Ensure proper airflow around the device to prevent overheating.
- Install the projector in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Only use attachments and accessories specified by the manufacturer.
- Refer all servicing to qualified service personnel. Do not attempt to repair the device yourself.

3. Package Contents

Verify that all items are present in the package:

- WUPRO Cinema G1 Smart Projector
- Remote Control
- Power Adapter
- User Manual (this document)

4. Setup Guide

4.1. Placement

Position the projector on a stable, flat surface. Ensure adequate ventilation around the device. The projector can cast a screen size from 40 to 120 inches. For optimal viewing, place the projector at a distance that achieves your desired screen size, typically between 1.2 to 3.6 meters (approximately 4 to 12 feet) from the projection surface.

Image 4.1: The WUPRO Cinema G1 projecting a large, immersive display up to 120 inches in a home environment.

4.2. Power Connection

Connect the power adapter to the DC input port on the projector. Then, plug the power adapter into a standard electrical outlet. Use only the provided power adapter.

Image 4.2: Rear view of the projector highlighting the DC power input, HDMI, USB, and audio ports.

4.3. Initial Power On

Press the power button on the projector or the remote control to turn on the device. Follow the on-screen instructions for the initial setup process, which typically includes language selection, network connection (Wi-Fi), and Google account login.

5. Operating Instructions

5.1. Smart Adjustments

The Cinema G1 features advanced automatic adjustments to ensure a clear and properly aligned image:

- **Auto Focus:** The projector automatically adjusts the image clarity to ensure a sharp picture.
- **Auto Keystone:** This feature automatically corrects distorted images, ensuring the projection is rectangular even

if the projector is not perfectly aligned with the screen.

- **Obstacle Avoidance:** The projector can detect obstacles in the projection path and automatically adjust the image size and position to avoid them.



Image 5.1: Visual representation of the projector's automatic keystone correction, auto focus, and obstacle avoidance capabilities.

5.2. Connectivity

Utilize the various ports and wireless options for connecting external devices:

- **HDMI 2.1:** Connect devices such as laptops, set-top boxes, DVD players, or gaming consoles for high-definition video and audio input.
- **USB 3.0:** Insert USB flash drives or portable hard disks to play media files directly from storage.
- **Audio (3.5mm):** Connect external headphones or speakers for private listening or enhanced audio output.
- **Bluetooth:** Pair with Bluetooth-enabled audio devices like speakers or headphones for wireless sound.

5.3. Smart Features (Google TV & Casting)

The projector comes with a pre-installed authentication system and built-in Google TV, offering a wide range of entertainment options. It supports multi-language interface switching.

- **Google TV:** Access thousands of apps, games, and streaming services, including popular platforms like Netflix, directly from the projector's interface.
- **Google Cast:** Stream videos, music, and apps effortlessly from your compatible smartphone or laptop to the projector's large screen.

Image 5.2: The Google TV home screen displaying various streaming applications available on the projector.

Image 5.3: A smartphone screen being cast wirelessly to the WUPRO Cinema G1 projector.

5.4. Audio

The projector is equipped with dual 5W speakers, providing clear and immersive sound. It also supports Dolby Audio for an enhanced listening experience.



Image 5.4: The projector responding to a 'Hey Google' voice command, indicating integrated smart assistant functionality.

6. Maintenance

6.1. Cleaning

To maintain optimal performance and appearance:

- Clean the projector's exterior with a soft, dry, lint-free cloth. Do not use abrasive cleaners, waxes, or solvents.
- Gently clean the projector lens with a lens cleaning cloth or brush designed for optical surfaces. Avoid touching the lens directly with your fingers.

6.2. Dust Prevention

The WUPRO Cinema G1 features a fully enclosed light engine design. This advanced design helps to keep the projector's internal optical components free from dust, preventing the appearance of black spots on the display and ensuring the image remains pristine over time.

Image 6.1: An internal view of the projector, illustrating the enclosed light engine for enhanced dust protection and extended lifespan.

7. Troubleshooting

If you encounter issues with your WUPRO Cinema G1 Smart Projector, please refer to the following common solutions:

- **No Power:** Ensure the power adapter is securely connected to both the projector and a functional electrical outlet. Try a different outlet if necessary.
- **No Image:** Verify all cable connections (HDMI, USB). Ensure the correct input source is selected in the projector's menu. Confirm that the lens cap is removed.
- **Blurred Image:** The projector features auto-focus. If the image remains blurry, try restarting the projector or checking for any obstructions in front of the lens.
- **Distorted Image:** The projector includes auto-keystone correction. If the image is still distorted, ensure the projector is placed on a stable, level surface and is not at an extreme angle to the projection surface.
- **No Sound:** Check the volume level on the projector and any connected audio devices. Ensure the correct audio output is selected in the settings. If using Bluetooth, confirm the device is properly paired.

- **Remote Control Not Working:** Check the batteries in the remote control and ensure there are no obstructions between the remote and the projector's IR receiver.

For further assistance, please contact WUPRO customer support.

8. Specifications

Feature	Detail
Brand	WUPRO
Model	G1
Light Source	LED
Brightness	320 ISO Lumens
Native Resolution	1920 x 1080 (1080P)
Contrast Ratio	1500:1 (typical 2000:1)
Projection Ratio	1.25:1
Display Size	40-120 inches
Connectivity Technology	HDMI 2.1, USB 3.0, 3.5mm Audio, Bluetooth
Special Features	Digital Keystone Correction, Auto Focus, Obstacle Avoidance, Google TV, Dolby Audio
Noise Level	<30dB
Item Weight	6.95 pounds
Package Dimensions	12.36 x 10.67 x 7.36 inches

9. Warranty and Support

The WUPRO Cinema G1 series includes a **1-year replacement warranty** from the date of purchase. This warranty covers manufacturing defects and ensures a good purchasing experience.

For warranty claims, technical support, or any inquiries regarding your projector, please contact WUPRO customer service. Contact information can typically be found on the WUPRO official website or through the platform where the product was purchased.

When contacting support, please have your product model (G1) and proof of purchase readily available.

© 2025 WUPRO. All rights reserved.