Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MINISO X15 PRO

MINISO X15 PRO AI Translation Earbuds

User Manual

Introduction

This manual provides detailed instructions for the MINISO X15 PRO AI Translation Earbuds. These earbuds offer real-time two-way translation in over 135 languages, combined with music playback and call functions. Designed for travel, business, and learning, they feature Bluetooth 5.4 connectivity, Hi-Fi sound quality, and an ergonomic ear-hook design for comfortable extended wear.
Please read this manual thoroughly before using your earbuds to ensure proper operation and to maximize your experience.

What's in the Box

- 1* MINISO X15 PRO AI Translation Earbuds
- 1* Charging Cable
- 1* User Manual
- 1* Lanyard



Image: The MINISO X15 PRO package contents, showing the earbuds, charging case, USB charging cable, and user manual.

Setup

Charging the Earbuds

Before first use, fully charge the earbuds and the charging case. The earbuds provide up to 6 hours of use, and the 300mAh charging case extends playtime to 20 hours.

- Place the earbuds into the charging case.
- Connect the charging cable to the charging case and a power source.
- The indicator lights on the case will show charging status.

Pairing with Your Mobile Device

The MINISO X15 PRO earbuds connect effortlessly with iOS and Android devices via Bluetooth 5.4.

1. **Download the App:** Scan the QR code provided in the manual or visit classicearjoy.com/app-download-h5 to download the 'Earjoy' application.
2. **Login:** Open the Earjoy app and log in or create an account.
3. **Connect Earbuds:** Take the earbuds out of the charging case. They will automatically enter pairing mode.
4. **Bluetooth Connection:** On your mobile device, go to Bluetooth settings and select 'MINISO X15 PRO' to connect.
5. **App Connection:** Enter the Earjoy app and select the model name to establish the connection within the app for translation functions.



Image: Visual guide illustrating the four steps to set up the MINISO X15 PRO earbuds, including app download via QR code, app login, Bluetooth pairing, and in-app connection.

Operating Instructions

Basic Controls

The earbuds feature touch controls for various functions:

Action	Function
Click (either earbud)	Play/Pause, Answer Call
Double Click (right earbud)	Volume Up
Double Click (left earbud)	Volume Down
Three Strikes (right earbud)	Next Track
Three Strikes (left earbud)	Previous Track
Long Press (either earbud)	Reject Call, Activate Voice Assistant



Image: A visual representation of the touch controls for the MINISO X15 PRO earbuds, detailing actions like click, double click, three strikes, and long press for media and call management.

Translation Modes

The Earjoy app offers several translation modes to suit different communication scenarios:

- **AI Dialogue Mode:** For natural, continuous conversations.
- **Free Talk Mode:** Allows for spontaneous conversations with low latency.
- **Translation Machine Mode:** Utilizes the phone as a primary interface for translation.
- **Headphones + Phone Mode:** Combines earbud audio with phone display for translation.



Image: An overview of the various translation modes available through the Earjoy app, demonstrating how users can interact with the AI translation features.

Supported Languages

The MINISO X15 PRO supports real-time two-way translation for over 135 languages and accents. This includes, but is not limited to, English, Chinese, French, German, Italian, Japanese, Korean, Malay, Russian, Spanish, and Thai.



Image: A visual representation highlighting the extensive language support of the MINISO X15 PRO earbuds, featuring flags of several countries.

Maintenance

To ensure the longevity and optimal performance of your MINISO X15 PRO earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Avoid using abrasive materials or harsh chemicals.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool, dry place away from extreme temperatures.
- **Water Resistance:** The earbuds are water resistant. However, they are not waterproof. Avoid submerging them in water or exposing them to heavy rain. Dry them thoroughly if they get wet.

- **Charging Port:** Keep the charging port free of debris.

Troubleshooting

If you encounter issues with your MINISO X15 PRO earbuds, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Earbuds not connecting or only one earbud connects.	Ensure both earbuds are fully charged. Reset the earbuds by placing them back in the case, closing it, and then reopening. Delete the device from your phone's Bluetooth list and re-pair.
Translation is delayed or inaccurate.	Check your internet connection, as the translation function relies on online services. Ensure the Earjoy app is updated to the latest version. Speak clearly and at a moderate pace. Reduce background noise.
Poor sound quality or no audio.	Ensure earbuds are properly seated in your ears. Check the volume level on both your phone and the earbuds. Clean any debris from the earbud speakers. Reconnect Bluetooth.
Earbuds do not stay in place.	The X15 PRO features an ear-hook style design. Ensure they are correctly positioned over your ears for a secure fit. Adjust the ear-hook if possible.
Charging case not charging.	Verify the charging cable is securely connected to both the case and the power source. Try a different charging cable or power adapter.

Specifications

Feature	Detail
Model Name	X15 PRO
Brand	MINISO
Connectivity Technology	Wireless (Bluetooth 5.4)
Bluetooth Range	10 Meters
Ear Placement	Open Ear
Form Factor	True Wireless
Control Type	Touch Control
Audio Driver Size	14.2 Millimeters
Battery Life (Earbuds)	Up to 6 Hours
Battery Life (with Charging Case)	Up to 20 Hours

Feature	Detail
Charging Time	Approximately 6 Hours (for full system charge)
Water Resistance Level	Water Resistant
Material	Plastic
Item Weight	5 ounces
Compatible Devices	Smartphones, Tablets, Laptops

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or contact MINISO customer service directly. Keep your proof of purchase for any warranty claims.
You can also visit the official MINISO store on Amazon for more product information and support:MINISO Store

© 2025 MINISO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F7R9K258

More documents and user manuals: **https://manuals.plus/**