Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MERACH MR-S29B2-US

MERACH Magnetic Exercise Bike User Manual

Model: MR-S29B2-US

Introduction

This manual provides essential information for the safe and effective use of your MERACH Magnetic Exercise Bike, Model MR-S29B2-US. Please read this manual thoroughly before assembly and operation to ensure proper usage and to maximize your fitness experience. This exercise bike is designed for indoor cycling, featuring a self-powered magnetic resistance system, a heavy flywheel, and connectivity to the MERACH App for real-time fitness tracking.

Product Overview



The MERACH Magnetic Exercise Bike, Model MR-S29B2-US, is a robust indoor cycling solution designed for home fitness. It features a sleek black design with orange accents, a comfortable seat, and adjustable handlebars.



This exercise bike is self-powered, meaning it generates its own electricity as you pedal. This eliminates the need for an electrical outlet, offering flexibility in placement and an eco-friendly workout experience.



The bike features automatic magnetic resistance adjustment, which can sync with expert courses on the MERACH App. Manual resistance control is also available for personalized workouts.



Built with a reinforced steel frame, the bike supports a maximum user weight of 350 lbs. It incorporates a 40 lbs heavy flywheel for smooth and consistent resistance, suitable for various fitness levels.

Every Detail Matters

Dual Water
Bottle Holder



4-Way
Adjustable Bike Seat



Shock-absorbing
Cushion



4-Way Adjustable
Handle Bar



The bike offers 4-way adjustable handlebars and a 4-way adjustable seat to accommodate users from 4'8" to 6'4". It also includes a dual water bottle holder and a shock-absorbing cushion for enhanced comfort.



Connect the bike to the MERACH App or FantomFite gaming app via Bluetooth to track real-time workout statistics such as resistance level, distance, time, calories, and BPM. Data can be synced with Google Fit and Apple Health.



The MERACH S29B2 offers distinct advantages over regular exercise bikes, including no electrical outlet requirement, enhanced safety due to no cable tangling, zero power consumption (kinetic energy to electrical), and automatic resistance adjustment.

Setup

Unpacking and Assembly

Carefully unpack all components from the packaging. It is recommended to assemble the exercise bike in the location where it will be used. Detailed assembly instructions and videos are provided by MERACH to guide you through the setup process. Please refer to the separate assembly guide included with your product or available on the MERACH official website.

Placement

Place the exercise bike on a flat, stable surface. Ensure there is sufficient clear space around the bike for safe operation and movement. As the bike is self-powered, no electrical outlet is required for its operation, offering flexibility in placement.

Operating Instructions

Adjusting the Bike

- **Seat Adjustment:** The seat can be adjusted 4 ways (up/down, forward/backward). Loosen the adjustment knob, slide the seat to the desired position, and tighten the knob securely. Ensure the seat height allows for a slight bend in your knee at the bottom of the pedal stroke.
- **Handlebar Adjustment:** The handlebars can also be adjusted 4 ways (up/down, forward/backward). Loosen the adjustment knob, position the handlebars for comfortable reach and posture, and tighten the knob firmly.

Using the Resistance System

The MERACH Magnetic Exercise Bike features an auto magnetic resistance system. This system allows for two modes of operation:

- **Automatic Resistance:** When connected to the MERACH App and following a guided workout or course, the bike's resistance will automatically adjust to match the program's intensity. This provides a seamless and immersive training experience.
- **Manual Resistance:** For independent workouts, you can manually adjust the resistance level using the control knob on the bike. Turn the knob clockwise to increase resistance and counter-clockwise to decrease it. The bike offers 16 levels of resistance.

Connecting to the MERACH App

To enhance your workout experience, download the MERACH App (available on iOS and Android) or the FantomFite gaming app. Follow these steps to connect:

1. Ensure Bluetooth is enabled on your smartphone or tablet.
2. Open the MERACH App and follow the on-screen instructions to pair with your exercise bike.
3. Once connected, the app will display real-time workout data, including resistance level, distance, time, calories burned, and heart rate (if using a compatible heart rate monitor).
4. Your workout data can be synced with Google Fit and Apple Health for a comprehensive fitness overview.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your MERACH Magnetic Exercise Bike.

- **Cleaning:** Wipe down the bike after each use with a damp cloth to remove sweat and dust. Avoid using abrasive cleaners or solvents.
- **Inspecting Connections:** Periodically check all bolts, nuts, and moving parts to ensure they are securely fastened. Tighten any loose components.
- **Flywheel and Belt:** Keep the flywheel and belt area clean and free of debris. The magnetic resistance system is generally maintenance-free.
- **Storage:** Store the bike in a dry, cool place away from direct sunlight and extreme temperatures.

Troubleshooting

If you encounter any issues with your MERACH Magnetic Exercise Bike, refer to the following common troubleshooting tips:

- **No Resistance or Inconsistent Resistance:**

- Ensure the resistance knob is properly engaged and turning.
- If using the app, verify the Bluetooth connection is stable and the app is correctly communicating with the bike.

- **Squeaking or Unusual Noises:**
  - Check all assembly bolts and nuts for tightness. Loose connections can cause noise.
  - Inspect pedals and crank arms for any looseness.
- **App Connectivity Issues:**
  - Ensure Bluetooth is on and no other devices are interfering.
  - Restart the MERACH App and/or your smart device.
  - Ensure the bike is generating power by pedaling.

For issues not covered here, please contact MERACH customer support.

Specifications

Feature	Detail
Brand	MERACH
Model Name	MR-S29B2-US
Color	S29 Eco - Self Powered & Electromagetic
Power Source	Pedal-Powered Electricity (Self-Generating)
Resistance Mechanism	Auto Magnetic Resistance
Number of Resistance Levels	16
Maximum Weight Recommendation	350 Pounds
Product Dimensions (LxWxH)	40.16"D x 8.26"W x 34.05"H
Material	Alloy Steel
Recommended Uses	Build Muscle Strength, Indoor & Outdoor, Weight Loss

Warranty and Customer Support

MERACH is committed to providing excellent customer service and support for your exercise bike.

- **Warranty:** Your MERACH Magnetic Exercise Bike comes with a 12-month warranty. Please retain your proof of purchase for warranty claims.
- **Technical Support:** MERACH offers lifetime technical support for products purchased on Amazon.
- **Contact Information:** For any questions, concerns, or technical assistance, please contact the MERACH support team through the Amazon platform or visit the official MERACH website for contact details.

© 2025 MERACH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F7RGLXWN

More documents and user manuals: **https://manuals.plus/**