**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Garvee 13x13FT Pop Up Gazebo

# Garvee 13x13FT Pop Up Gazebo Instruction Manual

Model: 13x13FT Pop Up Gazebo

## Introduction

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Garvee 13x13FT Pop Up Gazebo. Please read this manual thoroughly before use to ensure safe and correct operation.

## Safety Information

**Important Safety Warnings:**

- Always assemble and secure the gazebo to a stable foundation.
- Keep away from high winds, heavy rain, snow, and other severe weather conditions. Disassemble and store the gazebo during such conditions to prevent damage or injury.
- Do not exceed the weight limit of the gazebo.
- Always follow the assembly instructions carefully.
- Ensure all parts are securely fastened before and during use.
- Keep children and pets away from the assembly area.
- Do not use open flames or heating appliances inside or near the gazebo.

## Package Contents

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, contact customer support.

- Gazebo Frame (Alloy Steel)
- Canopy Cover (Oxford Fabric with Silver Plated PU lining)
- Mosquito Net Walls (4 pieces with zippers)
- Ground Stakes
- Ropes (for securing)
- Assembly Tools (e.g., Allen wrench if needed)

## Setup Instructions

Assembly typically requires 1-2 people. Choose a flat, stable surface for setup.

1. **Step 1: Unfold the Frame**

   Place the folded gazebo frame in the desired location. With a partner, gently pull the outer legs of the frame outwards until it begins to expand. Do not force the frame.

   
   

   *Image: The compact, folded gazebo frame before expansion.*

2. **Step 2: Attach the Canopy Cover**

   Carefully place the canopy cover over the partially expanded frame. Ensure the corners of the canopy align with the frame's corners. Secure the canopy to the frame using the attached fasteners (e.g., Velcro straps, clips).



*Image: The gazebo with the canopy cover installed.*

3. **Step 3: Fully Extend the Frame and Adjust Height**

   Continue to expand the frame until it is fully open. Locate the height adjustment mechanisms on each leg. Press the release buttons and extend the legs to the desired height. Ensure all legs are locked into place at the same height for stability.




*Image: A hand demonstrating how to adjust the gazebo's height.*

4. **Step 4: Secure the Gazebo**

   Use the provided ground stakes and ropes to firmly anchor the gazebo to the ground. This is crucial for stability, especially in windy conditions. Attach ropes to the canopy corners and stake them into the ground at an angle.




*Image: Close-up of a gazebo leg secured with a ground stake.*

5. **Step 5: Install Mosquito Net Walls (Optional)**

   If desired, attach the four zippered mosquito net walls to the gazebo frame using the integrated fasteners. Zip them together to create an enclosed space.



*Image: The gazebo with mosquito nets installed.*

## Operating Instructions

- **Height Adjustment:** To adjust the height, press the release buttons on each leg and slide the inner leg to the desired position. Ensure all four legs are locked at the same height for stability.
- **Mosquito Netting:** The four zippered mosquito net walls can be opened or closed as needed to provide

protection from insects while maintaining airflow.

- **Ventilation:** The gazebo features ventilated double tops to reduce wind resistance and improve air circulation.

## Maintenance

- **Cleaning:** Clean the canopy fabric with mild soap and water. Do not use harsh chemicals or abrasive cleaners. Rinse thoroughly and allow to air dry completely before storage.
- **Frame Care:** Inspect the alloy steel frame periodically for any signs of rust or damage. Clean any dirt or debris from the frame.
- **Storage:** When not in use or during severe weather, disassemble the gazebo and store it in a dry, protected area to prolong its lifespan. Ensure the canopy is completely dry before folding to prevent mildew.
- **Fasteners:** Regularly check all fasteners, stakes, and ropes to ensure they are secure and in good condition. Replace any worn or damaged components.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Gazebo is unstable or wobbly. | Not properly secured; legs not locked at equal height; uneven ground. | Ensure all ground stakes and ropes are firmly anchored. Verify all legs are extended and locked at the same height. Move to a flatter surface if necessary. |
| Canopy collects water. | Improper tension; heavy rainfall. | Ensure the canopy is taut and evenly stretched over the frame. Disassemble the gazebo during heavy rain to prevent damage. |
| Frame difficult to open/close. | Mechanism stuck; dirt in joints. | Apply a silicone-based lubricant to moving joints. Ensure no debris is obstructing the mechanism. Do not force the frame. |
| Mosquito nets do not close properly. | Zipper misalignment; fabric caught. | Check for any fabric caught in the zipper. Ensure the gazebo is fully extended and square, which can affect net alignment. |

## Specifications

| | |
|---|---|
| **Brand** | Garvee |
| **Model** | 13x13FT Pop Up Gazebo |
| **Material** | Alloy Steel (Frame), Oxford Fabric (Canopy) |
| **Assembled Dimensions (L x W x H)** | 156.7"L x 156.7"W x 121"H |

| | |
|---|---|
| **Shaded Area** | 169 square feet |
| **Water Resistance Level** | Waterproof |
| **UV Protection** | UPF 50+ UV Protection |
| **Assembly Required** | Yes |
| **Color** | Grey |
| **UPC** | 199414977432 |
| **ASIN** | B0F8QX6K85 |




*Image: Detailed dimensions of the gazebo.*

## Warranty Information

Garvee products are designed for durability and performance. For specific warranty details regarding your 13x13FT Pop Up Gazebo, please refer to the warranty card included in your packaging or contact Garvee customer support.

Keep your purchase receipt as proof of purchase for any warranty claims.

## Customer Support

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Garvee customer support through the retailer's platform or visit the official Garvee website for contact information.
**Online Support:** Visit the Garvee Store on Amazon

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

**Open the live page**

**https://manuals.plus/asin/B0F8QX6K85**

More documents and user manuals: **https://manuals.plus/**