Velivi KMJG154D

Velivi 24-inch Dual-Zone Wine Cooler Refrigerator Instruction Manual

Model: KMJG154D

1. Introduction

This manual provides essential information for the safe and efficient operation of your Velivi 24-inch Dual-Zone Wine Cooler Refrigerator, Model KMJG154D. Please read these instructions thoroughly before installation and use, and retain them for future reference.

2. Safety Information

To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.
- Keep ventilation openings, in the appliance enclosure or in the built-in structure, clear of obstruction.
- Do not damage the refrigerant circuit.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Before cleaning or performing maintenance, always unplug the appliance from the power outlet.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.

3. Product Overview

The Velivi KMJG154D is a 24-inch dual-zone wine cooler designed for optimal wine storage. It features a large capacity, precise temperature control, and a quiet operation.

Key Features:

- **Dual-Zone Cooling:** Separate temperature zones for white and sparkling wines (40°F-55°F) and red wines (55°F-65°F).
- **Large Capacity:** Accommodates up to 154 standard wine bottles on 12 wooden shelves.
- **Quiet Operation:** Advanced compressor cooling system operates below 40dB with minimal vibration.
- **UV-Protected Glass Door:** Double-reinforced tempered glass blocks harmful UV rays and provides thermal insulation.
- **Digital Touch Control:** Intuitive touchscreen panel for temperature adjustment, light control, and unit settings.
- **Temperature Memory Function:** Automatically restores previous temperature settings after a power outage.
- **Safety Lock:** Integrated lock mechanism to secure your wine collection.
- **Freestanding or Built-in Installation:** Versatile design for various placement options.
- **LED Lighting:** Soft blue interior LED lighting for visibility without affecting wine quality.
- **Frost Free Defrost:** Automatic defrost system for convenience.

Components:

- Wine cooler body
- 12 Wooden shelves (including one slanted for display)
- Stainless steel door handle
- Keys for safety lock
- Adjustable feet

Image 1: Front view of the Velivi 24-inch Dual-Zone Wine Cooler Refrigerator, showcasing its sleek black design and glass door with interior lighting.



Image 2: Close-up views of key components including the safety lock, exhaust vent, stainless steel handle, and adjustable feet.

4. Setup and Installation

Unpacking:

- Remove all packaging materials. Keep the original packaging for future transport if needed.
- Inspect the appliance for any damage. Report any damage to your retailer immediately.
- Clean the interior and exterior of the appliance with a soft cloth and mild detergent before use.

Placement:

- This wine cooler can be installed as a freestanding unit or built into cabinetry.
- Ensure adequate ventilation around the unit. For built-in installation, refer to the specific dimensions and ensure proper airflow through the front exhaust vent.
- Place the appliance on a flat, stable surface capable of supporting its weight when fully loaded.
- Avoid placing the unit in direct sunlight or near heat sources (e.g., oven, radiator).
- Allow at least 2-4 inches of space at the back and sides for proper air circulation if freestanding.
- **Dimensions:** 23.54" W x 27.17" D x 65.74" H.



Image 3: Diagram illustrating the dimensions of the wine cooler (23.54" W x 27.17" D x 65.74" H) and bottle capacity.

Leveling:

- Adjust the leveling feet at the bottom of the unit to ensure it is perfectly level. This is crucial for proper door sealing and efficient operation.

Electrical Connection:

- Ensure the voltage and frequency of your power supply match the ratings on the appliance's label (115V/60Hz).
- Plug the appliance into a dedicated, grounded wall outlet. Do not use extension cords or adapter plugs.
- Allow the unit to stand upright for at least 24 hours before plugging it in to allow compressor fluids to settle.

5. Operating Instructions

Your wine cooler features a multi-functional smart touch control panel for easy operation.

Image 4: Detailed view of the digital touch control panel with icons for light, Celsius/Fahrenheit, temperature settings, and power.

Control Panel Functions:

- **Power Switch ( ):** Press to turn the unit ON or OFF.
- **Light Control ( ):** Press to turn the interior LED light ON or OFF.
- **Celsius/Fahrenheit Degree (°C/°F):** Press to switch between Celsius and Fahrenheit temperature display.
- **Temperature Setting (⚙):** Press to select the zone for temperature adjustment (upper or lower).
- **Temperature Up (↑):** Press to increase the set temperature.
- **Temperature Down (↓):** Press to decrease the set temperature.

Setting Temperatures for Dual Zones:

The wine cooler has two independent temperature zones:

- **Upper Zone:** Recommended for white and sparkling wines (40°F-55°F / 5°C-13°C).
- **Lower Zone:** Recommended for red wines (55°F-65°F / 13°C-18°C).

1. Press the **Temperature Setting (⚙)** button to select either the upper or lower zone. The selected zone's display will flash.

2. Use the **Temperature Up (↑)** or **Temperature Down (↓)** buttons to adjust the desired temperature for that zone.
3. Once the desired temperature is set, the display will stop flashing after a few seconds, indicating the setting is saved.
4. Repeat for the other zone if necessary.

The unit will automatically maintain the set temperatures. The temperature memory function will restore your last settings in case of a power interruption.

Image 5: Visual guide for optimal temperature ranges for different wine types in the upper and lower zones.

6. Maintenance

Cleaning:

- **Interior:** Unplug the unit. Wash the interior surfaces with a solution of warm water and baking soda (2 tablespoons of baking soda to 1 quart of water). Rinse and dry thoroughly.
- **Exterior:** Clean the exterior with a mild detergent and warm water. Wipe dry with a soft cloth.
- **Door Gasket:** Clean the door gasket regularly to ensure a proper seal.
- **Shelves:** The wooden shelves can be removed and cleaned with a damp cloth. Ensure they are completely dry before placing them back in the unit.

- Do not use abrasive cleaners or sharp objects, as they can damage the surfaces.

Defrosting:

This appliance features an automatic "Frost Free" defrost system. Frost will melt and drain into a drip tray at the back of the unit, where it evaporates. No manual defrosting is required.

Power Failure:

In case of a power failure, the wine cooler will retain its temperature settings due to the memory function. However, prolonged power outages may affect internal temperatures. Minimize door openings during such events.

Vacation Time:

- **Short Vacations:** Leave the wine cooler operating.
- **Long Vacations:** If the appliance will not be used for several months, remove all items, unplug the power cord, clean the interior, and leave the door slightly ajar to prevent odor and mold formation.

7. Troubleshooting

Review this section before calling for service. It may save you time and expense. This section contains common issues that are not a result of defective materials or workmanship.

Problem	Possible Cause	Solution
Appliance does not operate.	Not plugged in; circuit breaker tripped; power switch off.	Ensure plug is secure; check circuit breaker; press power switch.
Temperature is not cold enough.	Door not closed properly; frequent door openings; warm items added; poor ventilation; unit in direct sunlight.	Check door seal; minimize door openings; allow items to cool before storing; ensure proper clearance; relocate unit.
Vibrations.	Unit not level; weak floor.	Adjust leveling feet; ensure floor can support the unit.
Noise.	Normal compressor operation; fan noise.	This is normal. If noise is excessive, check for vibrations or obstructions. The unit operates below 40dB.
Door does not close properly.	Unit not level; door gasket dirty/damaged; shelves out of position.	Level the unit; clean/replace gasket; reposition shelves.

8. Specifications

Feature	Detail
Brand	Velivi
Model Number	KMJG154D
Capacity	13.5 Cubic Feet (approx. 154 standard bottles)

Feature	Detail
Product Dimensions (D x W x H)	27.17" x 23.54" x 65.74"
Item Weight	216 Pounds
Installation Type	Freestanding/Built-in
Voltage	115 Volts
Defrost System	Frost Free
Shelf Type	Wood
Number of Shelves	12
Noise Level	<40dB
Color	Black



Image 6: Energy Guide label for Model KMJG154D, indicating an estimated yearly energy cost of $29 and 240 kWh estimated yearly electricity use.

9. Warranty and Support

Your Velivi wine cooler comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures proper functioning under normal use.
For technical assistance, warranty claims, or any product-related inquiries, please contact Velivi customer support. Professional support is available to assist you.
Please retain your proof of purchase for warranty validation.