Manuals+
Q & A | Deep Search | Upload

Hoxida 016-1

Hoxida Rechargeable High Lumens LED Flashlight User Manual

Model: 016-1 | Brand: Hoxida

1. Introduction

Thank you for choosing the Hoxida Rechargeable High Lumens LED Flashlight. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new flashlight. Please read it thoroughly before use and retain it for future reference.

2. Key Features

- **Super Bright Long Beam:** Equipped with an optical-grade double-convex lens, providing a perfectly balanced beam with a real illumination distance of up to 1500 feet.
- **Rechargeable & Power Digital Display:** Features a USB Type-C port for fast charging (approx. 4 hours) and a USB output for emergency power bank functionality. A digital display shows remaining power.
- **Extended Runtime:** 5000mAh battery capacity offers up to 20 hours of runtime in Low Mode.
- **5 Lighting Modes & Zoomable:** Includes High, Medium, Low, Strobe, and SOS modes. The zoomable function allows switching between spotlight (zoom out) and floodlight (zoom in).
- **Durable & Waterproof:** Constructed with a sturdy aluminum body, offering IPX6 water resistance for all-weather use and impact resistance.

3. What's Included

Your package should contain the following items:

- 2x Rechargeable LED Flashlights
- 2x USB Type-C Cables
- 1x User Manual
- 1x Storage Box

4. Setup

4.1 Initial Charging

Before first use, fully charge the flashlight. Connect the provided USB Type-C cable to the flashlight's charging port and plug the other end into a compatible USB power adapter (not included). The digital power display will indicate the charging progress. A full charge typically takes approximately 4 hours.

Figure 1: USB Type-C Fast Charging and Digital Power Display

4.2 Battery Installation (Optional)

The flashlight comes with a built-in rechargeable battery. In situations where recharging is not possible, the flashlight can also be powered by AAA batteries using the included adapter (if applicable to your model). To install AAA batteries, unscrew the tail cap, insert the AAA batteries into the adapter with correct polarity, and then insert the adapter into the flashlight. Re-attach the tail cap securely.

Your browser does not support the video tag.

Video 1: Demonstrating the rechargeable feature of the Hoxida flashlight, eliminating the need for disposable batteries.

5. Operation

5.1 Power On/Off

Press the power button once to turn the flashlight on. To cycle through the 5 lighting modes (High, Medium, Low, Strobe, SOS), press the power button repeatedly. To turn the flashlight off from any mode, press and hold the power button for 2 seconds.

Figure 2: Long Beam and 5 Lighting Modes

5.2 Zoom Function

The flashlight features a telescopic zoom function. To adjust the beam, gently push or pull the head of the flashlight. Zoom out for a focused spotlight beam, ideal for long-distance illumination. Zoom in for a wider floodlight beam, suitable for lighting up a larger area.

Figure 3: Telescopic Zoom Function

Your browser does not support the video tag.

Video 2: Demonstrating the brightness and zoom function of the Hoxida flashlight.

5.3 Power Bank Function

The flashlight can be used as an emergency power bank to charge small electronic devices. Connect your device to the USB output port on the flashlight using a compatible USB cable.

6. Maintenance

- **Cleaning:** Wipe the flashlight with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the flashlight in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, ensure the battery is partially charged (around 50%) and recharge every 3-6 months to maintain battery health.
- **Water Resistance:** The flashlight is IPX6 water resistant, meaning it can withstand strong jets of water. It is not designed for submersion. Ensure the charging port cover is securely closed to maintain water resistance.

Figure 4: IPX6 Water Resistance

7. Troubleshooting

- **Flashlight not turning on:** Ensure the battery is charged. If using AAA batteries, check polarity and replace if necessary.
- **Dim light output:** Recharge the battery. If the issue persists, the battery may need replacement.
- **Charging issues:** Check the USB cable and power adapter. Ensure the charging port is clean and free of debris.

If you encounter any issues not listed here, please contact Hoxida customer support for assistance.

8. Specifications

Feature	Specification
Brand	Hoxida

Model Number	016-1
Light Source Type	LED
Light Output Maximum	2000 Lumens
Beam Distance	Up to 1500 feet (approx. 457 meters)
Power Source	LED Powered (Rechargeable Lithium Ion)
Battery Capacity	5000mAh
Runtime (Low Mode)	Up to 20 Hours
Charging Port	USB Type-C
Water Resistance Level	IPX6
Material	Aluminum
Product Dimensions	1"D x 1"W x 1"H (approximate)
Special Features	5 Modes, One-Key Turn Off, Water Resistant, Zoomable, Lightweight & Pocket-Sized, Anti-Roll Body, Tactical Tail Switch, Power Display, USB Output (Power Bank)

9. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact Hoxida customer service directly. You can also visit the official Hoxida store on Amazon for more information: Hoxida Store.

© 2026 Hoxida. All rights reserved.