Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VOWNER GLS-007

VOWNER GLS-007 72" x 40" Double-Sided Magnetic Mobile Whiteboard Instruction Manual

Model: GLS-007

1. Product Overview

The VOWNER GLS-007 is a 72" x 40" double-sided magnetic mobile dry erase board designed for various environments including home offices, classrooms, and schools. Its reversible design and rolling stand provide flexibility and ease of use.



Image 1.1: VOWNER 72" x 40" Double-Sided Magnetic Mobile Whiteboard.

2. Package Contents

Please verify that all components are present before beginning assembly:

- Whiteboard Panel (72" x 40")
- Mobile Stand Frame
- 4 Lockable Universal Casters
- Accessory Tray
- Assembly Tools
- 6 Magnetic Tiles
- 1 Whiteboard Eraser
- Instruction Manual



Image 2.1: Overview of whiteboard dimensions and included magnetic accessories.

3. Setup and Assembly

Assembly of the VOWNER GLS-007 whiteboard is designed to be straightforward. Follow the included instructions carefully, ensuring each piece is correctly identified and all screws are securely tightened for optimal stability.

3.1. Assembly Steps

1. Unpack all components and verify against the package contents list.
2. Assemble the mobile stand frame using the provided tools and hardware. Ensure all connections are firm.
3. Attach the four universal casters to the base of the stand. Ensure they are securely fastened.
4. Mount the whiteboard panel onto the stand. Pay attention to the orientation for proper rotation.
5. Attach the accessory tray to the desired position on the stand.
6. Once assembled, test the stability of the stand and the functionality of the casters and locking mechanism.

Note: In rare cases, a threaded hole for a crossmember bolt may be misaligned. If this occurs, please contact customer

support for assistance. A small gap at the center joint of the board is a characteristic of the design and does not affect stability or functionality.

4. Operating Instructions

4.1. Writing and Erasing

The whiteboard features a smooth, three-layer baked paint surface designed for effortless writing with dry erase markers. The matte finish helps prevent glare, improving visibility from various angles. For best results, use high-quality dry erase markers and the provided eraser or a soft cloth for cleaning.



Image 4.1: Multiple users interacting with the large whiteboard surface.

4.2. Double-Sided Functionality

The board is double-sided, providing twice the writing space. To reverse the board, locate the swing-stop mechanism (typically a knob or lever) on the side of the frame. Release the lock, rotate the board 360 degrees to expose the other side, and then re-engage the lock to secure it in place.



Image 4.2: Illustration of the 360-degree reversible angle and swing-stop feature.

4.3. Mobility and Locking

The mobile stand is equipped with four 360-degree steering silent casters for smooth movement across various floor types, including cement, plank, and carpet. To move the whiteboard, ensure all casters are unlocked. Once positioned, engage the locking mechanism on each caster to prevent unintended movement and ensure stability during use.



Image 4.3: Demonstrating the release and lock function of the universal casters for easy movement and stability.

4.4. Magnetic Surface

Both sides of the whiteboard are magnetic, allowing you to attach documents, notes, or other magnetic accessories using the included magnetic tiles.



Image 4.4: Detailed view of the magnetic surface and integrated storage tray.

5. Maintenance and Care

To ensure the longevity and optimal performance of your VOWNER whiteboard, follow these maintenance guidelines:

- **Cleaning:** Use a dry erase eraser or a soft, damp cloth to clean the board after each use. For stubborn marks, a specialized whiteboard cleaner can be used. Avoid abrasive cleaners or materials that could damage the surface.
- **Stain Prevention:** The board's surface is designed to be stain-resistant. Promptly erase markings to prevent ghosting or staining, especially with darker colors.
- **Storage:** When not in use for extended periods, store the whiteboard in a dry environment.
- **Frame Care:** The metal frame is covered with a rust-proof black coating. Wipe with a dry or slightly damp cloth to keep it clean.



Image 5.1: Illustration of the stain-resistant and easy-to-write surface.

6. Troubleshooting

- **Board Wobbles After Assembly:** Ensure all bolts and screws on the stand frame and casters are fully tightened. Verify that the casters are locked when the board is stationary.
- **Difficulty Erasing Marks:** Ensure you are using dry erase markers. If marks are stubborn, use a whiteboard cleaning spray and a soft cloth. Avoid leaving markings on the board for extended periods.
- **Casters Not Rolling Smoothly:** Check for any debris or hair caught in the caster wheels. Ensure the caster locks are fully disengaged.
- **Missing or Defective Parts:** If any parts are missing or appear defective upon arrival, please contact VOWNER customer support for assistance.

7. Specifications

Model Number	GLS-007
Board Dimensions (including frame)	72 inches (W) x 40 inches (H)
Writing Area Dimensions	70 inches (W) x 38 inches (H)
Overall Product Dimensions	77.9 inches (W) x 77.9 inches (H) x 21.65 inches (D)
Item Weight	3 pounds
Material	Metal (frame), ABS (reinforced corners), Three-layer baked paint (surface)
Features	Double-sided, Magnetic, 360° Reversible, Mobile with Lockable Casters, Accessory Tray



Image 7.1: Diagram of the whiteboard's 15-layer structure for durability and writing performance.

8. Warranty and Support

Specific warranty information for the VOWNER GLS-007 whiteboard is not provided in this manual. For details regarding warranty coverage, claims, or technical support, please refer to the product packaging or contact VOWNER customer service directly through their official website or the retailer where the product was purchased.

© 2025 VOWNER. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F99M886X

More documents and user manuals: **https://manuals.plus/**