Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ycolnaefllr 3HUSHLW-01

Ycolnaefllr 6FT Halloween Inflatable Haunted Tree with Glowing Ghost & LED Pumpkin Instruction Manual

Model: 3HUSHLW-01

Introduction

Thank you for choosing the Ycolnaefllr 6FT Halloween Inflatable Haunted Tree. This product is designed to enhance your Halloween decorations with its impressive 6-foot height, integrated glowing ghost, and LED pumpkin features. This manual provides essential information for the safe and proper setup, operation, and maintenance of your inflatable decoration. Please read these instructions thoroughly before use and retain them for future reference.



Image: The 6-foot Halloween Inflatable Haunted Tree featuring a glowing ghost and LED pumpkin, set against a festive Halloween backdrop.

Package Contents

Verify that all components are present in the package before proceeding with setup.

- 1 x 6FT Halloween Inflatable Haunted Tree
- 1 x Powerful Air Blower (built-in)
- 1 x Power Adapter
- Ground Stakes
- Ropes
- 1 x Storage Bag



Image: Illustration of the package contents, including the inflatable unit, air blower, power adapter, ground stakes, and ropes.

Setup Instructions

Follow these steps for quick and easy setup of your inflatable decoration.

1. **Choose a Location:** Select a flat, clear area outdoors, away from sharp objects, heat sources, and open flames. Ensure the area is free from obstructions that could damage the inflatable or interfere with its operation.
2. **Unpack the Inflatable:** Carefully remove the inflatable and all accessories from the storage bag.
3. **Position the Inflatable:** Lay the inflatable flat on the chosen surface. Ensure the built-in blower is positioned correctly and not obstructed.
4. **Close Zipper:** Locate the bottom zipper on the inflatable and ensure it is fully closed. This is crucial for proper inflation.
5. **Connect Power:** Plug the power adapter into the inflatable's blower, then plug the adapter into a standard outdoor-rated electrical outlet. The inflatable will begin to inflate automatically.

6. **Secure the Inflatable:** Once fully inflated, use the provided ground stakes and ropes to secure the inflatable to the ground. Attach ropes to the designated loops on the inflatable and anchor them firmly into the ground to prevent tipping or movement, especially in windy conditions.



Image: The inflatable fully set up, demonstrating its 6-foot height in an outdoor setting.

Operating Instructions

Operating your Ycolnaefllr Halloween Inflatable is straightforward.

- **Inflation:** Once plugged into a power source with the bottom zipper closed, the built-in blower will automatically inflate the decoration within approximately 60 seconds.
- **Lighting:** The inflatable features internal LED lights for the ghost and pumpkin, which will illuminate automatically when the unit is powered on, creating a glowing effect.
- **Deflation:** To deflate, simply unplug the power adapter from the electrical outlet. For quicker deflation, open the bottom zipper.



Image: The inflatable displayed at night, showcasing its internal LED lighting for the ghost and pumpkin.

Maintenance and Storage

Proper care ensures the longevity of your inflatable decoration.

- **Cleaning:** To clean, wipe the surface with a damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the inflatable is completely dry before storing.
- **Repairs:** In case of small punctures or tears, use a repair kit (not included) designed for inflatable fabrics.
- **Storage:** After deflation and ensuring the inflatable is dry, fold it neatly and place it back into the provided storage bag. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Weather Resistance:** The inflatable is made of thickened polyester fabric, offering water resistance and tear resistance. However, for prolonged heavy rain or strong winds, it is recommended to deflate and store the unit to prevent damage.



Image: The inflatable demonstrating its waterproof design, suitable for outdoor use in various weather conditions.

Troubleshooting

Problem	Possible Cause	Solution
Inflatable does not inflate fully.	• Power not connected. • Bottom zipper is open. • Blower obstructed. • Puncture or tear in fabric.	• Ensure power adapter is securely plugged in. • Close the bottom zipper completely. • Check for any obstructions around the blower intake. • Inspect for damage and repair if necessary.
Lights are not working.	• Power not connected. • LEDs are damaged.	• Ensure the inflatable is powered on. • Contact customer support if LEDs are confirmed damaged.

Problem	Possible Cause	Solution
Inflatable falls over easily.	• Not properly anchored. • Strong winds.	• Ensure all ground stakes and ropes are securely fastened. • Deflate and store the inflatable during strong winds.

Specifications

- **Brand:** Ycolnaefllr
- **Model Number:** 3HUSHLW-01
- **Theme:** Halloween
- **Height:** 6 feet (approx.)
- **Material:** Thickened Polyester Fabric
- **Special Features:** Built-in Blower, LED Lights (Glowing Ghost, LED Pumpkin), Waterproof, Tear Resistant
- **Power Source:** Standard Electrical Outlet (via included adapter)
- **Item Weight:** 1.65 pounds
- **Product Dimensions (L x W x H):**22 x 14 x 24 inches (packaged)
- **UPC:** 667763808313

Safety Information

Please adhere to the following safety guidelines to prevent injury or damage to the product.

- Always follow the manufacturer's instructions for proper inflation and deflation.
- Keep the product away from heat sources and open flames.
- Ensure the product is securely anchored to prevent it from becoming a projectile in high winds.
- Do not operate the product if the electrical components are damaged or wet.
- Do not attempt to modify or repair the electrical components yourself. Contact qualified personnel for assistance.
- This product is for decorative purposes only and is not a toy. Keep out of reach of small children.
- Ensure the power cord is routed safely to prevent tripping hazards.

Warranty and Support

For any questions, concerns, or support regarding your Ycolnaefllr 6FT Halloween Inflatable Haunted Tree, please refer to your purchase documentation or contact the retailer where the product was purchased. Please retain your proof of purchase for warranty claims, if applicable.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0F9L39227

More documents and user manuals: **https://manuals.plus/**