Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy SF6084-BN

Sweetcrispy SF6084-BN Recliner Chair User Manual

Model: SF6084-BN

Introduction

Thank you for choosing the Sweetcrispy SF6084-BN Recliner Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new recliner. Please read these instructions carefully before use and retain them for future reference.
The Sweetcrispy SF6084-BN is a versatile recliner designed for comfort and functionality. It features a 360-degree swivel base, a smooth gliding mechanism, and a multi-angle recline function, making it suitable for various living spaces including living rooms, nurseries, and bedrooms.

Safety Information

- Ensure all components are securely fastened before use.
- Do not exceed the maximum weight capacity of 250 lbs (113 kg).
- Keep hands and feet clear of moving parts during recline and swivel operations.
- Avoid standing on the chair or using it as a step stool.
- Supervise children around the recliner to prevent injury.

Setup and Assembly

The Sweetcrispy SF6084-BN recliner is designed for straightforward assembly, typically taking 8-15 minutes. It ships in one box with most major components pre-assembled.

Required Tools:

- No additional tools are typically required; an Allen wrench may be included for specific fasteners.

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components are present according to the included parts list.
2. **Attach Backrest:** Align the metal brackets on the backrest with the corresponding slots on the seat base. Slide the backrest down firmly until it clicks into place. Ensure it is securely seated.
3. **Connect Power (if applicable):** If your model includes a massage or heating function, connect the power adapter to the chair and then to a wall outlet.

4. **Verify Stability:** Once assembled, gently rock and swivel the chair to ensure all connections are stable and the chair operates smoothly.



Figure 1: Product dimensions and key components. This image illustrates the overall size and structure, aiding in understanding assembly points.

Operating Instructions

Your Sweetcrispy recliner offers multiple comfort adjustments for a personalized experience.

Reclining Function:

- To recline the backrest and extend the footrest, apply gentle backward pressure to the backrest while seated. The chair will smoothly transition through its recline angles, from 95° to 160°.
- The footrest can be adjusted from 0° to 90° independently as you recline.
- To return to the upright position, lean forward and apply pressure with your legs to retract the footrest. The backrest will follow.

Swivel and Gliding Functions:

- The chair features a 360-degree swivel base, allowing you to rotate freely in any direction.
- The gliding function provides a smooth, back-and-forth motion, ideal for relaxation.



Figure 2: Illustrates the reclined position, showing a user enjoying the chair's full recline and footrest extension.



Figure 3: Visual representation of the 360-degree swivel and smooth gliding capabilities of the chair.

Maintenance

Proper care will extend the life and appearance of your Sweetcrispy recliner.

Cleaning the PU Leather:

- The PU leather upholstery is designed for easy cleaning. For general cleaning, wipe the surface with a soft, damp cloth.
- For spills or stains, use a mild soap solution on a clean cloth and gently blot the affected area. Avoid harsh chemicals or abrasive cleaners.
- Always test any cleaning solution on an inconspicuous area first.
- Wipe dry immediately after cleaning to prevent water spots.

Frame and Mechanism Care:

- Periodically check all bolts and screws to ensure they remain tight. Tighten if necessary.
- Avoid exposing the chair to direct sunlight or extreme temperatures, which can damage the upholstery and frame.



Figure 4: Demonstrates the spot cleaning process for the PU leather upholstery.

Troubleshooting

If you encounter any issues with your recliner, refer to the following common solutions:

Problem	Possible Cause	Solution
Chair does not recline smoothly.	Mechanism obstruction or loose connections.	Check for any objects obstructing the reclining mechanism. Ensure all assembly bolts are tightened.
Swivel or gliding motion is stiff.	Debris in the base mechanism or lack of lubrication.	Inspect the swivel base for debris. If accessible, apply a silicone-based lubricant to moving parts (avoid oil-based lubricants on plastic).
Chair feels unstable or wobbly.	Loose assembly connections.	Re-check all assembly points, especially where the backrest connects to the seat base, and tighten any loose fasteners.

Specifications

Feature	Detail
Brand	Sweetcrispy
Model Name	Recliner Chair (SF6084-BN)
Color	Brown
Product Dimensions (Overall)	35.44"D x 28"W x 40.16"H (Upright)
Maximum Weight Recommendation	250 Pounds
Back Style	High, Continuous
Special Feature	Ergonomic, 360° Swivel, Gliding, Reclining
Upholstery Material	PU Leather
Fill Material	Foam
Frame Material	Metal (Powder Coated Finish)
Reclining Position Count	5 (Backrest tilt 95°-160°, Footrest 0°-90°)
Assembly Required	Yes
Item Weight	77.8 pounds
UPC	718025780226

Warranty and Support

For specific warranty details and customer support, please refer to the documentation included with your purchase or contact Sweetcrispy customer service directly. Information regarding protection plans may also be available from your retailer.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FB3QH1H3

More documents and user manuals: **https://manuals.plus/**