Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Almost Heaven Saunas SAC80500

Almost Heaven Bluetooth Sauna Speaker Instruction Manual

Model: SAC80500

Brand: Almost Heaven Saunas

1. Introduction

The Almost Heaven Bluetooth Sauna Speaker is engineered to provide high-quality audio in challenging sauna environments. Its design ensures resistance to temperatures up to 149°F and water, making it suitable for both wet and dry saunas, indoors or outdoors. This manual provides essential information for the safe and optimal use of your speaker.



Image: The Almost Heaven Bluetooth Sauna Speaker in red, shown with its product packaging.

2. Safety Information

- **Temperature Limits:** The speaker is resistant to temperatures up to 149°F (65°C). To ensure a long-lasting lifespan and prevent damage, place the speaker on the floor or in a low position within the sauna, as temperatures are typically lower there. Avoid exposing the speaker to temperatures exceeding 149°F.
- **Water Resistance:** The speaker is rated IPX6 for water resistance, meaning it can withstand strong jets of water. However, it is not designed for submersion. Avoid submerging the speaker in water.
- **Charging:** Use only the provided USB-C charging cable and a compatible power adapter (DC 5V / 0.5A). Do not attempt to charge the speaker in a wet environment.
- **Cleaning:** Do not use abrasive cleaners or solvents. Refer to the Maintenance section for proper cleaning instructions.
- **Disassembly:** Do not attempt to disassemble or repair the speaker. This will void the warranty and may cause damage or injury.

3. Package Contents

Please ensure all items are present upon unboxing:

- Almost Heaven Bluetooth Sauna Speaker
- USB-C Charging Cable
- User Manual (this document)

4. Product Features

- **Bluetooth Compatible:** Seamlessly connect your devices for audio playback.
- **Heat & Water Resistant:** Withstands temperatures up to 149°F and rated IPX6 for water resistance, ideal for wet and dry saunas.
- **High-Quality Sound:** Designed for clear audio production.
- **Stereo Pairing:** Connect two speakers simultaneously for an immersive stereo experience.
- **Long Battery Life:** Up to 8 hours of playtime on a single charge.
- **USB-C Charging:** Convenient and fast charging.



Image: Key features of the Almost Heaven Bluetooth Sauna Speaker, highlighting its sauna-ready design.

5. Specifications

Attribute	Detail
Model Number	SAC80500
Dimensions	4 x 4 x 8 inches
Weight	15.5 ounces
Speaker Impedance	4 ohms
Speaker Power	5W

Frequency Range	100 Hz – 18 kHz
Battery Capacity	1800 mAh
Playtime	Approx. 8 hours
Charging Input	USB-C (DC 5V / 0.5A)
Heat Resistance	Up to 149°F (65°C)
Water Resistance	IPX6



Image: Detailed technical specifications of the Harvia Sauna & Spa speaker.

6. Setup

6.1 Initial Charging

Before first use, fully charge your speaker using the provided USB-C cable. Connect the USB-C end to the speaker's charging port and the USB-A end to a compatible power source (e.g., computer USB port, wall adapter). The charging indicator light will show the charging status.

6.2 Powering On/Off

- **To Power On:** Press and hold the power button () for 2-3 seconds until you hear an audible cue and the LED indicator lights up.
- **To Power Off:** Press and hold the power button () for 2-3 seconds until you hear an audible cue and the LED indicator turns off.

6.3 Bluetooth Pairing

1. Ensure the speaker is powered on and in pairing mode (the LED indicator will typically flash blue).
2. On your mobile device (smartphone, tablet, etc.), go to the Bluetooth settings.
3. Search for available devices and select "Almost Heaven Speaker" (or similar name) from the list.
4. Once connected, you will hear a confirmation tone, and the LED indicator will turn solid blue.

7. Operating Instructions

7.1 Basic Controls

- **Play/Pause:** Press the Play/Pause button (▷‖) once.
- **Volume Up:** Press the '+' button. Hold to continuously increase volume.
- **Volume Down:** Press the '-' button. Hold to continuously decrease volume.
- **Next Track:** Press and hold the '+' button for 2 seconds.
- **Previous Track:** Press and hold the '-' button for 2 seconds.

7.2 Stereo Pairing (TWS Function)

For an enhanced audio experience, you can pair two Almost Heaven Bluetooth Sauna Speakers together:

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be your primary speaker), double-press the Bluetooth button (often indicated by a Bluetooth symbol). It will enter TWS pairing mode.
3. The primary speaker will automatically search for the secondary speaker. Once connected, you will hear a confirmation tone.
4. Now, connect your mobile device to the primary speaker via Bluetooth as described in section 6.3. Audio will play through both speakers in stereo.



Image: The stereo pairing feature allows two speakers to connect for an immersive sauna experience.

8. Charging

The speaker is equipped with an 1800 mAh battery, providing approximately 8 hours of playtime. When the battery is low, the LED indicator may flash, and you might hear an audible alert. Connect the speaker to a DC 5V / 0.5A power source using the USB-C cable to recharge. A full charge typically takes a few hours.

9. Maintenance and Care

- **Placement:** Always place the speaker on the floor or in a low position within the sauna to avoid exposure to

temperatures above 149°F, which can shorten its lifespan.

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals, solvents, or abrasive cleaners, as these can damage the finish or internal components.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.



Image: Care instructions for the speaker, emphasizing proper placement in the sauna.

10. Troubleshooting

- **Speaker will not power on:** Ensure the battery is charged. Connect to a power source and try again.
- **Cannot pair with Bluetooth device:** Make sure the speaker is in pairing mode (flashing blue LED) and not already connected to another device. Turn off Bluetooth on other nearby devices. Ensure your device's Bluetooth

is enabled.

- **No sound:** Check the volume levels on both the speaker and your connected device. Ensure the speaker is successfully paired.
- **Stereo pairing not working:** Ensure both speakers are fully charged and not connected to any other Bluetooth device before attempting TWS pairing. Follow the steps in section 7.2 carefully.

11. Warranty and Support

Almost Heaven Saunas, with nearly 50 years of experience in producing saunas and sauna accessories, stands by the quality of its products. For warranty information, technical support, or any inquiries regarding your Bluetooth Sauna Speaker, please refer to the official Almost Heaven Saunas website or contact their customer service directly. Contact details are typically found on the product packaging or the official brand website.



Image: Information about Almost Heaven Saunas' heritage and commitment to quality.

© 2025 Almost Heaven Saunas. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FB6HQ964

More documents and user manuals: **https://manuals.plus/**