Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VEVOR B0FBRSS8MC

VEVOR Appliance Slider User Manual

Model: Large (13"D x 16"W)

Introduction Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for choosing the VEVOR Appliance Slider. This manual provides essential information for the proper setup, operation, and maintenance of your new appliance slider. This product is designed to facilitate the easy movement of various kitchen appliances across countertops, reducing effort and protecting surfaces.

2. Setup

2.1 Unboxing and Placement

The VEVOR Appliance Slider requires no assembly or installation. Simply remove it from its packaging. Place the slider on a clean, flat, and stable countertop surface. Ensure the surface is dry before placing the slider.

2.2 Appliance Positioning

Carefully place your desired kitchen appliance onto the center of the VEVOR Appliance Slider. Ensure the appliance is stable and balanced on the slider before attempting to move it. The slider is designed to support appliances up to 40 lbs.



Image 2.1: The VEVOR Appliance Slider in use, with a coffee maker placed on top, ready to be moved effortlessly across the kitchen countertop.

3. Operation

3.1 Moving Appliances

To move an appliance, gently pull or push the VEVOR Appliance Slider using the hollow handle. The silent rubber wheels allow for smooth, quiet movement without scratching your countertop surfaces, including marble, quartz, tiles,

and wood. This design eliminates the need for heavy lifting.



Image 3.1: This image illustrates the ease of use of the VEVOR Appliance Slider, with a 'Before' and 'After' view of a coffee machine being moved, highlighting the effortless sliding action.

3.2 Countertop Protection

The directional rubber wheels are specifically designed to protect your countertops from scratches and wear. The 0.7-inch thick natural wood material is durable and resistant to warping or cracking, ensuring long-term use.



Image 3.2: A coffee maker rests on the VEVOR Appliance Slider, with an inset showing the silent rubber wheels designed to prevent scratches on various countertop surfaces like marble, quartz, tiles, and wood.

3.3 Video Demonstration

▶ **Watch video online**

VEVOR Appliance Slider Rolling Tray 10x13

Video 3.1: An official video demonstrating the VEVOR Appliance Slider in action, showing how it facilitates easy movement of kitchen appliances like blenders across countertops.

4. Maintenance

4.1 Cleaning

The VEVOR Appliance Slider features a smooth surface that is easy to clean. Simply wipe it with a damp cloth and mild detergent. Avoid abrasive cleaners or harsh chemicals that could damage the material. Ensure the slider is completely dry before placing an appliance back on it.



Image 4.1: The VEVOR Appliance Slider is shown being washed under running water, emphasizing its smooth, easy-to-wipe surface for

simple maintenance.

5. Troubleshooting

5.1 Movement Issues

- **Difficulty Sliding:** Ensure the countertop surface is clean and free of debris. Check that the appliance is centered on the slider and not exceeding the 40 lbs weight capacity.
- **Uneven Movement:** Verify that the appliance is placed evenly on the slider. Inspect the rubber wheels for any obstructions or damage.

6. Specifications

The following table outlines the key specifications for the VEVOR Appliance Slider (Large 13"D x 16"W model):



Image 6.1: This image presents the range of VEVOR Appliance Slider sizes available, along with a table detailing their depth and width to help users choose the correct size for their appliances.

Feature	Detail
Brand	VEVOR
Model	Large (13"D x 16"W)
Material	Bamboo
Color	Black
Item Weight	3.31 Pounds
Product Dimensions (L x W)	13"L x 16"W
Item Thickness	2 Inches (0.7 inches for the board itself)
Shape	Rectangular
Installation Type	No Installation Required
Surface Recommendation	Hardwood, Laminate, Tile
Weight Capacity	Up to 40 lbs
Included Components	1 x Appliance Slider

7. Warranty & Support

7.1 Warranty Information

For information regarding the product warranty, please refer to the documentation provided at the time of purchase or contact VEVOR customer support directly. Standard return policy allows for refund/replacement within 30 days of purchase.

7.2 Customer Support

Should you encounter any issues or have questions about your VEVOR Appliance Slider, please contact VEVOR customer support. Contact details can typically be found on the VEVOR official website or on your product packaging.

© 2026 VEVOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FBRSS8MC

More documents and user manuals: **https://manuals.plus/**