Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VEVOR 14.5D x 9.5W

VEVOR Appliance Slider Instruction Manual (Medium, 14.5"D x 9.5"W)

Product Overview

The VEVOR Appliance Slider is designed to facilitate the movement of kitchen appliances on countertops. This medium-sized model measures 14.5 inches deep by 9.5 inches wide, providing a stable and easy-to-use platform for various kitchen devices.



Image: Top-down view of the VEVOR Appliance Slider, showcasing its sleek black design and compact form factor.

Key Features

- **High Weight Capacity:** Supports up to 40 lbs, ensuring stable movement for heavy kitchen appliances without tipping or wobbling.
- **Durable Natural Material:** Constructed from natural material with a 0.7-inch thickness, resistant to warping or cracking, and free from odors.
- **Silent Rubber Wheels:** Features directional, silent rubber wheels that protect countertops from scratches and wear, suitable for marble or tile surfaces.
- **Effortless Movement:** A hollow handle design allows for easy one-handed movement of appliances, reducing the need for heavy lifting.
- **Wide Compatibility:** This 14.5 x 9.5-inch mat is compatible with various appliances such as coffee makers, ovens, and microwaves.




Image: The VEVOR Appliance Slider demonstrating its 40 lb weight capacity with a kettlebell placed on top.

Setup and Installation

The VEVOR Appliance Slider requires no assembly. Simply place the slider on a clean, flat countertop surface. Ensure the surface is dry and free of debris to allow the rubber wheels to function optimally.

1. Choose a suitable location on your kitchen countertop for your appliance.

2. Place the VEVOR Appliance Slider on the chosen spot.
3. Carefully position your kitchen appliance (e.g., coffee maker, blender) onto the center of the slider.
4. Ensure the appliance is stable and centered on the slider before use.



Image: A woman carefully placing a coffee maker onto the VEVOR Appliance Slider on a kitchen countertop.

Operating Instructions

To move your appliance, gently pull or push the slider using the integrated hollow handle. The silent rubber wheels will allow the appliance to glide smoothly across the countertop.

- Locate the hollow handle cutout on the front edge of the slider.
- Place your fingers into the hollow handle.
- Gently pull the slider forward to bring the appliance out from under cabinets or push it back for storage.
- The directional wheels ensure smooth movement without lifting the appliance.



Image: A visual comparison showing a coffee maker being effortlessly slid forward on the VEVOR Appliance Slider from under a cabinet.

Maintenance

The VEVOR Appliance Slider is designed for easy cleaning. Its smooth surface can be wiped down with a damp cloth.

- For general cleaning, use a soft, damp cloth to wipe the surface of the slider.
- Avoid abrasive cleaners or harsh chemicals, as these may damage the material.

- Ensure the slider is completely dry before placing an appliance back on it.
- Periodically check the rubber wheels for any debris that might hinder smooth operation.



Image: A person cleaning the VEVOR Appliance Slider under running water in a sink, highlighting its smooth, easy-to-wipe surface.

Specifications

Feature	Detail
Brand	VEVOR
Material	Bamboo
Color	Black
Item Weight	2 Pounds
Product Dimensions (L x W)	14" x 9.5"
Item Thickness	0.7 Inches
Shape	Rectangular
Surface Recommendation	Tile, Hardwood
Included Components	1 x Appliance Slider

Troubleshooting

If you encounter any issues with your VEVOR Appliance Slider, please refer to the following common solutions:

- **Difficulty Sliding:** Ensure the countertop surface is clean and free of debris. Check the wheels for any obstructions. The slider is designed for smooth surfaces like tile or hardwood.
- **Appliance Instability:** Verify that your appliance is centered on the slider and does not exceed the 40 lbs weight capacity.
- **Damage to Countertop:** The rubber wheels are designed to prevent scratches. Ensure the wheels are clean and

intact. Avoid dragging the slider sideways if the wheels are not designed for omnidirectional movement.

Warranty and Support

For warranty information or technical support, please refer to the VEVOR official website or contact their customer service directly. Keep your purchase receipt for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FBRT8JH5

More documents and user manuals: **https://manuals.plus/**