Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VEVOR Large 13 x 16-inch

VEVOR Appliance Slider Instruction Manual

Model: Large 13 x 16-inch

Introduction

Thank you for choosing the VEVOR Appliance Slider. This manual provides essential information for the proper setup, operation, and maintenance of your new appliance slider. Designed for convenience and durability, this bamboo sliding tray allows for effortless movement of kitchen appliances on your countertop, protecting surfaces and optimizing space.

The VEVOR Appliance Slider is crafted from natural bamboo, featuring silent rubber wheels and a hollow handle for easy use. It is built to support various kitchen appliances, making your daily routines more efficient.

Product Features

- **High Weight Capacity:** Supports up to 40 lbs, ensuring stable movement for heavy appliances.
- **Natural Bamboo Material:** Constructed from 0.7-inch thick natural wood, resistant to warping and cracking, and free from odors.
- **Silent Rubber Wheels:** Directional wheels designed to prevent scratches and wear on countertops, suitable for marble, tile, quartz, and hardwood surfaces.
- **Effortless Sliding:** Features a hollow handle for easy, one-handed movement of appliances.
- **Wide Compatibility:** Measuring 13 x 16 inches, it accommodates various appliances such as 6-quart crockpots, air fryers, ovens, medium-sized mixers, slow cookers, and rice cookers.

Setup Instructions

1. **Unpacking:** Carefully remove the appliance slider from its packaging. Inspect for any damage during transit.
2. **Placement:** Place the appliance slider on a clean, dry, and flat countertop surface where you intend to use your appliance.
3. **Appliance Positioning:** Center your kitchen appliance (e.g., coffee maker, air fryer) on the bamboo surface of the slider. Ensure the appliance's base fits within the slider's dimensions (13"D x 16"W).
4. **Ready for Use:** The rubber wheels are pre-installed and ready for immediate use. No assembly is required.



Image: The VEVOR Appliance Slider positioned on a countertop with a coffee maker, ready for use.

Operating Instructions

The VEVOR Appliance Slider is designed for simple and efficient operation. Follow these steps to move your appliances with ease:

1. **Grip the Handle:** Locate the hollow handle cutout on the front edge of the bamboo slider.

2. **Slide Appliance:** Gently pull or push the slider using the hollow handle. The silent rubber wheels will allow the appliance to glide smoothly across your countertop.
3. **Positioning:** Move the appliance to your desired position for use or storage. The directional wheels facilitate movement in a straight line.
4. **Stability:** Once in position, the appliance slider provides a stable base for your appliance.




Image: A visual demonstration of an appliance being effortlessly slid forward on the VEVOR Appliance Slider.




Image: The appliance slider shown supporting a 40 lb weight, highlighting its robust capacity.

Maintenance

To ensure the longevity and optimal performance of your VEVOR Appliance Slider, follow these simple maintenance guidelines:

- **Cleaning the Surface:** Wipe the bamboo surface with a damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the natural wood finish. Dry thoroughly after cleaning.
- **Wheel Inspection:** Periodically check the rubber wheels for any debris or obstructions that might hinder smooth movement. Clean as necessary.
- **Avoid Soaking:** Do not submerge the appliance slider in water, as this can cause the bamboo to warp or crack.
- **Storage:** Store the slider in a dry environment when not in use.



Image: Demonstrating the ease of cleaning the smooth surface of the appliance slider.

Troubleshooting

If you encounter any issues with your VEVOR Appliance Slider, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Slider does not move smoothly.	Debris on wheels or countertop surface. Uneven weight distribution.	Clean wheels and countertop. Ensure appliance is centered on the slider.
Countertop appears scratched.	Wheels may have accumulated abrasive particles.	Regularly clean the rubber wheels to prevent scratching. Ensure countertop is clean before use.
Slider appears warped or damaged.	Exposure to excessive moisture or extreme temperature changes. Exceeded weight capacity.	Avoid prolonged exposure to water. Do not exceed the 40 lbs weight limit.



Image: Detail of the silent rubber wheels, highlighting their design for countertop protection.

Specifications

Attribute	Detail
Brand	VEVOR

Attribute	Detail
Model	Large 13 x 16-inch
Material	Bamboo
Color	Natural Wood
Product Dimensions (L x W)	13"L x 16"W
Item Thickness	0.7 Inches
Item Weight	3.31 Pounds
Weight Capacity	Up to 40 lbs
Shape	Rectangular
Surface Recommendation	Tile, Hardwood, Quartz, Marble
Included Components	1 x Appliance Slider
UPC	197988149323



Image: The appliance slider's thickness and dimensions are illustrated for clarity.



Image: Various kitchen appliances demonstrating the wide compatibility of the slider.

Warranty and Support

For warranty information or technical support regarding your VEVOR Appliance Slider, please refer to the product packaging or contact VEVOR customer service directly. Contact details can typically be found on the official VEVOR website or through your purchase platform.

Please have your product model (Large 13 x 16-inch) and UPC (197988149323) available when contacting support for faster service.

© 2026 VEVOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FBRTHY6V

More documents and user manuals: **https://manuals.plus/**