Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NUASI DE-NS-U30-BKZ02

NUASI Z02 Bluetooth 5.3 IPX7 Wireless In-Ear Headphones User Manual

Model: DE-NS-U30-BKZ02

Introduction Safety Information Package Contents Product Overview Setup Operating Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for choosing the NUASI Z02 Bluetooth 5.3 IPX7 Wireless In-Ear Headphones. These headphones are designed to provide high-quality audio and a secure, comfortable fit for active lifestyles. Featuring advanced Bluetooth 5.3 technology and IPX7 waterproofing, they are ideal for sports, jogging, and workouts in various weather conditions. Please read this manual carefully before using your headphones to ensure proper operation and to maximize their lifespan.

2. Safety Information

- Do not disassemble or modify the headphones. This may cause malfunction or electric shock.
- Keep the headphones away from extreme temperatures, direct sunlight, and moisture.
- Avoid prolonged exposure to high volume levels to prevent hearing damage.
- Do not use the headphones while driving or cycling in situations where inability to hear ambient sounds could be dangerous.
- Keep out of reach of children and pets.
- Dispose of batteries and electronic components according to local regulations.

3. Package Contents

Please check that all items are present in your package:

- NUASI Z02 Wireless In-Ear Headphones
- Charging Case
- USB Charging Cable

- Eartips (various sizes)
- User Manual

4. Product Overview

The NUASI Z02 headphones feature an ergonomic design for a secure fit during intense activities. Each earbud is equipped with touch controls for easy management of music and calls. The charging case provides additional battery life and protects the earbuds when not in use.
Key features include:

- Bluetooth 5.3 for stable and fast connection.
- IPX7 waterproof rating, resistant to sweat and rain.
- Ergonomic design for secure fit.
- Touch controls.
- Portable charging case.

5. Setup

5.1 Charging the Headphones and Case

1. **Initial Charge:** Before first use, fully charge the charging case and earbuds.
2. **Charging the Case:** Connect the USB charging cable to the charging port on the case and to a USB power adapter (not included) or a computer's USB port. The indicator light on the case will show charging status.
3. **Charging the Earbuds:** Place the earbuds into the charging case. Ensure they are correctly seated. The earbuds will automatically begin charging. The indicator lights on the earbuds will show their charging status.

5.2 Bluetooth Pairing

1. **Power On:** Open the charging case. The earbuds will automatically power on and enter pairing mode. The indicator light on one earbud will flash, indicating it's ready to pair.
2. **Activate Bluetooth:** On your device (smartphone, tablet, etc.), enable Bluetooth.
3. **Select Device:** Search for "NUASI Z02" in the list of available Bluetooth devices and select it to connect.
4. **Confirmation:** Once connected, you will hear an audio prompt, and the indicator lights on the earbuds will stop flashing.
5. **Automatic Reconnection:** After initial pairing, the earbuds will automatically connect to the last paired device when taken out of the case, provided Bluetooth is enabled on the device.

5.3 Wearing the Headphones

- Choose the eartips that provide the most comfortable and secure fit for your ears. A good seal is crucial for optimal sound quality and bass response.
- Insert the earbuds into your ear canals and gently twist them until they feel snug and stable.

6. Operating Instructions

6.1 Power On/Off

- **Power On:** Open the charging case, or long-press the touch area on both earbuds for 3 seconds.

- **Power Off:** Place the earbuds back into the charging case and close the lid, or long-press the touch area on both earbuds for 5 seconds.

6.2 Music Playback

- **Play/Pause:** Single tap the touch area on either earbud.
- **Next Track:** Double tap the touch area on the right earbud.
- **Previous Track:** Double tap the touch area on the left earbud.
- **Volume Up:** Triple tap the touch area on the right earbud.
- **Volume Down:** Triple tap the touch area on the left earbud.

6.3 Call Management

- **Answer/End Call:** Single tap the touch area on either earbud.
- **Reject Call:** Long-press the touch area on either earbud for 2 seconds.

6.4 Voice Assistant

- **Activate Voice Assistant:** Long-press the touch area on either earbud for 2 seconds (when not on a call).

7. Maintenance

7.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents.
- Remove eartips and clean them separately with mild soap and water if necessary, ensuring they are completely dry before reattaching.

7.2 Storage

- When not in use, store the headphones in their charging case to protect them from dust and damage.
- Store in a cool, dry place, away from extreme temperatures.

7.3 Water Resistance (IPX7)

- The earbuds are IPX7 rated, meaning they can withstand immersion in water up to 1 meter for 30 minutes. They are resistant to sweat and rain.
- *Note:* The charging case is NOT waterproof. Do not expose the charging case to water or moisture.
- Ensure the earbuds are completely dry before placing them back into the charging case to prevent damage to the charging contacts.

8. Troubleshooting

Problem	Possible Cause	Solution
Cannot pair with device	Bluetooth is off; earbuds not in pairing mode; device list full.	Ensure Bluetooth is on. Place earbuds in case, close, then open to re-enter pairing mode. Forget "NUASI Z02" on your device and try pairing again.

Problem	Possible Cause	Solution
No sound or low volume	Volume too low; earbuds not properly seated; poor connection.	Adjust volume on both earbuds and device. Re-seat earbuds. Reconnect Bluetooth.
Earbuds not charging	Charging contacts dirty; cable faulty; case battery low.	Clean charging contacts on earbuds and case. Try a different USB cable. Charge the charging case.
Intermittent connection	Distance too far; interference; low battery.	Keep device within 10 meters. Avoid strong electromagnetic interference. Charge earbuds and case.

9. Specifications

Brand	NUASI
Model	DE-NS-U30-BKZ02
Wireless Technology	Bluetooth 5.3
Water Resistance Rating	IPX7 (Earbuds only)
Ear Placement	In-Ear
Battery Type	Lithium Polymer (included)
Item Weight	100 g
Package Dimensions	10.2 x 10 x 4.3 cm

10. Warranty and Support

NUASI products are designed for reliability and performance. For warranty information or technical support, please refer to the warranty card included in your package or visit the official NUASI website. If you encounter any issues not covered in this manual, please contact our customer service for assistance.
Note: Keep your purchase receipt as proof of purchase for warranty claims.

© 2025 NUASI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FBRVVS2Z

More documents and user manuals: **https://manuals.plus/**