KLARSTEIN Arctic Porter

Klarstein Arctic Porter Ice Cube Maker User Manual

Model: Arctic Porter | Brand: KLARSTEIN

Introduction

This manual provides essential information for the safe and efficient operation of your Klarstein Arctic Porter Ice Cube Maker. Please read it thoroughly before first use and keep it for future reference. This appliance is designed to produce ice cubes for household use.

Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions carefully before operating the appliance.
- Do not immerse the power cord, plug, or the appliance itself in water or other liquids.
- Keep the appliance out of reach of children and pets.
- Use only potable (drinking) water in the ice maker.
- Ensure adequate ventilation around the appliance. Maintain a minimum clearance of 15 cm on all sides.
- Unplug the appliance from the power outlet before cleaning, maintenance, or when not in use.
- Do not operate the appliance with a damaged cord or plug. If the cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- Allow the appliance to stand upright for at least 2 hours before plugging it in, especially after transport, to allow the refrigerant to settle.
- Do not use the appliance outdoors.
- Do not place the appliance near heat sources such as ovens, radiators, or direct sunlight.

Product Features

- Produces 9 bullet ice cubes per cycle.
- Fast production time: approximately 8 minutes per cycle.

- High daily production capacity: up to 12 kg of ice in 24 hours.
- Selectable ice cube sizes: small and large.
- Large 2-liter water tank capacity.
- 0.8 kg ice cube storage compartment.
- Intuitive touch control panel with clear indicator lights.
- Convenient self-cleaning function.
- Durable stainless steel housing.
- Integrated carry handle for easy transport.
- BPA-Free materials for safe ice production.

Setup

1. **Unpack the Appliance:** Carefully remove the ice maker and all accessories from its packaging. Check for any damage during transit.
2. **Placement:** Place the ice maker on a stable, level, and dry surface. Ensure it is away from direct sunlight, heat sources (like ovens or radiators), and corrosive gases. Allow at least 15 cm of space around the appliance for proper ventilation.
3. **Refrigerant Settling:** After unpacking or moving, allow the ice maker to stand upright for a minimum of 2 hours before plugging it into a power outlet. This allows the refrigerant to settle, ensuring optimal performance and preventing damage.
4. **Initial Cleaning:** Before first use, clean the interior of the ice maker. Refer to the "Maintenance and Cleaning" section for detailed instructions.

Operating Instructions

Follow these steps to produce ice cubes with your Klarstein Arctic Porter Ice Cube Maker:

Illustration of the three simple steps for operating the ice maker.

1. **Step 1: Fill with Water.** Open the lid of the ice maker. Fill the water tank with clean, potable water up to the 'MAX' fill line. Do not overfill. Ensure the ice basket is in place.

2. **Step 2: Select Ice Cube Size.** Plug the appliance into a grounded power outlet. The 'POWER' indicator light may flash. Press the '**SELECT**' button to choose your desired ice cube size: 'S' for small or 'L' for large. The corresponding indicator light will illuminate.
3. **Step 3: Start Production.** Press the '**ON/OFF**' button to begin the ice production cycle. The 'POWER' indicator will light up steadily. The appliance will start making ice.
4. **Step 4: Monitor Status.**
   - If the '**ADD WATER**' indicator lights up, it means the water tank is empty. Add more water and the ice production will resume automatically.
   - If the '**ICE FULL**' indicator lights up, the ice basket is full. Remove the ice cubes to allow production to continue.
5. **Step 5: Remove Ice Cubes.** Once ice cubes are produced, use the provided ice scoop to remove them from the ice basket. If not removed, the ice will eventually melt and the water will return to the reservoir for future cycles.
6. **Step 6: Stop Operation.** To stop ice production at any time, press the **ON/OFF**' button. Unplug the appliance when not in use.

The intuitive control panel with indicator lights for easy operation.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your ice maker.

Regular Cleaning

1. **Unplug the Appliance:** Always ensure the ice maker is unplugged from the power outlet before cleaning.
2. **Remove Ice Basket:** Take out the ice basket and any remaining ice cubes.
3. **Drain Water:** Locate the drain plug at the bottom or side of the unit (if present) and remove it to drain any remaining water from the reservoir. Replace the plug securely after draining.
4. **Clean Interior:** Wipe the interior surfaces, including the water tank and ice-making components, with a soft cloth dampened with warm water and a mild, food-safe detergent. Rinse thoroughly with clean water to remove any detergent residue.

5. **Clean Exterior:** Wipe the exterior of the appliance with a soft, damp cloth. Do not use abrasive cleaners or solvents.
6. **Dry Thoroughly:** Ensure all parts are completely dry before reassembling and storing or using the appliance again.

Self-Cleaning Function

Your Klarstein Arctic Porter Ice Cube Maker features a self-cleaning function for convenient maintenance.

1. **Fill Water Tank:** Ensure the water tank is filled with clean, potable water.
2. **Activate Self-Clean:** With the appliance plugged in and powered on, press and hold the**CLEAN**' button (if available, or refer to specific model instructions for activation). The appliance will initiate a cleaning cycle.
3. **Drain and Dry:** After the self-cleaning cycle is complete, drain the water from the reservoir as described in the regular cleaning steps and wipe the interior dry.

The self-cleaning function and smooth stainless steel housing simplify maintenance.

Removable ice cube container and scoop for practical use and cleaning.

Troubleshooting

If you encounter issues with your ice maker, refer to the following table for common problems and solutions:

Problem	Possible Cause	Solution
Appliance not turning on.	No power supply; 'ON/OFF' button not pressed.	Check if the power cord is securely plugged in. Press the 'ON/OFF' button.
'ADD WATER' indicator is lit.	Water tank is empty.	Fill the water tank with potable water up to the 'MAX' line.
'ICE FULL' indicator is lit.	Ice basket is full.	Remove ice cubes from the basket.
No ice production or very small ice cubes.	Insufficient water; high ambient temperature; water too warm; refrigerant not settled.	Ensure water tank is full. Place the unit in a cooler environment. Use cold water. If recently moved, allow 2 hours for refrigerant to settle. Clean the unit.
Unusual noise during operation.	Normal compressor/fan operation; unit not level.	Some noise is normal. Ensure the unit is on a stable, level surface. If noise is excessive or unusual, contact customer support.

Specifications

Brand:	KLARSTEIN
Model Name:	Arctic Porter
Product Dimensions (D x W x H):	11.81" x 9.45" x 12.99" (approx. 30 cm x 24 cm x 33 cm)
Water Tank Capacity:	2 Liters
Ice Cube Compartment Capacity:	0.8 kg
Wattage:	120 watts
Voltage:	220-240 V~ | 50 Hz
Refrigerant:	R600a (23g)
Material Type:	Stainless Steel
Daily Production Volume:	Approx. 12 kg/24h
Ice Cubes per Cycle:	9
Production Time per Cycle:	Approx. 8 minutes
Cord Length:	180 cm
Weight:	Approx. 7.2 kg

Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the documentation included with your purchase or visit the official KLARSTEIN website. You can also find more information at the KLARSTEIN Store on Amazon.