Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEFFOT H313 (2GB+8GB)

LEFFOT H313 Android 14.0 TV Box User Manual

Model: H313 (2GB+8GB)

1. Introduction

Thank you for choosing the LEFFOT H313 Android 14.0 TV Box. This device transforms your television into a smart entertainment hub, offering stunning 4K Ultra HD streaming, dual-band WiFi 6 connectivity, and hands-free control with the integrated Google Assistant voice remote. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new TV box to ensure an optimal user experience.



Image: The LEFFOT H313 Android TV Box and its accompanying voice remote control.

2. Setup Guide

2.1 What's in the Box

Before you begin, please ensure all components are present:

- LEFFOT H313 Android TV Box
- Bluetooth Voice Remote Control
- HDMI Cable
- Power Adapter (5V/2A)
- User Manual (this document)



Image: A visual representation of all items included in the LEFFOT H313 TV Box package: the TV box, remote, power adapter, HDMI cable, and user manual.

2.2 Connecting Your TV Box

Follow these steps to connect your LEFFOT H313 TV Box to your television and network:

1. **Attach TV Box to TV:** Connect one end of the HDMI cable to the HDMI port on your LEFFOT H313 TV Box and the other end to an available HDMI input on your television.
2. **Connect Power:** Plug the power adapter into the DC 5V/2A port on the TV box and then into a wall outlet.
3. **Connect to the Internet:**
    - **Wi-Fi:** Once powered on, navigate to the network settings and select your Wi-Fi network. Enter the password if prompted. The device supports 2.4G and 5G WiFi 6 for stable connections.
    - **Ethernet:** For a wired connection, connect an Ethernet cable from your router to the LAN port on the TV box.
4. **Select Input:** On your television, select the correct HDMI input source that corresponds to where you connected the TV box.
5. **Initial Setup:** Follow the on-screen prompts to complete the initial setup, including language selection, Google account login, and network configuration.




Image: A visual guide illustrating the three main steps for setting up the TV box: attaching it to the TV via HDMI, connecting to the internet (wirelessly or wired), and initiating streaming.




Image: A detailed diagram showing the dimensions of the LEFFOT H313 TV Box and the location of its various interface ports, including TF Card slot, USB1, USB2, AV, HD (HDMI), ETHERNET, and DC 5V/2A power input.

3. Operating Instructions

3.1 Navigating the Interface

The LEFFOT H313 runs on Android 14.0, providing a user-friendly interface. Use the included Bluetooth voice remote to navigate through menus, select applications, and control playback. The remote features standard navigation buttons (directional pad, OK), home, back, volume controls, and dedicated buttons for popular streaming services.



Image: The Android 14.0 TV Box interface, highlighting its fluency, stability, and compatibility with various streaming apps and utilities accessible via the APP Store.

3.2 Voice Control with Google Assistant

The included remote features a built-in Google Assistant. Simply press the Google Assistant button on the remote and speak your commands. You can search for content, open apps, control smart home devices, get answers to questions, and more, all hands-free.




Image: A user interacting with the Bluetooth Voice Remote, demonstrating the hands-free convenience of Google Assistant for searching content and controlling the TV box with voice commands.

3.3 Streaming 4K Ultra HD Content

The LEFFOT H313 supports 4K@60fps video playback with HDR10, delivering exceptional clarity and vibrant colors. Ensure your television is 4K compatible and that you are streaming 4K content from supported applications like Netflix, YouTube, Prime Video, Hulu, and Disney+.



Image: A visual demonstrating the 4K Ultra HD Decoding capability, promising cinematic clarity and lifelike colors for high-quality streaming on your TV.

3.4 Network Connectivity

The device features dual-band WiFi 6 (802.11ax) and a 100M Ethernet port for reliable and fast internet access, ensuring buffer-free 4K streaming even during peak network usage.



Image: A graphic illustrating the stable and fast network connection delivered by 2.4G & 5G WiFi 6, enabling high-quality and buffer-free 4K streaming compared to older WiFi standards.

3.5 Installing and Managing Apps

Access the Google Play Store directly from your TV box to download and install a wide variety of applications, games, and streaming services. With 2GB RAM and 8GB ROM (expandable via TF card up to 64GB), you have ample space for your favorite content.



Image: A visual representation of accessing over 5000+ apps for your home TV via the Google Play Store, showcasing popular streaming services like HBO Max, Netflix, Hulu, Prime Video, Disney+, Apple TV+, YouTube, ESPN, STARZ, Sling, and Spotify.

4. Maintenance

Proper maintenance ensures the longevity and optimal performance of your LEFFOT H313 TV Box.

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the device. Do not use liquid cleaners or abrasive materials.
- **Ventilation:** Ensure the TV box is placed in a well-ventilated area. Do not cover ventilation openings or place the device in an enclosed space that could restrict airflow.
- **Software Updates:** Periodically check for system updates in the settings menu to ensure you have the latest features and security patches.
- **Power Cycle:** If the device becomes unresponsive, disconnect the power adapter for a few seconds and then reconnect it to perform a power cycle.

5. Troubleshooting

If you encounter issues with your LEFFOT H313 TV Box, refer to the following common problems and solutions:

Problem	Possible Solution

Problem	Possible Solution
No power/Device not turning on	Ensure the power adapter is securely connected to the TV box and a working power outlet. Try a different outlet.
No signal on TV screen	Verify the HDMI cable is properly connected to both the TV box and the TV. Ensure your TV is set to the correct HDMI input source. Try a different HDMI port or cable.
Wi-Fi connection issues	Check if your router is working correctly. Restart the TV box and your router. Re-enter the Wi-Fi password in network settings. Ensure the TV box is within range of your Wi-Fi signal.
Remote control not responding	Check the batteries in the remote control and replace them if necessary. Ensure there are no obstructions between the remote and the TV box. Re-pair the Bluetooth remote if needed (refer to on-screen instructions during initial setup or device settings).
Apps crashing or freezing	Close and restart the app. Clear the app's cache and data in the device settings. Ensure the device has enough free storage. Perform a system restart.

6. Specifications

Key technical specifications for the LEFFOT H313 Android 14.0 TV Box:

Feature	Detail
Model Name	H313
Operating System	Android 14.0
CPU	Allwinner H313 Quad-Core Cortex-A53
GPU	Mali-G31
RAM	2GB
ROM	8GB (Expandable via TF card up to 64GB)
Video Output	4K@60fps, HDR10
Connectivity	Dual-band WiFi 6 (802.11ax), 100M Ethernet, HDMI, USB 2.0 (x2), AV, TF Card Slot
Special Features	Google Assistant Voice Remote, Airplay, Miracast
Dimensions	3.54 x 3.54 x 0.7 inches
Weight	3.25 ounces

7. Warranty and Support

LEFFOT products are designed for reliability and performance. For specific warranty details, please refer to the warranty card included with your product or contact the seller directly. For further assistance or technical support, you may:

- Consult the digital User Manual available at: User Manual (PDF)
- Contact the LEFFOT Store directly through your purchase platform for product-specific inquiries.

© 2025 LEFFOT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FCS5PGB3

More documents and user manuals: **https://manuals.plus/**