Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Alfine A66

Alfine A66 4D Full Body Massage Chair Instruction Manual

Model: A66

Brand: Alfine

Safety Information

Before operating the Alfine A66 4D Full Body Massage Chair, please read all instructions carefully. Keep this manual for future reference.

- Individuals suffering from osteoporosis, spinal fracture, sprain, or acute pain should not use this product.
- Individuals with pacemakers, defibrillators, or other personal medical devices prone to electronic interference should not use the product.
- Pregnant women and women who have just given birth should not use the product.
- Individuals with symptoms of acute low back pain, herniated disk, spondylolisthesis, spinal stenosis, degenerative spondylolisthesis, or similar conditions should not use the product.
- Individuals who have abnormalities or curvature of the spine should not use the product.
- Children under 14 years of age should not use the product.
- Consult the instruction manual for other individuals who are not suitable for massage.
- In case of emergency, press the stop button on the remote to stop the operation.
- The areas under the footrest and behind the backrest are potentially dangerous for a child or pet. Keep children and pets away from the chair while in use and check these areas carefully before reclining, lowering legrest, or returning chair to upright position.

Setup and Installation

The Alfine A66 massage chair requires minimal assembly. Only the footrest needs to be attached to the main unit.

Unboxing and Component Identification

Carefully unbox the massage chair. You will find the main unit, the footrest, and an accessory box. The accessory box contains the control panel, control panel holder, power cord, screws, fuses, warranty card, and operation instructions.



Image: Alfine A66 Massage Chair dimensions and packaging. This image shows the chair's dimensions in both upright and reclined positions, as well as the package dimensions. It highlights that only footrest assembly is required.

Footrest Installation

1. Remove the packaging bag from the calf supports and take off the packaging protective sponge.
2. Connect the footrest's air tubes and plug terminals to the air connectors and terminal sockets on the main unit. Ensure a secure and snug fit.
3. Loosen the two screws on the main body that secure the calf supports. Flip the cover plate over and place the hanging axis of the calf support into the circular groove on the main body.
4. Secure the cover plate with the screws. Then, lift the cushion, place the calf support, and attach the Velcro straps to it, ensuring they are neatly arranged.

Control Panel Installation

1. Undo the cable ties on the control tablet's wiring harness. Align the notch on the aviation plug with the protrusion in the socket and firmly connect it in place by twisting the threads.
2. Securely place the control tablet on the stand tray.

3. Please note that when installing the stand, make sure to align the threaded rod of the stand with the threaded socket on the armrest and tighten it securely in place.

Power Connection

1. Connect one end of the power cord to the rear socket of the control box, and plug the other end into a household power outlet.
2. Turn on the power switch to energize the massage chair.

Your browser does not support the video tag. This video demonstrates the footrest installation for the Alfine A66 4D Massage Chair.

Video: Alfine A66 4D Massage Chair Footrest Installation. This video provides a step-by-step guide on how to install the footrest of the massage chair.

Operating Instructions

Starting a Massage

Press the power button at the top of the control panel to turn on the massage chair. The massage chair enters the automatic recline mode, with the backrest lowering and the footrest rising to the default massage position.

Automatic Body Scanning System

The massage chair begins the body scan process. During this process, the user needs to press their neck against the rollers. Once the position of the shoulders is detected, a confirmation dialog will appear. Users can adjust the shoulder position using the up and down arrows.

Choosing Auto Modes

In the "Auto Programs" box, you can choose from seven automatic modes: Comfort Massage, Quick Massage, Stretch Massage, Good Night Sleep, Shoulder & Neck Massage, Airbag Massage, and Sport Massage. These correspond to program codes A1 through A7. Pressing the "More" mode button repeatedly cycles through the following programs: Stress Relieving, Thai Massage, Waist & Hip Massage, Spine Care, Energy, Shiatsu Massage, Office Regimen, and TV Mode. The program codes corresponding to these eight automatic modes are from A8 to B7.

Adjusting Airbag Intensity

Under the automatic mode, you can adjust the intensity of the airbags by repeatedly pressing the airbag adjustment button. The airbag intensity has six levels, and you can also turn off the airbags. The default airbag intensity is the third level.

Adjusting 4D Massage Intensity

Under the automatic mode, you can adjust the 4D massage intensity by repeatedly pressing the 4D massage intensity button. The 4D massage intensity has six levels. The default intensity is the third level. You can also completely turn off the 4D function.

Adjusting Zero Gravity

Pressing the zero-gravity button on the massage chair enables one-touch access to the zero-gravity position. You can repeatedly press the zero-gravity button to switch between zero-gravity one, two, and three positions, as well as the

upright position.

Adjusting Heating Functions

Press the heat button to activate heating for the back and leg areas of the massage chair. There are three levels: default is level one, press again for levels two and three, or to turn off heating.

Adjusting Foot Rollers

The foot rollers have three selectable speeds, adjusted by repeatedly pressing the roller button. The default speed is the first level. If lit, pressing it again will turn off the foot roller function.

Adjusting Massage Program Duration

The massage chair's auto program time can be adjusted to ten, fifteen, twenty, twenty-five, or thirty minutes by pressing the time adjustment button. The default is twenty minutes.

Choosing Massage Techniques

Press the 'Technique' button to choose from individual techniques such as 'Knead', 'Tap', 'Knead & Tap', 'Knock', 'Shiatsu', and '4D Method'. Additionally, you can select compound techniques like 'Knead + 4D Method', 'Tap + 4D Method', 'Knead & Tap + 4D Method', 'Knock + 4D Method', and 'Shiatsu + 4D Method'.

Customizing Massage Area

Press the 'Point/Partial' button to choose among five massage areas: Point, Partial, Full Body, Upper Body, and Lower Body. In 'Point' and 'Partial' settings, you can use the arrow keys to adjust the vertical position of the back roller.

Adjusting Backrest and Leg Angle Independently

Pressing the circular button in the video will navigate to the massage chair posture adjustment interface. In the posture adjustment interface, you can adjust the backrest angle by long-pressing the backrest up and down buttons. Long pressing the up and down buttons on the leg section adjusts the angle of the legs. Releasing the buttons stops at the current angle.

Child Lock Function

Pressing and holding the button on the right side of the top of the control panel for three seconds activates the child lock function. Once activated, all buttons on the control panel are disabled. To deactivate the child lock, press and hold the button again for three seconds.

Pause/Close Programs

Pressing the pause button can pause all massage functions, and pressing it again will resume the previous massage. Long pressing the power button can turn off the massage chair, causing it to enter a reset state. The backrest will rise, the footrest will descend, and after returning to an upright position.

Bluetooth Function

Long pressing and holding the "Roller" button for three seconds can turn on the Bluetooth function. By default, the Bluetooth function is turned on.

Voice Control Function

Long-press the Time button for three seconds to activate voice control. Say "Hi Alfine" to activate it. After hearing "I am here," use the listed voice commands on the back of the control panel to control the massage chair functions. Speak slowly for better recognition.

Shortcut Key Usage

Press and hold the central position of the circular shortcut button for three seconds to turn on the massage chair. Press the knob's center button to pause all massage chair actions; press again to resume. Long press the middle button of the knob for three seconds to close the massage chair. Turning the knob clockwise will adjust the massage chair to the upright state; turning it counterclockwise will adjust the massage chair to zero gravity, stop the rotation, and the massage chair will stop in its current state.

Wireless Charging / USB Charging

Placing the phone in the video wireless charging area will start charging. You can also open the dust plug of the USB charging port and connect the phone to charge with the data cable.

Your browser does not support the video tag. This video provides a comprehensive instructional guide for operating the Alfine A66 Massage Chair.

Video: ALFINE A66 Massage Chair Instructional Video. This video demonstrates various operational features of the massage chair, including starting a massage, adjusting settings, and using special functions.

Specifications

- **Brand:** Alfine
- **Model Name:** A66
- **Product Dimensions:** 59.06"D x 29.92"W x 46.46"H
- **Item Weight:** 216 Pounds
- **Material:** Faux Leather, Memory Foam
- **Maximum Weight Recommendation:** 300 Pounds
- **Reclining Position Count:** 3
- **Included Components:** Arm Pad

Warranty and Support

Our products are backed by a 3-year Coverage with Expert Support and 24/7 customer support. If you have any questions or issues with our products, feel free to contact us through Amazon or call our after-sales phone number directly. We are dedicated to providing you with the best shopping experience.



Image: U.S.-Based Support Anytime, Day or Night. This image shows customer support representatives ready to assist users.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FD9CK32Q

More documents and user manuals: **https://manuals.plus/**