Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Garvee PPG_339D4PFXzswmbJc05

Garvee Chaise Lounge Outdoor Set of 2 Instruction Manual

Model: PPG_339D4PFXzswmbJc05

Introduction

Thank you for choosing the Garvee Chaise Lounge Outdoor Set of 2. This manual provides important information regarding the assembly, operation, maintenance, and specifications of your new outdoor furniture. Please read these instructions carefully before assembly and use to ensure safe and proper operation.

Safety Information

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble on a soft, clean surface to prevent scratching.
- Do not overtighten screws during assembly. Tighten all fasteners securely once assembly is complete.
- Keep children and pets away during assembly.
- Do not exceed the maximum weight capacity of the lounge chair.
- Periodically check all bolts and nuts for tightness and re-tighten as necessary.

Package Contents

Before beginning assembly, ensure all components listed below are present.

- Chaise Lounge Frame (2 sets)
- Cushions (2 sets)
- Hardware Pack (screws, washers, wrench)
- Instruction Manual



Image: A complete Garvee Chaise Lounge, representing the items included in the package.

Setup and Assembly

Follow these steps to assemble your Garvee Chaise Lounge:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, flat surface to prevent damage. Verify all parts are present against the package contents list.
2. **Attach Legs/Wheels:** Secure the legs and wheels to the main frame of the chaise lounge using the provided hardware. Ensure all bolts are finger-tightened initially.
3. **Assemble Backrest Mechanism:** Connect the adjustable backrest mechanism to the main frame. Pay attention to the orientation of the parts to ensure proper reclining function.
4. **Secure All Fasteners:** Once all major components are in place, fully tighten all bolts and screws using the included wrench. Do not overtighten.
5. **Place Cushions:** Position the cushions onto the assembled chaise lounge. Use the integrated ties or straps to secure the cushions to the frame, preventing them from slipping.



Image: An assembled Garvee Chaise Lounge set, demonstrating the final product after setup.

Operating Instructions

Adjusting the Backrest

Your Garvee Chaise Lounge features a 5-level adjustable backrest, allowing you to customize your comfort for various activities such as reading, napping, or sunbathing.

1. To adjust the backrest, gently lift the backrest section.
2. Select one of the five available positions by aligning the support bar with the desired notch.
3. Ensure the backrest is securely locked into place before applying full weight.



Image: Illustration of the 5-position adjustable backrest mechanism.

Moving the Chaise Lounge

The chaise lounge is equipped with two back wheels for easy relocation.

- To move the lounge chair, slightly lift the front end.
- Roll the chair to your desired location using the wheels.
- Lower the front end to secure the chair in its new position.

Care and Maintenance

Proper care will extend the life and appearance of your Garvee Chaise Lounge.

Cushion Care

- The cushions feature removable, breathable covers for easy cleaning.
- Spot clean with a mild soap and water solution. For deeper cleaning, remove covers and hand wash or machine wash on a gentle cycle with cold water. Air dry only.
- Store cushions indoors during inclement weather or prolonged periods of non-use to prevent fading and wear.

Frame Care

- The frame is constructed from rust-resistant steel and all-weather PE rattan.
- Wipe down the rattan and frame with a damp cloth and mild soap as needed. Rinse thoroughly and dry completely.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- Periodically inspect the frame for any signs of wear or damage. Tighten any loose fasteners.



Image: Details showcasing the strong, weather-resistant rattan and easy-to-clean cushion fabric for maintenance.

TROUBLESHOOTING

If you encounter any issues with your chaise lounge, please refer to the following common solutions:

- **Wobbly Chair:** Ensure all bolts and screws are securely tightened. Check that the chair is on a level surface.
- **Backrest Not Adjusting Smoothly:** Inspect the adjustment mechanism for any obstructions or debris. Ensure

the support bar is properly aligned with the notches.

- **Cushions Slipping:** Verify that the cushion ties or straps are securely fastened to the frame.

If problems persist, please contact Garvee customer support for assistance.

Specifications

Feature	Detail
Brand	Garvee
Model Number	PPG_339D4PFXzswmbJc05
Product Dimensions (D x W x H)	40.55"D x 25.59"W x 16.14"H
Frame Material	Metal (with PE Rattan)
Color	Grey
Item Weight	84 pounds (per set of 2)
Backrest Adjustment	5 positions
Included Components	Cushions
UPC	199414725217
ASIN	B0FF9RLQTW



Image: Product dimensions and weight capacity illustration for the chaise lounge.

Warranty and Support

Warranty Information

For specific warranty details regarding your Garvee Chaise Lounge, please refer to the documentation included with your purchase or contact Garvee customer service directly. Standard return policies typically allow for returns within 30 days of purchase.

Customer Support

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact Garvee customer support. Have your model number (PPG_339D4PFXzswmbJc05) and purchase information ready for faster service.
You can often find contact information on the manufacturer's website or through your retailer.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FF9RLQTW

More documents and user manuals: **https://manuals.plus/**