Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

anysun BG1536

anysun Smart Robot Dog Instruction Manual

Model: BG1536

1. Introduction and Overview

The anysun Smart Robot Dog is an interactive and programmable toy designed to provide entertainment and educational value. It features various modes including interactive learning, programmable actions, and realistic responses to commands and touch. This manual will guide you through the setup, operation, and maintenance of your robot dog.



Figure 1: The anysun Smart Robot Dog, showcasing its interactive nature.

2. Setup

2.1 Battery Installation and Charging

The robot dog is powered by a rechargeable lithium-ion battery. Ensure the battery is fully charged before first use.

1. Locate the battery compartment on the underside of the robot dog.
2. Open the battery box cover.
3. Connect the battery to the robot dog's internal connector.
4. Close the battery box cover.
5. Connect the provided USB charging cable to the robot dog's charging port and a suitable USB power source.

6. Charge for approximately 2 hours to achieve 60-80 minutes of playtime.



Figure 2: USB Charging and Battery Installation Steps.

3. Operating Instructions

3.1 Remote Control Functions

The robot dog is controlled using the provided 2.4GHz wireless remote. Familiarize yourself with the buttons for various commands.

3.2 Basic Movements and Actions

Use the remote control to command the robot dog to perform the following actions:

- **Forward** / **Backward:** Move the robot dog in the desired direction.
- **Turn Left** / **Turn Right:** Change the robot dog's orientation.
- **Sit Down:** Commands the robot dog to sit.
- **Handstand:** Commands the robot dog to perform a handstand.
- **Get Down:** Commands the robot dog to lie down.

- **Push-up:** Commands the robot dog to perform push-ups.
- **Play Cute:** Activates a cute interaction sequence.
- **Dancing:** Initiates a dancing routine.



Figure 3: Multiple Interaction Functions of the Robot Dog.

3.3 Touch Sensing

The robot dog responds to touch. A simple pat on its chin can trigger barks and lively movements, simulating interaction with a real pet.



Figure 4: Demonstrating Touch Sensor and Manual Following Mode.

3.4 Manual Following Mode

In Manual Following Mode, point the remote's front at the ground between you and the robot dog. The robot dog will detect that spot and follow it.

3.5 Programmable Actions

Empower creativity by programming the robot dog. Using the remote control, you can sequence up to 100 unique actions. This feature helps develop logical thinking and problem-solving skills.

3.6 Interactive Learning Companion

The robot dog can tell stories, sing songs, and perform various actions, blending entertainment with education. This helps enhance language skills and sparks imagination.

▶ **Watch video online**

Smart Interactive Toy Dog

Video 1: Demonstration of the Smart Interactive Toy Dog's features, including voice control, various movements, and touch responses.

4. Maintenance

- Keep the robot dog clean by wiping it with a dry, soft cloth.
- Avoid exposing the toy to water or excessive moisture.
- Store the robot dog in a cool, dry place away from direct sunlight when not in use.
- Ensure the battery is charged periodically even during long storage to maintain battery health.

5. Troubleshooting

- **Robot not responding:** Check if the robot dog is powered on and if the remote control has fresh batteries. Ensure they are within range.
- **Limited movement:** The battery might be low. Recharge the robot dog fully.
- **Interference:** The 2.4GHz wireless control is designed to minimize interference, but ensure no other strong wireless signals are nearby if issues persist.
- **Unexpected behavior:** Turn the robot dog off and on again to reset its system.

6. Specifications

Feature	Detail
Brand Name	anysun
Model Name	750880016553
Model Number	BG1536
Toy Figure Type	Interactive Gaming Figure
Character	Robot Dog
Manufacturer Minimum Age	36.0 Months
Material Type	Plastic
Item Dimensions (L x W x H)	8.5"L x 5.6"W x 8.5"H
Item Weight	2.1 Pounds
Color	Yellow
Power Source	Rechargeable Battery
Number of Batteries	1 Lithium Ion battery required (built-in, non-removable)
Additional Features	Interactive Learning & Realistic Interaction

7. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your product packaging or visit the official anysun website. Keep your purchase receipt for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FFH57XPN

More documents and user manuals: **https://manuals.plus/**