Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GarveeHome 1sxp5GPeZ6VWvmTK9p-fPAQ20c

GarveeHome Nursery Rocking Chair User Manual

Model: 1sxp5GPeZ6VWvmTK9p-fPAQ20c

Introduction

Thank you for choosing the GarveeHome Nursery Rocking Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new rocking chair. Please read these instructions carefully before use and retain them for future reference.

Important Safety Information

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble the chair on a soft, clean surface to prevent scratches.
- Tighten all fasteners securely, but do not overtighten. Periodically check and retighten fasteners as needed.
- Do not exceed the maximum weight capacity of 300 lbs (136 kg).
- Keep children away from the assembly area.
- Use the chair only on a flat, stable surface.
- Avoid placing fingers or other body parts near moving parts, especially the footrest mechanism, to prevent pinching.

Package Contents

Verify that all components are included in your package:

- 1 x GarveeHome Rocking Chair (main body)
- Assembly hardware (screws, washers, Allen wrench, etc.)
- Instruction Manual

Note: Specific hardware details may vary. Refer to the included assembly diagram for precise component identification.

Setup and Assembly

Assembly is required for this rocking chair. Follow the steps below carefully. It is recommended to have two people for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a clean, soft surface to prevent damage.
2. **Identify Parts:** Refer to the assembly diagram (not provided in this digital manual, but typically included in the physical package) to identify each component and hardware piece.
3. **Attach Rocker Base:** Secure the wooden rocker legs to the chair frame using the provided screws and tools. Ensure the curved parts of the legs are oriented correctly for rocking motion.
4. **Secure Backrest and Seat:** Connect the backrest to the seat frame, ensuring all alignment points are correctly engaged. Fasten with the appropriate hardware.
5. **Install Armrests:** Attach the armrests to the main chair body. Pay attention to the side pocket orientation if applicable.
6. **Attach Footrest Mechanism:** If your model includes a retractable footrest, carefully attach its mechanism according to the diagram. Test its smooth operation after installation.
7. **Final Tightening:** Once all components are in place, gently tighten all screws and bolts. Do not overtighten.
8. **Stability Check:** Before use, gently rock the chair and ensure it is stable and all connections are secure.



Image: Fully assembled GarveeHome Nursery Rocking Chair, showing its overall design and retractable footrest.

Operating Instructions

Using the Rocking Function

The chair is designed for a smooth and gentle rocking motion. Sit comfortably in the chair and gently push off with your feet to initiate rocking. The curved wooden base allows for a rocking range of approximately 80°–130°.



Image: Diagram showing the gentle rocking motion of the chair, suitable for sleeping, reading, and relaxing.

Extending and Retracting the Footrest

To extend the footrest:

1. Locate the handle or mechanism for the footrest, typically located under the front edge of the seat.
2. Pull the handle or activate the mechanism to release the footrest.
3. Gently push the footrest outwards with your feet until it locks into the extended position.

To retract the footrest:

1. Push your toes against the ground while seated to disengage the footrest lock.
2. Guide the footrest back underneath the seat until it is fully retracted and secured.



Image: Visual guide showing the footrest in its closed and open positions for relaxation.

Using the Side Pocket

The integrated side pocket provides convenient storage for small items such as bottles, phones, magazines, or remote controls. Simply place items into the pocket for easy access.



Image: Detailed view highlighting the large side pocket, expandable footstool, and the soft texture of the chair's fabric and cushion.

Care and Maintenance

- **Regular Cleaning:** Vacuum the Teddy fabric regularly using a soft brush attachment to remove dust and debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. For stubborn stains, use a mild upholstery cleaner according to the product instructions. Test on an inconspicuous area first.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, bleach, or harsh solvents, as these can damage the fabric and wood finish.
- **Wood Care:** Wipe wooden legs with a soft, damp cloth. Avoid excessive moisture.
- **Fastener Check:** Periodically check all screws and bolts to ensure they remain tight. Retighten as necessary to maintain stability.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fabric fading.

Troubleshooting

Problem	Possible Cause	Solution
Chair wobbles or feels unstable.	Loose fasteners; uneven floor.	Check and tighten all assembly screws. Ensure the chair is on a flat, level surface.
Footrest does not extend or retract smoothly.	Mechanism obstruction; misaligned parts; dirt/debris.	Inspect the footrest mechanism for any obstructions. Ensure all parts are correctly aligned and lubricate if necessary (use a dry lubricant suitable for furniture mechanisms).
Squeaking noise during rocking.	Friction between wooden parts or joints.	Check all connections for tightness. Apply a small amount of furniture wax or silicone spray to contact points on the rocker base if the noise persists.

Specifications

Feature	Detail
Brand	GarveeHome
Model Number	1sxp5GPeZ6VWvmTK9p-fPAQ20c
Color	Teddy Velvet With Footrest
Material	Wood, Teddy Fabric, Sponge (Fill)
Overall Height	40.9 inches
Overall Depth	34.2 inches
Seat Width	19.6 inches
Seat Depth	20 inches
Item Weight	46.5 pounds
Maximum Weight Recommendation	300 pounds
Rocking Range	80°–130°
Additional Features	Side Pocket, Retractable Footrest
Recommended Uses	Nursing, Reading, Relaxing
Room Type	Living Room, Bedroom, Nursery Room



Image: Detailed diagram showing the dimensions of the GarveeHome Nursery Rocking Chair, including height, width, depth, and footrest extension.

Warranty and Support

Specific warranty information for this product is not provided in this manual. For details regarding warranty coverage, claims, or technical support, please contact GarveeHome customer service directly or visit their official website. Please have your model number (1sxp5GPeZ6VWvmTK9p-fPAQ20c) and proof of purchase ready when contacting support.

You can often find contact information on the product packaging or by visiting the GarveeHome store page on Amazon: GarveeHome Store

© 2023 GarveeHome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FFN457XM

More documents and user manuals: **https://manuals.plus/**