Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Vente-unique DUKIAN

Vente-unique DUKIAN TV Cabinet User Manual

Model: DUKIAN | Brand: Vente-unique

1. Introduction

Thank you for choosing the Vente-unique DUKIAN TV Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.



Figure 1: Front view of the assembled DUKIAN TV Cabinet.

The DUKIAN TV Cabinet features a modern design with three spacious drawers and an open shelf, offering practical storage solutions for your media devices and accessories. Its dimensions are 200 x 40 x 40 cm, and it weighs 62 kg.

2. Safety Information

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all hardware is securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload drawers or shelves. Distribute weight evenly.
- Keep small parts and packaging materials away from children.
- If wall-mounting hardware is included, use it to prevent tipping, especially in homes with children or pets.
- Do not stand or climb on the TV cabinet.

3. Package Contents

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, contact customer support.

3.1. Components

- Main panels (top, bottom, sides, back)
- Drawer panels (front, back, sides, bottom)
- Shelf panel
- Legs/Support base

3.2. Hardware and Tools

- Screws, dowels, cam locks, and other fasteners
- Drawer slides and handles
- Allen key (usually included)
- *Required (not included):* Phillips head screwdriver, hammer.

4. Setup and Assembly Instructions

Follow these steps carefully to assemble your DUKIAN TV Cabinet. It is recommended to have two people for assembly.

1. **Prepare the Workspace:** Clear a spacious area and lay out all components on a soft, clean surface to prevent damage.
2. **Assemble the Base Frame:** Attach the side panels to the bottom panel using the provided dowels and cam locks. Ensure they are aligned correctly.
3. **Install the Back Panel:** Secure the back panel to the assembled frame using small nails or screws. This adds stability to the structure.
4. **Assemble the Drawers:** For each of the three drawers, attach the side panels to the front and back panels. Slide the drawer bottom into the grooves. Secure with fasteners. Attach the drawer handles.



Figure 2: View of the TV cabinet with drawers open, illustrating internal structure.

5. **Attach Drawer Slides:** Install the drawer slides to the inside of the cabinet frame and to the sides of each assembled drawer. Ensure they are level and aligned for smooth operation.
6. **Insert Drawers:** Carefully slide each assembled drawer onto its respective slides within the cabinet frame.
7. **Attach the Top Panel and Shelf:** Place the top panel onto the main frame and secure it. Insert the open shelf panel into its designated position.
8. **Final Positioning:** Carefully move the assembled TV cabinet to its desired location. If anti-tip hardware is provided, secure the cabinet to the wall according to the separate instructions included with the hardware.



Figure 3: The DUKIAN TV Cabinet in a typical living room setup.

5. Operating Instructions

The DUKIAN TV Cabinet is designed for straightforward use.

- **Drawers:** Gently pull the handles to open the drawers. Push them back in until they are fully closed. Avoid forcing the drawers, especially if they feel stiff.
- **Open Shelf:** Use the open shelf for media players, gaming consoles, or decorative items. Ensure proper ventilation for electronic devices.
- **Top Surface:** The top surface is suitable for placing your television. Ensure the TV base fits within the cabinet's dimensions and that the weight does not exceed the cabinet's capacity.

6. Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish. Dry immediately with a clean cloth.
- **Dusting:** Regularly dust the cabinet with a dry, soft cloth.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the wood and white finishes.
- **Moisture:** Protect the cabinet from excessive moisture and spills. Wipe up any liquids immediately.

7. Troubleshooting

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned drawer slides or loose screws.	Check alignment of drawer slides and tighten all screws on both the drawer and cabinet frame. Ensure no obstructions are in the way.
Cabinet feels wobbly or unstable.	Loose fasteners or uneven floor.	Ensure all assembly screws and cam locks are fully tightened. Place the cabinet on a level surface. Use shims if necessary.
Parts are missing or damaged.	Manufacturing defect or shipping damage.	Do not proceed with assembly. Contact Vente-unique customer support immediately for replacement parts.

8. Specifications

- **Model Number:** DUKIAN
- **Brand:** Vente-unique
- **Color:** White and Natural
- **Dimensions:** 200 x 40 x 40 cm (Length x Width x Height)

- **Product Weight:** 62 Kilograms
- **Number of Drawers:** 3
- **Number of Items:** 1 (TV Cabinet)
- **Assembly Required:** Yes
- **Country of Origin:** France

9. Warranty and Support

Vente-unique products are manufactured to high-quality standards. For specific warranty information, please refer to the documentation included with your purchase or visit the official Vente-unique website. If you encounter any issues or require assistance with your DUKIAN TV Cabinet, please contact Vente-unique customer support.

You can typically find contact information on the Vente-unique website or through your purchase platform (e.g., Amazon).

© 2023 Vente-unique. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FFSD1GZ1

More documents and user manuals: **https://manuals.plus/**