Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Snailax SL-128-BGE

Snailax Back Massager User Manual

Model: SL-128-BGE

1. Product Overview

The Snailax Back Massager SL-128-BGE is designed to provide a customizable massage experience for various body areas. It incorporates shiatsu kneading, vibration, and heat functions to help alleviate muscle tension and promote relaxation.



Image 1.1: Snailax Back Massager SL-128-BGE, Khaki color.

Key Features:

- **Customizable Massage:** Features 8 kneading nodes, 2 vibration motors, and heating wires. Settings for heat, roller rotation direction, kneading intensities, and vibration modes are adjustable.
- **Targeted Relief:** Shiatsu massage rollers are fixed. When placed upright, the massager targets the lower back. For neck, shoulder, or upper back massage, position the unit upside down.
- **User-Friendly Design:** Constructed with durable, easy-to-clean materials. Includes a detachable cover for adjusting massage intensity and a hand controller for operation.
- **Safety Features:** Equipped with a 30-minute auto-off timer and over-heat protection function.
- **Portable:** Compact design allows for use in various settings such as couches, office chairs, car seats, and recliners.
- **Versatile Application:** Can be used on the neck, back, lumbar, arms, abdomen, and legs.

2. Safety Information

Please read all safety instructions before using the Snailax Back Massager. Failure to follow these instructions may

result in injury or damage to the product.

- Always unplug the massager when not in use.
- If the over-heat protection function activates, allow the massager to cool down for 15-30 minutes before resuming use.
- Do not use the massager on broken skin or areas with acute inflammation.
- Consult a physician before use if you have any health conditions, are pregnant, or have recently undergone surgery.
- Keep the massager and its cord away from water and heat sources.
- Always follow the directions for proper usage and body positioning.

3. Product Components

- Snailax Back Massager Unit
- Hand Controller (attached via cord)
- Detachable Cover (for intensity adjustment)
- Power Adapter (Corded Electric)

4. Setup and Usage

4.1 Initial Setup

1. Unpack the Snailax Back Massager and ensure all components are present.
2. Place the massager on a suitable chair, couch, or flat surface. Ensure it is stable.
3. Connect the power adapter to the massager and then plug it into a power outlet.

4.2 Operating Instructions

The massager is operated using the attached hand controller. The controller features buttons for Power, Intensity, Direction, Vibration, and Heat.



Image 4.1: Hand controller with power, intensity, direction, vibration, and heat buttons.

1. **Power ON/OFF:** Press the **Power button** ( ) to turn the massager on or off.
2. **Adjust Intensity:** Press the **Intensity button** ( ) to cycle through three kneading intensity levels (Low, Medium, High).
3. **Change Direction:** Press the **Direction button** ( ) to reverse the rotation direction of the shiatsu massage nodes.
4. **Vibration Modes:** Press the **Vibration button** ( ) to select from three vibration modes for the seat area.
5. **Heat Function:** Press the **Heat button** ( ) to activate or deactivate the soothing heat function.

Positioning for Different Body Parts:

- For lower back massage, place the massager upright against your back.
- For neck, shoulder, or upper back massage, place the massager upside down.
- The massager can also be used on the abdomen, arms, thighs, and calves as needed.



Image 4.2: Versatile application of the massager on various body parts.

Automatic Timer: The massager features a 30-minute auto-off timer for safety and to prevent overuse. If you wish to continue using the massager after the timer expires, restart the device by pressing the power button. It is recommended to allow the device to cool down for 15-30 minutes between extended uses.

5. Maintenance

5.1 Cleaning

- Always unplug the massager before cleaning.
- The detachable cover can be removed and washed according to its care label.
- Wipe the main unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.

5.2 Storage

Store the massager in a cool, dry place away from direct sunlight and heat sources when not in use.

6. Troubleshooting

If you experience any issues with your Snailax Back Massager, please refer to the following common solutions:

- **Massager does not turn on:** Ensure the power adapter is securely plugged into both the massager and a working electrical outlet.
- **Heat function not working:** Verify that the heat function is activated via the hand controller. Allow a few minutes for the heat to become noticeable. If the unit has been running for an extended period, the over-heat protection may have activated; allow it to cool down.
- **Massage feels too intense:** Use the detachable cover to reduce the intensity of the massage. Adjust your body position to lessen direct pressure on the massage nodes.
- **Massager stops unexpectedly:** The 30-minute auto-off timer may have activated. Restart the device. If the issue persists, the over-heat protection may be engaged; allow the unit to cool for 15-30 minutes.

For further assistance, please contact Snailax customer support.

7. Specifications

Feature	Detail
Product Dimensions	12.85 x 4 x 15 inches
Item Weight	3.31 Pounds
Model Number	SL-128-BGE
Power Source	Corded Electric
Massage Technique	Kneading, Vibration
Special Features	Heat Function, Auto-Off Timer, Over-Heat Protection
Material Type	Leather
Color	Khaki

8. Warranty and Support

For warranty information or customer support, please visit the official Snailax website or contact their customer service department directly. Keep your purchase receipt for warranty claims.

Snailax Official Store: Snailax Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FGJJVH3V

More documents and user manuals: **https://manuals.plus/**