Manuals+
Q & A | Deep Search | Upload

Alyoen B0FGXMCSRJ

Alyoen 3-Tier Printer Stand with Storage Drawer Instruction Manual

Model: B0FGXMCSRJ

1. Introduction

Thank you for choosing the Alyoen 3-Tier Printer Stand with Storage Drawer. This versatile stand is designed to optimize your workspace, providing organized storage for your printer, office supplies, and other essentials. It can be used as a desktop organizer or an under-desk shelf, accommodating various office equipment such as printers, fax machines, and scanners.

Please read this manual carefully before assembly and use to ensure proper setup and longevity of your product.

2. Components List

Before beginning assembly, please verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desktop Printer Stand with Drawer (1 unit)
- Assembly Hardware (screws, Allen wrench, etc.)
- Instruction Manual (this document)

3. Assembly Instructions

Assembly of the Alyoen Printer Stand is straightforward and requires no professional tools. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Identify Parts:** Refer to the included hardware diagram (if applicable) to identify each component, including the metal frame pieces, wooden shelves, and the fabric drawer.
3. **Assemble Frame:** Connect the metal frame pieces using the provided screws and Allen wrench. Ensure all connections are secure but do not overtighten initially.

4. **Attach Shelves:** Place the wooden shelves onto the designated slots or attach them to the frame using the appropriate hardware. Ensure the shelves are level and firmly secured.
5. **Insert Drawer:** Assemble the fabric drawer by unfolding it and inserting the bottom panel. Slide the assembled drawer into its designated slot on the stand.
6. **Final Tightening:** Once all parts are in place, gently tighten all screws to ensure the stand is stable and rigid.
7. **Apply Non-Slip Pads:** Attach the non-slip pads to the bottom of the stand's feet to prevent scratching surfaces and enhance stability.

Image showing the Alyoen Printer Stand's easy-to-clean surface, non-slip bottom design, metal drawer handle, and sturdy frame design.

Diagram illustrating the dimensions of the Alyoen 3-Tier Printer Stand, including height (41.2cm/16.22in), width (42.8cm/16.86in), and depth (30.2cm/11.89in), with the drawer height (11.3cm/4.45in) also indicated.

4. Operation

The Alyoen Printer Stand offers flexible usage options to suit your office needs.

4.1 Placing Equipment

- **Top Tier:** Ideal for placing your primary printer, 3D printer, or fax machine for easy access.
- **Middle Tier:** Use this shelf for additional equipment like a scanner, or for organizing documents, books, and other office supplies.
- **Under-Desk Use:** The stand can be positioned under a desk, allowing a printer to be placed on the lower shelf while the top shelf provides additional surface area.

4.2 Using the Storage Drawer

The integrated fabric drawer provides a convenient and private space for smaller items.

- Store toner cartridges, IDs, documents, pens, calculators, and other small office supplies.
- The drawer helps reduce desktop clutter and protects items from dust.

Image showing the Alyoen 3-Tier Printer Stand in a desktop setup, with a printer on the top shelf and office supplies neatly organized in the drawer below. The image highlights the stand's capacity for a printer and various small office items.

Image displaying the Alyoen 3-Tier Printer Stand on a desk, featuring a printer on the top tier, books and files on the middle tier, and a drawer filled with office supplies. This illustrates the multi-functional storage capabilities.

Image demonstrating the Alyoen 3-Tier Printer Stand placed under a desk, with a printer on the lower shelf and a plant and clock on the top shelf. This shows its versatility for both desktop and under-desk use.

5. Maintenance

To ensure your Alyoen Printer Stand remains in excellent condition, follow these simple maintenance guidelines:

- **Cleaning:** The stand's surface is smooth and easy to clean. Use a soft, damp cloth to wipe away dust and spills. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Drawer Care:** The fabric drawer can be spot cleaned with a mild detergent and damp cloth if necessary. Allow it to air dry completely before reinserting.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight and secure. Retighten if any looseness is detected.
- **Avoid Overloading:** Do not exceed the recommended weight capacity of the stand to prevent damage or instability.

6. Troubleshooting

If you encounter any issues with your Alyoen Printer Stand, please refer to the following common troubleshooting tips:

- **Stand is Wobbly:** Ensure all screws are fully tightened. Check that the stand is placed on a flat, even surface. Adjust the non-slip pads if necessary to compensate for minor unevenness.
- **Drawer Does Not Slide Smoothly:** Verify that the drawer is correctly assembled and inserted into its slot. Ensure no items are obstructing its movement.
- **Difficulty Assembling:** Double-check the instruction manual and ensure all parts are correctly oriented. Do not force parts together. If a part seems ill-fitting, re-examine the assembly steps.

If these steps do not resolve your issue, please contact customer support for further assistance.

7. Specifications

Feature	Detail
Model Number	B0FGXMCSRJ
Brand	Alyoen
Package Dimensions	16.69 x 12.64 x 3.58 inches
Item Weight	8.56 pounds
Form Factor	Desk stand
Compatible Devices	Printers, Fax Machines, Scanners, 3D Printers
Mounting Type	Tabletop
Material	High-quality metal and wood

8. Warranty Information

Specific warranty details for the Alyoen 3-Tier Printer Stand are not provided in this manual. For information regarding warranty coverage, terms, and conditions, please refer to the product packaging or contact the retailer/manufacturer directly.

9. Customer Support

If you have any questions, require assistance with assembly, or need to report a missing/damaged part, please contact Alyoen customer support through the retailer's platform where the product was purchased. Please have your model number (B0FGXMCSRJ) and purchase date ready when contacting support.

© 2025 Alyoen. All rights reserved.