Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy J781B-BK

Sweetcrispy Home Office Executive Chair (Model J781B-BK) Instruction Manual

Brand: **Sweetcrispy**

Model: **J781B-BK**

Introduction

Welcome to your new Sweetcrispy Home Office Executive Chair. This manual provides detailed instructions for assembly, operation, and maintenance to ensure optimal use and longevity of your chair. Please read through all instructions carefully before beginning assembly or use.

Important Safety Information

- Wipe clean to avoid allergic reactions.
- Do not exceed the maximum weight capacity of**250 pounds**.
- Ensure all bolts are fully tightened before using the chair.
- Lubricate all moving parts and tighten all bolts every 6 months or whenever needed to maintain stability and safety.

Package Contents

Before assembly, please verify that all the following components are present in your package:

- 1x Backrest (A)
- 1x Seat (B)
- 1x Left Armrest (C-L)
- 1x Right Armrest (C-R)
- 1x Mechanism (D)
- 1x Gas Lift (E)
- 1x Base (F)
- 5x Legs (G)
- 5x Casters (H)
- Bolts (I, J, K, L - various sizes)

- 1x Wrench (M)
- 1x User Manual (this document)

Assembly Instructions

For a comprehensive visual guide, please watch the official Sweetcrispy Office Chair Installation Video below. Detailed steps are also provided.


▶ **Watch video online**

Sweetcrispy Office Chair Installation Video

Official Sweetcrispy Office Chair Installation Video.

1. **Step 1: Assemble the Chair Base**

   Turn the Base (F) upside down. Insert the 5 Legs (G) into the Base one by one. Use the provided Wrench (M) to secure both with 10 Bolts (K).



Secure the legs to the chair base.

2. **Step 2: Attach Casters**


   Press the 5 Casters (H) firmly into the holes at the end of each Leg (G) until they click into place.



Install the casters onto the legs.

3. **Step 3: Insert Gas Lift**

Insert the Gas Lift (E) into the central hole of the assembled Base (F).



Place the gas lift into the base.

4. **Step 4: Attach Armrests to Backrest**

   Using the Wrench (M), install the Armrests (C) (1 Left, 1 Right) to both sides of the Backrest (A) with 4 Bolts (I). *Note: Bolts (I) should only be tightened 50% at this stage. Armrests are marked "L" (Left) and "R" (Right) for correct installation.*



Partially secure armrests to the backrest.

5. **Step 5: Attach Armrests to Seat**

   Turn the Seat (B) upside down. Using the Wrench (M), install the Armrests (C) (1 Left, 1 Right) to the Seat with 6 Bolts (J). *Note: Ensure the "FRONT" direction of the Seat (B) is correct. Tighten these bolts 100%.*



Fully secure armrests to the seat.

6. **Step 6: Attach Mechanism to Seat**


   Make sure the "FRONT" direction of the Mechanism (D) and Seat (B) are the same. Using the Wrench (M), attach the Mechanism (D) to the Seat (B) with 4 Bolts (L).



Attach the mechanism to the seat, ensuring correct orientation.

7. **Step 7: Final Assembly**

   Using the Wrench (M), fully tighten (100%) the previously installed 4 Bolts (I) on the Armrests (C). Align the hole on the Mechanism (D) with the Gas Lift (E), and press the Chair down until it is fully secured.



Complete the final assembly by securing the chair to the gas lift.

Operating Instructions

Your Sweetcrispy office chair is designed with several adjustable features to enhance your comfort and productivity.

1. Height Adjustment

The seat height of this 360° rotating chair can be easily adjusted using the pneumatic adjustable lever located under the seat. The adjustable range is 18.5-22.2 inches. Pull the lever up to raise the seat, or pull it up while seated to lower the seat.



Adjust the seat height using the lever.

2. Rocking Mode

The rocking mode helps you to relax from hard work. Use the lever under the seat to engage or disengage the rocking function. Turn the tension control knob to adjust the resistance of the rocking motion.



Engage the rocking mode for relaxation.

3. Flip-up Armrests

The armrests provide comfortable support for your arms and can be flipped up to save space effectively when not in use. This allows the chair to be tucked neatly under a desk, making it perfect for smaller spaces.



Flip up armrests to save space.

4. Swivel Function

The comfortable office desk chair is equipped with smooth multi-direction casters for effortless mobility and a 360° swivel function, allowing you to move freely and access different areas of your workspace without standing up.



Enjoy 360-degree swivel and smooth movement.

Maintenance

Proper maintenance will extend the life and performance of your Sweetcrispy office chair.

- **Cleaning:** For general cleaning, wipe the chair with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as they may damage the mesh or fabric.
- **Tightening:** Periodically check all bolts and screws. Tighten them every 6 months or whenever you notice any looseness to ensure the chair remains stable and safe.
- **Lubrication:** If any moving parts, such as the casters or gas lift, begin to squeak or operate roughly, apply a small amount of silicone-based lubricant to restore smooth function.

Specifications

Feature	Detail
Brand	Sweetcrispy
Model Name	Sweetcrispy Home Office Managerial Executive Chair
Model Number	J781B-BK
Color	Black
Material	Mesh, Metal
Product Dimensions (D x W x H)	18.49"D x 41.5"W x 20.08"H
Seat Depth	18.5 inches
Seat Height Adjustment Range	18.5-22.2 inches
Maximum Weight Recommendation	250 Pounds
Back Style	Mesh Back
Arm Style	Flip Up Armrest
Furniture Base Movement	Swivel
Required Assembly	Yes
Included Components	A Chair, Assembly Tool, User Manual

Warranty & Support

For warranty information or customer support, please refer to the contact details provided with your purchase or visit the official Sweetcrispy website. Keep your purchase receipt for any warranty claims.

Additional Resources

Explore more Sweetcrispy products and accessories:

Visit the Sweetcrispy Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FGY19P3S

More documents and user manuals: **https://manuals.plus/**