Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy L7181BPK

Sweetcrispy Ergonomic Office Desk Chair L7181BPK User Manual

Model: L7181BPK

Introduction

Thank you for choosing the Sweetcrispy Ergonomic Office Desk Chair. This manual provides comprehensive instructions for the safe assembly, proper operation, and effective maintenance of your new chair. Please read this manual thoroughly before assembly and retain it for future reference.

Important Safety Instructions

- Do not stand on the chair. Use the chair for its intended purpose only.
- Ensure all bolts and screws are securely tightened before use. Re-tighten periodically.
- Do not use the chair if any parts are damaged or missing. Contact customer support for replacement parts.
- Keep children away from moving parts during assembly and adjustment.
- Maximum weight capacity: 250 lbs (113 kg). Do not exceed this limit.
- Avoid placing heavy objects on the armrests.

Package Contents

Please verify that all components are present before beginning assembly:

- 1x Backrest (A)
- 1x Seat (B)
- 1x Left Armrest (C-L)
- 1x Right Armrest (C-R)
- 1x Mechanism (D)
- 1x Gas Lift (E)
- 1x Base (F)
- 5x Legs (G)
- 5x Casters (H)
- 4x Bolts (I)
- 6x Bolts (J)

- 10x Bolts (K)
- 4x Bolts (L)
- 1x Wrench (M)

Assembly Instructions

Follow these steps to assemble your Sweetcrispy office chair. An assembly video is also available for visual guidance.

▶ **Watch video online**

Video: Step-by-step assembly guide for the Sweetcrispy Office Chair.

1. **Assemble the Base:** Turn the Base (F) upside down. Insert the 5 Legs (G) into the base one by one. Use the Wrench (M) to secure each leg with 2 Bolts (K), totaling 10 bolts.
2. **Attach Casters:** Press the 5 Casters (H) firmly into the holes at the end of each Leg (G) until they click into place.
3. **Insert Gas Lift:** Insert the Gas Lift (E) into the center hole of the assembled Base (F).
4. **Install Armrests to Backrest:** Using the Wrench (M), install the Left Armrest (C-L) and Right Armrest (C-R) to both sides of the Backrest (A) with 2 Bolts (I) each, totaling 4 bolts. Note that bolts (I) should only be tightened 50% at this stage. Armrests are marked 'L' and 'R' for correct side installation.
5. **Install Armrests to Seat:** Turn the Seat (B) upside down. Using the Wrench (M), install the Armrests (C) to the Seat (B) with 3 Bolts (J) on each side, totaling 6 bolts. Ensure the 'FRONT' marking on the seat is facing the correct direction. Tighten these bolts 100%.
6. **Attach Mechanism to Seat:** Make sure the 'FRONT' direction of the Mechanism (D) and Seat (B) are aligned. Using the Wrench (M), attach the Mechanism (D) to the Seat (B) with 4 Bolts (L). Tighten these bolts 100%.
7. **Final Assembly:** Align the hole on the Mechanism (D) with the Gas Lift (E). Press the assembled chair top down onto the Gas Lift until it is fully secured. Finally, tighten the previously installed Bolts (I) on the armrests to the backrest to 100% to fully secure the chair.

Operating Instructions

1. Height Adjustment

To adjust the seat height, locate the pneumatic adjustment lever under the right side of the seat. Pull the lever upwards while seated to lower the chair, or pull the lever upwards while standing to raise the chair. Release the lever at your desired height. The adjustable range is 18.5-22.2 inches.



Image: The adjustable height lever and rocking tension knob located beneath the seat.

2. Rocking Mode

The chair features a rocking mode for relaxation. To activate, pull the same lever (used for height adjustment) outwards. Push the lever inwards to lock the chair in an upright position. The rocking tension can be adjusted by turning the round knob located under the seat, allowing you to control the resistance of the rocking motion.

3. Flip-up Armrests

The armrests are designed to flip up, allowing you to push the chair closer to your desk or save space when not in use. Simply lift the armrests upwards until they lock into the vertical position. To lower them, pull them down until they lock into the horizontal position.



Image: The chair's flip-up armrests provide flexibility and space-saving options.

Maintenance

- **Cleaning:** For general cleaning, spot clean with a mild detergent and a damp cloth. Wipe clean any spills immediately.

Avoid harsh chemicals or abrasive cleaners.

- **Inspection:** Periodically check all bolts and screws to ensure they are tight. Re-tighten as necessary to maintain stability and safety.
- **Casters:** Keep casters free of debris (hair, dust, etc.) to ensure smooth movement.

Troubleshooting

- **Chair Squeaks:** Apply a small amount of silicone lubricant to moving parts, especially where metal components meet.
- **Difficulty Adjusting Height:** Ensure the gas lift lever is fully engaged. If the issue persists, the gas lift may need replacement.
- **Unstable Chair:** Check all assembly bolts and tighten any loose connections. Ensure the chair is on a flat, even surface.

Specifications

Brand	Sweetcrispy
Model Name	Office Computer Desk Managerial Executive Chair
Item Model Number	L7181BPK
Color	Pink
Product Dimensions	18.5"D x 20.08"W x 41.5"H
Item Weight	25.9 pounds
Material	Sponge (Seat), Mesh (Back)
Special Features	Adjustable Height, Lumbar Support, Ergonomic, Flip-up Arms, Swivel
Maximum Weight Capacity	250 lbs

Warranty and Support

For warranty information, technical support, or to order replacement parts, please contact Sweetcrispy customer service through the retailer's platform or visit the official Sweetcrispy website. Please have your model number (L7181BPK) and purchase date available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FGY1PG2B

More documents and user manuals: **https://manuals.plus/**