Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BVNA I25 Ultra

BVNA 2501 Smartphone User Manual

Model: I25 Ultra

1. Introduction

Thank you for choosing the BVNA 2501 Smartphone. This manual provides essential information for setting up, operating, and maintaining your device. Please read this manual carefully to ensure proper use and to maximize the performance of your smartphone.

2. Package Contents

Verify that all items are present in your product package:

- BVNA 2501 Smartphone
- Headset
- Phone Case
- Screen Protector
- Power Adapter
- USB Cable (Type C)

3. Device Overview

The BVNA 2501 features a large 6.99-inch display, a USB Type C port for charging and data transfer, and a 3.5mm headphone jack. It also incorporates advanced biometric security features including face recognition and fingerprint recognition.



Figure 3.1: Front and back view of the BVNA 2501 Smartphone, highlighting its sleek design and camera placement.

4. Setup

4.1. SIM Card Installation

The BVNA 2501 supports dual SIM cards. To install your SIM card(s):

1. Locate the SIM card tray on the side of your device.
2. Insert the SIM ejector tool into the small hole next to the tray to open it.
3. Place your Nano-SIM card(s) into the tray with the gold contacts facing down.
4. Carefully push the tray back into the slot until it clicks into place.

4.2. Charging the Battery

Before first use, fully charge your smartphone. Connect the USB Type C cable to the phone's charging port and the power adapter to a wall outlet. The battery indicator on the screen will show charging progress.

4.3. Powering On/Off

- **To Power On:** Press and hold the Power button until the BVNA logo appears.
- **To Power Off:** Press and hold the Power button, then select 'Power Off' from the options on the screen.

4.4. Initial Configuration

Upon first power-on, follow the on-screen prompts to set up your device. This includes selecting your language, connecting to a Wi-Fi network, and setting up your Google account.

5. Operating Your Smartphone

5.1. Making Calls and Sending Messages

Tap the Phone icon to make calls. Enter the number or select a contact. Tap the Messages icon to send text messages. Select a contact or enter a number, then type your message.

5.2. Camera Functions

Your BVNA 2501 is equipped with a 108 MP rear camera and a 68 MP front camera. Tap the Camera icon to open the camera application. Select between photo, video, and other modes. Tap the shutter button to capture images or start/stop video recording.

5.3. Internet Connectivity

The device is unlocked for all carriers, allowing you to use mobile data with your chosen network. To connect to Wi-Fi, go to **Settings > Network & internet > Wi-Fi**, then select your desired network and enter the password.

5.4. Security Features

Enhance your phone's security using:

- **Fingerprint Recognition:** Register your fingerprint(s) in **Settings > Security & privacy > Device unlock > Fingerprint**.
- **Face Recognition:** Set up face unlock in **Settings > Security & privacy > Device unlock > Face unlock**

6. Maintenance

6.1. Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your smartphone. Avoid using harsh chemicals or abrasive materials, as these can damage the device. The device is not water resistant.

6.2. Battery Care

To prolong battery life, avoid exposing your phone to extreme temperatures. It is recommended to keep the battery charge between 20% and 80% for optimal longevity. Use only the provided charger and USB cable.

7. Troubleshooting

If you encounter issues with your BVNA 2501, try the following solutions:

- **Device Not Turning On:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again.
- **No Network Signal:** Check if your SIM card is properly inserted. Verify that airplane mode is off. Contact your carrier to confirm service availability.

- **Apps Crashing/Freezing:** Close and restart the app. If the issue persists, clear the app's cache (**Settings > Apps > [App Name] > Storage & cache > Clear cache**).
- **Slow Performance:** Close unused apps. Clear unnecessary files and cache. Consider performing a factory reset as a last resort (back up your data first).

8. Specifications

Feature	Specification
Model Name	I25 Ultra
Brand	BVNA
Screen Size	6.99 inches
Resolution	1440 x 3040 pixels
RAM Memory	16 GB
Memory Storage Capacity	10 GB
Rear Camera Resolution	108 MP
Front Camera Resolution	68 MP
Battery Capacity	7000 mAh
Wireless Carrier	Unlocked for All Carriers
SIM Card Slot Count	Dual SIM
Connector Type	USB Type C
Headphones Jack	3.5 mm
Biometric Security	Face Recognition, Fingerprint Recognition
Water Resistance Level	Not Water Resistant
GPS Geotagging	True

9. Warranty and Support

For warranty information and technical support, please refer to the warranty card included in your package or visit the official BVNA website. Keep your proof of purchase for warranty claims.

© 2026 BVNA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FHF8GDK8

More documents and user manuals: **https://manuals.plus/**