Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VEVOR YQ-JT2

VEVOR Instant Hot Water Dispenser

MODEL: YQ-JT2 USER MANUAL

1. Introduction

Thank you for choosing the VEVOR Instant Hot Water Dispenser. This countertop appliance is designed to provide hot water rapidly at various temperatures and volumes, suitable for beverages, baby formula, and instant meals. Please read this manual thoroughly before operation to ensure safe and efficient use.

2. Safety Information

- **Electrical Safety:** Ensure the dispenser is connected to a grounded power outlet with the correct voltage. Do not operate with a damaged power cord or plug.
- **Hot Water Hazard:** The dispenser produces very hot water. Exercise extreme caution to prevent burns. Keep hands and face clear of the dispensing area during operation.
- **Child Lock:** Always activate the child lock feature when the appliance is not in use, especially in households with children.
- **Placement:** Place the dispenser on a stable, flat, heat-resistant surface, away from edges and out of reach of children. Ensure adequate ventilation around the unit.
- **Water Quality:** Use only clean, potable water in the water tank. Do not fill with other liquids.
- **Material Safety:** The dispenser's body and frame are made from food-grade ABS and are BPA-free. The internal heating system uses food-grade 304 stainless steel.
- **Cleaning:** Always unplug the appliance before cleaning. Do not immerse the main unit in water.

3. Product Overview

Familiarize yourself with the components of your VEVOR Instant Hot Water Dispenser:

- **Main Unit:** Houses the heating element, control panel, and dispensing nozzle.
- **Water Tank:** Detachable, 118oz (3.7 Quarts) capacity, located at the rear of the unit.
- **Touchscreen Display:** Front-facing panel for temperature, volume selection, and child lock activation.
- **Dispensing Nozzle:** Where hot water is released.

- **Drip Tray:** Removable tray at the base to catch spills.



Figure 3.1: VEVOR Instant Hot Water Dispenser - Front View

Figure 3.2: Internal Components Diagram

4. Setup

1. **Unpacking:** Carefully remove all packaging materials and inspect the dispenser for any damage. Retain packaging for future transport or returns.
2. **Placement:** Place the dispenser on a clean, dry, stable, and level countertop. Ensure there is enough space

around the unit for ventilation.

3. **Clean the Water Tank:** Remove the detachable water tank from the back of the unit. Wash it thoroughly with mild soap and water, then rinse completely.
4. **Fill Water Tank:** Fill the water tank with fresh, potable water up to the 'MAX' line. Do not overfill.
5. **Install Water Tank:** Securely place the filled water tank back into the main unit.
6. **Connect Power:** Plug the power cord into a standard, grounded electrical outlet. The display will illuminate.
7. **Initial Rinse Cycle:** Before first use, perform a rinse cycle. Place a large heat-resistant container under the dispensing nozzle. Select the highest temperature (212°F) and largest volume (18oz). Press the dispense button. Repeat this process 2-3 times to flush out any manufacturing residue.

5. Operating Instructions

The VEVOR Instant Hot Water Dispenser features a user-friendly touchscreen for all operations.

Figure 5.1: Touchscreen Display

5.1 Power On/Off

- The unit powers on automatically when plugged in.
- To turn off, press and hold the power icon on the touchscreen.

5.2 Selecting Temperature

The dispenser offers 7 preset temperatures:

- 77°F (Room Temperature)
- 113°F (Milk)
- 131°F (Honey Water)
- 149°F (Herbal Tea)
- 185°F (Coffee)
- 194°F (Tea)
- 212°F (Boiling Water)

Touch the 'TEMP' icon on the display to cycle through the available temperature options until your desired temperature is shown.



Figure 5.2: 7 Preset Temperature Options

5.3 Selecting Water Volume

The dispenser offers 7 preset water volumes:

- 6oz
- 8oz
- 10oz
- 12oz
- 14oz

- 16oz
- 18oz

Touch the 'Volume Oz' icon on the display to cycle through the available volume options until your desired volume is shown.



Figure 5.3: 7 Water Volume Levels

5.4 Activating Child Lock

To prevent accidental dispensing of hot water, the child lock automatically activates after a period of inactivity. To unlock, touch and hold the 'Lock' icon on the touchscreen until it unlocks.

5.5 Dispensing Water

1. Place your cup or container on the drip tray, centered under the dispensing nozzle.
2. Unlock the child lock if it is active.
3. Select your desired temperature and water volume using the touchscreen.
4. Press the 'Water Drop' icon (dispense button) to start dispensing. The unit will heat and dispense the selected volume of water.
5. To stop dispensing before the selected volume is reached, press the 'Water Drop' icon again.

6. Maintenance

6.1 Cleaning the Water Tank

The 118oz water tank is detachable for easy cleaning and refilling.



Figure 6.1: Detachable Water Tank

1. Unplug the dispenser from the power outlet.
2. Remove the water tank from the back of the unit.
3. Wash the tank with warm, soapy water and a soft brush. Rinse thoroughly to remove all soap residue.
4. Dry the tank completely before refilling and reattaching to the dispenser.

6.2 Cleaning the Drip Tray

The drip tray should be emptied and cleaned regularly to prevent overflow and bacterial growth.

1. Slide out the drip tray from the base of the dispenser.

2. Empty any collected water.
3. Wash the tray with warm, soapy water and rinse thoroughly.
4. Dry completely before placing it back into the unit.

6.3 Descaling

Depending on water hardness, mineral deposits (limescale) may build up inside the heating system. Descale the unit every 1-3 months or as needed.

1. Unplug the dispenser and empty the water tank.
2. Fill the water tank with a descaling solution (e.g., a mixture of white vinegar and water, or a commercial descaling agent designed for coffee makers/kettles) according to the descaling product's instructions.
3. Place a large heat-resistant container under the dispensing nozzle.
4. Plug in the dispenser. Select the highest temperature (212°F) and largest volume (18oz). Dispense the entire tank of descaling solution.
5. Repeat the dispensing process with fresh, clean water 2-3 times to thoroughly rinse the system.

7. Troubleshooting

Problem	Possible Cause	Solution
No water dispensed	Water tank empty or not properly installed; child lock active.	Refill water tank and ensure it's seated correctly. Deactivate child lock.
Water not hot enough	Incorrect temperature setting; ambient temperature affecting water in cup.	Ensure the desired temperature is selected. Note that the displayed temperature is at the water outlet, and there may be a slight variation when it reaches your cup due to ambient temperature. Pre-heat your cup if higher temperature retention is desired.
Water splatters during dispensing	High water pressure; cup too far from nozzle.	Ensure the cup is placed as close as possible to the dispensing nozzle. Some minor splashing is normal with instant heating systems.
Unit leaks	Water tank not properly seated; drip tray full.	Re-seat the water tank firmly. Empty and clean the drip tray. If leaking persists, contact customer support.
Display not working	Power issue; unit malfunction.	Check power connection. Try plugging into a different outlet. If issue persists, contact customer support.

8. Specifications



Figure 8.1: Product Dimensions

Feature	Detail
Brand	VEVOR
Model Number	YQ-JT2
Capacity	118oz (3.7 Quarts) Water Tank
Material	Stainless Steel, ABS Plastic (Food-grade, BPA-free)
Color	White
Control Method	Touchscreen
Special Feature	Temperature Control, Child Lock
Wattage	1500 watts

Feature	Detail
Item Dimensions (L x W x H)	9.45" x 8.03" x 11.81" (240 x 204 x 300 mm)
Item Weight	4.59 Pounds (2.08 kg)
Included Components	1 x Instant Hot Water Dispenser, 1 x Drip Tray

9. Warranty and Support

For warranty information, please refer to the documentation included with your product packaging or visit the official VEVOR website. If you encounter any issues or require technical assistance, please contact VEVOR customer support. Keep your purchase receipt and model number (YQ-JT2) handy for faster service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FHFMH52H

More documents and user manuals: **https://manuals.plus/**