Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bellemave FST00191-TB-AK1

Bellemave Twin Triple Bunk Bed (Model FST00191-TB-AK1) Instruction Manual

Your guide to assembly, use, and maintenance.

1. Product Overview

The Bellemave Twin Triple Bunk Bed is designed to maximize sleeping space, accommodating three twin-sized mattresses. Constructed from durable metal, this bunk bed features integrated ladders and continuous guardrails for safety and stability. It is suitable for children, teenagers, and adults.



Image 1.1: Fully assembled Bellemave Twin Triple Bunk Bed in white.

2. Safety Information

WARNING: Failure to follow these safety instructions could result in serious injury.

- **Maximum Weight Capacity:** Each bed tier has a maximum weight recommendation of 400 pounds (181 kg). Do not exceed this limit.
- **Guardrails:** Always ensure guardrails are securely in place on the upper and middle bunks.
- **Ladder Safety:** Use the built-in ladders for climbing up and down. Do not use other furniture or objects to access the upper bunks.
- **Mattress Size:** Use only twin-sized mattresses that fit snugly within the bed frame to prevent entrapment.
- **Sharp Edges:** Exercise caution around sharp edges during assembly and use.
- **Assembly:** Ensure all components are correctly assembled and tightened before use. Regularly check and re-tighten hardware as needed.

- **No Jumping:** Do not allow jumping on the bunk bed.
- **Age Recommendation:** The top bunk is not suitable for children under 6 years of age.

3. Package Contents

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Bed Frame Components (Metal posts, side rails, crossbars)
- Guardrails
- Ladders (Built-in)
- Slat System (Metal slats for mattress support)
- Assembly Hardware (Bolts, nuts, washers, Allen wrench)
- Instruction Manual

4. Specifications

Feature	Detail
Model Number	FST00191-TB-AK1
Brand	Bellemave
Material	Metal
Color	White
Overall Dimensions (L x W x H)	76"L x 39"W x 75.6"H (193 cm x 99 cm x 192 cm)
Compatible Mattress Size	Twin
Weight Capacity (Each Tier)	400 lbs (181 kg)
Item Weight	52 lbs (23.6 kg)
Assembly Required	Yes
Included Components	Guardrails, Ladders, Slats




Image 4.1: Detailed dimensions of the bunk bed.

5. Assembly Instructions

Assembly requires two adults. Please follow these steps carefully. All necessary tools are included.

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface (e.g., a rug or blanket) to prevent scratches. Compare all parts with the provided parts list in your package to ensure nothing is missing.
2. **Assemble Base Frames:** Begin by assembling the base frames for each of the three bed tiers. Connect the side rails to the headboard and footboard sections using the provided bolts and Allen wrench. Do not fully tighten bolts until all sections are aligned.
3. **Install Slats:** Once the base frames are partially assembled, insert the metal slats into the designated slots on each frame. Ensure all slats are securely in place.
4. **Stack Bed Tiers:** Carefully stack the bed tiers one by one, starting with the bottom tier. Align the connecting points and secure them with the appropriate hardware.
5. **Attach Guardrails:** Install the guardrails on the upper and middle bunks. Ensure they are firmly attached to the bed frame.

6. **Secure Ladders:** The ladders are built into the design. Ensure all connections related to the ladder structure are fully tightened.
7. **Final Tightening:** Once all components are in place and aligned, go back and fully tighten all bolts and screws. Do not overtighten.




Image 5.1: Illustration of the robust slat system and reinforced support legs.



Image 5.2: Safety features: full-length guardrails and sturdy ladder.

6. Usage and Operation

- **Mattress Placement:** Place twin-sized mattresses on each bed tier. Ensure mattresses are not too thick, especially for the upper bunks, to maintain adequate guardrail height.
- **Accessing Upper Bunks:** Always use the built-in ladders to access the upper and middle bunks. Face the ladder when climbing up or down.
- **Weight Distribution:** Distribute weight evenly on each bed tier. Avoid concentrating weight in one small area.
- **Ventilation:** Ensure adequate air circulation around the mattresses.




Image 6.1: Each bed tier supports up to 400 lbs.

7. Maintenance

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Hardware Check:** Periodically (e.g., every 3-6 months) inspect all bolts, screws, and connections. Re-tighten any loose hardware to ensure the bed remains stable and safe.
- **Damage Inspection:** Regularly check for any signs of wear, damage, or structural fatigue. If any damage is found, discontinue use and contact customer support for replacement parts or advice.

8. Troubleshooting

Problem	Possible Cause	Solution

Bed feels wobbly or unstable.	Loose hardware. Uneven floor.	Check and tighten all bolts and screws. Ensure the bed is on a level surface.
Squeaking noises.	Loose connections. Friction between metal parts.	Re-tighten all hardware. Apply a small amount of silicone lubricant to contact points if necessary.
Missing parts during assembly.	Packaging error.	Do not proceed with assembly. Contact Bellemave customer support immediately for replacement parts.

9. Warranty and Support

Bellemave provides a limited warranty for this product against manufacturing defects. For specific warranty terms, claims, or technical support, please refer to the warranty card included in your package or visit the official Bellemave website. For assistance, please contact Bellemave customer service. When contacting support, please have your model number (FST00191-TB-AK1) and purchase information ready.

Manufacturer: Bellemave

© 2024 Bellemave. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FHQ22NJV

More documents and user manuals: **https://manuals.plus/**