Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Sweetcrispy AS-7BC-02

Sweetcrispy 7-Drawer Dresser with Fabric Bins (Model AS-7BC-02) Instruction Manual

Your guide to assembly, usage, and maintenance.

1. Introduction

Thank you for choosing the Sweetcrispy 7-Drawer Dresser with Fabric Bins. This versatile storage unit is designed to help organize your living space efficiently. Featuring a sturdy steel frame, a durable wooden top, and seven fabric drawers, it offers a practical solution for various storage needs. This manual provides detailed instructions for assembly, usage, and maintenance to ensure optimal performance and longevity of your product.

The dresser measures 11.8"D x 39.4"W x 30"H, making it suitable for bedrooms, closets, hallways, or entryways. The wooden top supports up to 66 lbs, providing additional surface space.

2. Safety Information

To prevent potential hazards, please adhere to the following safety guidelines:

- **Anti-Tip Kit:** Always secure the dresser to the wall using the provided anti-tip kit. This is crucial to prevent the furniture from tipping over, especially in households with children or pets, which could lead to serious injury.
- **Weight Limit:** Do not exceed the maximum weight limit of 66 lbs on the wooden top. Overloading can compromise the stability and structural integrity of the dresser.
- **Even Distribution:** Distribute items evenly across the drawers to maintain balance and prevent tipping.
- **Stable Surface:** Place the dresser on a flat, level, and stable surface. Use the adjustable feet to compensate for any uneven flooring.
- **Adult Assembly:** Assembly should be performed by adults. Keep small parts and packaging materials away from children during assembly.

3. Parts List

Before beginning assembly, ensure all components are present and undamaged. If any parts are missing or damaged, please contact customer service.

Frame Components:

- Steel Frame (various sections)
- Wooden Top Board
- Adjustable Feet (4x)
- X-Cross Support Bar (for stability)

Drawer Components:

- Large Fabric Drawers (4x)
- Small Fabric Drawers (3x)
- Drawer Handles (7x)
- Base Boards for Drawers (7x)

Hardware & Tools:

- Various Screws and Bolts
- Allen Wrench (included)
- Anti-Tip Kit (straps, screws, wall anchors)

4. Assembly Instructions

Follow these steps carefully for proper assembly. An online assembly video is available for visual guidance.

Assembly Video:

▶ **Watch video online**
Installation Video for the New 7-Fabric-Drawer Model

Video Description: This official Sweetcrispy installation video demonstrates the step-by-step assembly process for the 7-fabric-drawer model. It covers attaching feet, assembling the frame, installing support bars, and preparing the fabric drawers.

Step-by-Step Guide:

1. **Attach Adjustable Feet:** Screw the four adjustable feet into the bottom of the main frame components. Ensure they are tightened securely.
2. **Assemble the Main Frame:** Connect the side frames and cross tubes using the provided bolts and Allen wrench. Follow the numbered diagrams in the included guide to ensure correct orientation of all parts.
3. **Install X-Cross Support Bar:** Attach the X-cross support bar to the back of the frame. This provides additional stability and prevents wobbling.
4. **Secure the Wooden Top:** Place the wooden top board onto the assembled frame and secure it with the designated screws.
5. **Prepare Fabric Drawers:** For each fabric drawer, insert the base board into the bottom to create a sturdy structure. Attach the handles to the front of each drawer using the small screws.
6. **Insert Drawers:** Slide the assembled fabric drawers into their respective slots in the dresser frame.
7. **Install Anti-Tip Device:** Following the instructions in the anti-tip kit, secure the dresser to a wall stud using the provided strap, screws, and wall anchors. This is a critical safety step.



Image Description: A fully assembled Sweetcrispy 7-Drawer Dresser with fabric bins, featuring a black metal frame and a wooden top. The dresser has three smaller drawers on top and four larger drawers below.

5. Usage

The Sweetcrispy 7-Drawer Dresser is designed for versatile storage. The four large drawers are ideal for clothing like T-shirts (10-12 per drawer) or jeans (10-12 per drawer), while the three smaller drawers can hold socks (45-50 pairs per drawer), underwear, or accessories. The durable wooden top can serve as a display surface for decor or as a TV stand.



Image Description: The Sweetcrispy 7-Drawer Dresser with several drawers pulled open, illustrating the spacious interior and capacity for various clothing items like socks, T-shirts, and jeans.

6. Maintenance

To keep your dresser in optimal condition, follow these simple maintenance tips:

- **Cleaning:** Wipe the wooden top and metal frame with a dry cloth to remove dust and debris. For the fabric drawers, spot clean with a damp cloth and mild detergent if necessary, then air dry. Avoid harsh chemicals.
- **Inspection:** Periodically check all bolts and screws to ensure they remain tight. Re-tighten if any looseness is detected.
- **Avoid Overloading:** Do not overload the drawers or the top surface beyond their recommended weight limits.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading of the fabric drawers and potential damage to the wooden top.

7. Troubleshooting

If you encounter any issues with your dresser, refer to the following common solutions:

- **Dresser is Wobbly:**
  - Ensure all bolts and screws are securely tightened.
  - Adjust the leveling feet on the bottom of the frame to stabilize the dresser on uneven floors.
- **Drawers Do Not Slide Smoothly:**
  - Check that the base board is correctly inserted and fully extended within the fabric drawer.
  - Ensure the drawer is not overloaded or unevenly packed.
  - Verify that the drawer is inserted correctly into its designated slot in the frame.
- **Missing Parts or Damaged Components:**
  - Refer to the parts list and contact Sweetcrispy customer service for assistance.

8. Specifications

Brand	Sweetcrispy
Model Name	7 Drawer Storage Black (AS-7BC-02)
Product Dimensions	11.8"D x 39.4"W x 30"H
Item Weight	26.6 Pounds
Weight Limit (Top)	66 Pounds
Frame Material	Alloy Steel
Top Material Type	Wood
Drawer Material	Fabric (Polyester with MDF board)
Number of Drawers	7 (4 large, 3 small)
Special Feature	Adjustable Feet, Anti-Tip Kit
Assembly Required	Yes
Care Instructions	Wipe with Dry Cloth

9. Warranty and Support

Sweetcrispy products are designed for quality and durability. For any warranty claims, technical support, or assistance with missing/damaged parts, please contact Sweetcrispy customer service. Our team is available 24/7 to assist you with your storage solution.

Please refer to your purchase documentation for specific warranty terms and contact details.

© 2025 Sweetcrispy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FJLT8YMZ

More documents and user manuals: **https://manuals.plus/**