Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DUMOS 389bu

DUMOS Ergonomic Computer Gaming Chair User Manual

Model: 389bu

1. Introduction

Thank you for choosing the DUMOS Ergonomic Computer Gaming Chair. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your chair. Please read this manual thoroughly before assembly and use.





The DUMOS Ergonomic Computer Gaming Chair, featuring a blue and black design with flip-up armrests and a sturdy five-star base with wheels.

2. Safety Information

To prevent injury or damage to the chair, please adhere to the following safety guidelines:

- Do not stand on the chair.
- Do not use the chair as a stepladder.
- Ensure all bolts and screws are firmly secured before use.
- Avoid contact with sharp objects to prevent puncturing the fabric.
- Periodically (every 6 months) check all bolts and screws to ensure they remain tight.
- The chair has a maximum weight limit of 275 pounds (150 kilograms). Do not exceed this limit.
- Do not sit on the front edge of the chair.
- This chair is designed for single-person use. Do not use with more than one person.
- Do not push the chair around when a person is sitting in it.
- Do not place all your weight solely on the backrest.

3. Setup and Assembly

The DUMOS Gaming Chair is designed for easy assembly. All necessary mounting parts and tools are included in the

package. For detailed visual instructions, please refer to the electronic installation instructions and videos provided by the manufacturer.

3.1 Unpacking and Component Check

Carefully unpack all components and compare them with the parts list in your package to ensure nothing is missing or damaged. Place all parts on a soft, clean surface to prevent scratches.

3.2 Assembly Steps

1. Attach the casters to the chair base.
2. Insert the gas lift into the center hole of the base.
3. Attach the mechanism to the seat cushion using the provided screws.
4. Connect the backrest to the seat cushion and armrests. Ensure all screws are aligned and tightened securely.
5. Place the assembled seat and backrest onto the gas lift.



Detailed dimensions of the chair, including seat height, width, and backrest height, along with a 250 lbs weight capacity indicator.



An overview of the chair's features, including height adjustment, ergonomic armrests, 360-degree rotation, thick cushion, low-noise casters, and durable metal frame.

4. Operating Instructions

Your DUMOS Gaming Chair offers several adjustable features to enhance your comfort and support during long periods of sitting.

4.1 Height Adjustment

To adjust the chair's height, locate the lever under the seat on the right side. While seated, pull the lever up to lower the chair. To raise the chair, stand up slightly and pull the lever up. Release the lever at your desired height.

4.2 Rocking Mode and Tilt Tension

The chair features a rocking mode that allows the backrest to recline from 90° to 135°. To activate the rocking function, pull out the same lever used for height adjustment. Push it in to lock the chair in an upright position. The tension of the rocking motion can be adjusted by turning the round knob located under the seat, towards the front.



Illustration of the chair's rocking angle adjustment, demonstrating the range from 90° to 120° and the knob for tension control.

4.3 Flip-Up Armrests

The armrests are designed to flip up 90°, allowing the chair to be easily pushed under a desk to save space. Simply lift the armrests upwards until they lock into the vertical position. To return them to the horizontal position, pull them down.



Demonstration of the flip-up armrests, showing the chair with armrests down for use and flipped up for space-saving storage under a desk.

4.4 360° Swivel and Rolling Casters

The chair features a 360° swivel function for easy rotation and smooth nylon rolling casters for effortless movement across various floor types, including carpets, hardwood, and concrete.

5. Maintenance

Proper care and maintenance will extend the life of your DUMOS Gaming Chair.

5.1 Cleaning

The chair's PU leather surface can be easily cleaned by wiping it with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these may damage the material.

5.2 Fastener Check

Every six months, inspect all bolts and screws to ensure they are tight. Re-tighten any loose fasteners to maintain the chair's stability and safety.

6. Troubleshooting

If you encounter any issues with your DUMOS Gaming Chair, please refer to the following common solutions:

- **Chair feels wobbly or unstable:** Check all assembly bolts and screws. Ensure they are fully tightened. Refer to Section 3.2 for assembly steps.
- **Height adjustment not working:** Ensure the gas lift lever is fully engaged or disengaged as required. Check for any obstructions around the gas lift cylinder.
- **Casters not rolling smoothly:** Clean any debris (hair, dust) from the caster wheels. Ensure the wheels are properly inserted into the base.
- **Squeaking noises:** Apply a small amount of lubricant to moving parts, such as the gas lift, mechanism, or where the backrest connects to the seat.
- **Armrests not flipping smoothly:** Check for any obstructions or loose screws at the armrest pivot points.

If the issue persists after attempting these solutions, please contact DUMOS customer support for further assistance.

7. Specifications

Feature	Specification
Brand	DUMOS
Model Name	DUMOS Ergonomic Computer Gaming Chair
Model Number	389bu
Color	Blue
Product Dimensions	27.76"D x 25.39"W x 41.73"H
Back Style	Solid Back
Special Features	Adjustable Height, Arm Rest, Cushion Availability, Ergonomic, Rolling
Product Care Instructions	Wipe Clean
Unit Count	1.0 Count
Recommended Uses	Gaming, Office
Maximum Weight Recommendation	275 pounds (150 Kilograms)
Style	Modern
Pattern	Solid
Finish Type	Brushed
Room Type	Bedroom, Game Recreation Room, Library, Office, Study Room
Age Range (Description)	Adult
Included Components	Arm Pad, Caster, Cushion

Shape	L-Shape
Arm Style	With arms
Surface Recommendation	Hard Floor
Seat Back Interior Height	26 Inches
Furniture Base Movement	Swivel
Indoor/Outdoor Usage	Indoor
Furniture Finish	Leather
Seat Height	19.7 Inches
Seat Depth	26 inches
Fill Material	Memory Foam
Cushion Style	Boxed Edge
Leg Style	Tapered Leg
Arm Height	27.8 Inches
Tilting	Yes
Form Factor	Metal
Item Weight	30 pounds
UPC	708436295396

8. Warranty Information

For specific warranty details regarding your DUMOS Ergonomic Computer Gaming Chair, please refer to the warranty card included with your product or contact DUMOS customer support directly. Warranty terms typically cover manufacturing defects and material flaws for a specified period from the date of purchase.

9. Customer Support

If you have any questions, require assistance with assembly, or need to report an issue with your DUMOS Gaming Chair, please do not hesitate to contact our customer support team. We are committed to providing excellent service and support.

For more information or to explore other DUMOS products, visit the official DUMOS Store:DUMOS Store on Amazon

© 2025 DUMOS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FJXV9B6V

More documents and user manuals: **https://manuals.plus/**