TIDEWE BL008-CG-TE-AMZ

TIDEWE Hunting Blind 360° See Through User Manual

Model: BL008-CG-TE-AMZ | Brand: TIDEWE

Introduction Safety Information Package
Contents Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides instructions for the TIDEWE Hunting Blind, a portable ground blind designed for hunting activities. It features a 360° see-through design, a silent swing door, and adjustable windows for an optimal hunting experience. The blind is constructed with durable materials to withstand various outdoor conditions.



Image: The TIDEWE Hunting Blind, showcasing its camouflage pattern and overall structure when fully deployed in an outdoor setting.

2. Safety Information

Please read and understand all safety instructions before using the TIDEWE Hunting Blind. Failure to follow these instructions may result in injury or damage to the product.

- **Site Selection:** Choose a level, clear area for setup, away from sharp objects, power lines, or potential falling debris.
- **Anchoring:** Always use the provided ground stakes and resilient straps to securely anchor the blind, especially in windy conditions.
- **Visibility:** Utilize the orange warning flags to enhance visibility to other hunters, particularly during hunting seasons where blaze orange is required or recommended.
- **Fire Hazard:** Keep the blind away from open flames or heat sources. The fabric is not fireproof.
- **Children and Pets:** Keep children and pets away from the blind during setup and takedown to prevent injury.
- **Weather Conditions:** While resilient, avoid using the blind in extreme weather conditions such as severe thunderstorms, blizzards, or high winds exceeding its stability limits.

3. Package Contents

Verify that all components are present in your package:

- 1 × Hunting Blind
- 1 × Carrying Bag
- 1 × Detachable Blackout Panel (Shading Curtain)
- 5 × Orange Warning Flags
- 4 × Resilient Straps (Tie-down ropes)
- 8 × Blind Nails (Ground Stakes)



Image: An illustration showing all included components: the folded blind, carrying bag, blackout panel, orange warning flags, tie-down ropes, and ground stakes.

4. Setup Instructions

The TIDEWE Hunting Blind features a pop-up design for quick and easy assembly.

4.1. Deploying the Blind

1. Remove the blind from its carrying bag.
2. Lay the folded blind flat on the ground.
3. **Step 1:** Pull the roof pull ring upwards to begin expanding the blind.
4. **Step 2:** Continue pulling the pull rings around the sides until all hubs are fully extended and locked into place.
5. **Step 3:** The blind will stand up. Adjust its position as needed.

6. Secure the blind using the provided ground stakes and resilient straps. Insert stakes through the loops at the base of the blind and into the ground. Attach resilient straps to the top corners and stake them down for added stability.



Image: Visual guide demonstrating the three steps for easy installation and three steps for easy takedown of the hunting blind.

5. Operating Instructions

5.1. 360° See-Through Design and Blackout Panel

The blind utilizes fabric perforation technology to provide a 360° unidirectional see-through effect from the inside, allowing for a panoramic view of your surroundings while remaining concealed from the outside.



Image: A hunter seated inside the blind, demonstrating the 360-degree see-through capability, allowing visibility outwards while maintaining concealment.

For situations requiring enhanced concealment or a reduced visual range, attach the detachable 300D blackout panel. This panel allows you to switch between a 270° and 360° visual range, ensuring internal activities remain hidden.



Image: The hunting blind with a detachable blackout panel partially installed, illustrating how it can be used to adjust visibility and concealment.

5.2. Silent Swing Door

The blind features a side door that can be fully opened up to 90 degrees. This design facilitates convenient entry and exit, as well as easy retrieval of hunting equipment. The door operates silently using buckles and straps, minimizing disturbance to wildlife.



Image: A hunter entering the blind through the wide-opening swing door, highlighting the ease of access and equipment transport.

5.3. Adjustable Windows and Safety Panels

The blind is equipped with one rectangular window and nine trapezoidal windows. These windows feature dual silent sliding rails, allowing for quiet and precise adjustment of your shooting window. Each side of the tent includes over 160 square inches of removable blaze orange safety panels. These panels can be displayed to warn other individuals of your presence, enhancing

safety during hunting activities.



Image: A close-up of the hunting blind showing the blaze orange safety panels attached to the corners, indicating enhanced visibility for safety.



Image: A detailed view of the silent window sliders, demonstrating the mechanism for quiet adjustment of the shooting windows.

6. Maintenance

Proper maintenance will extend the life of your TIDEWE Hunting Blind.

- **Cleaning:** Wipe down the fabric with a damp cloth and mild soap if necessary. Avoid harsh chemicals or abrasive cleaners. Ensure the blind is completely dry before folding and storing to prevent mold or mildew.
- **Storage:** After each use, ensure the blind is clean and dry. Fold it carefully according to the takedown instructions and store it in the provided carrying bag in a cool, dry place, away from direct sunlight.
- **Inspection:** Periodically inspect the fabric, zippers, buckles, and hub system for any signs of wear, tear, or damage. Address any issues promptly to maintain optimal performance.

7. Troubleshooting

Here are solutions to common issues you might encounter:

- **Blind is difficult to set up:** Ensure all hub mechanisms are free of obstructions. If the fabric is stiff due to cold weather, gently work the hubs to loosen them. Refer to the setup instructions and image for correct deployment.
- **Blind is unstable in wind:** Verify that all 8 ground stakes are fully inserted into the ground and the 4 resilient straps are securely attached to the top corners and staked down. Ensure the blind is positioned in a sheltered area if possible.
- **Difficulty seeing through the fabric:** The 360° see-through fabric works best when there is a light differential (darker inside, brighter outside). In very dark environments or when light conditions are reversed, visibility may be reduced. Ensure the blackout panel is not installed if you desire full 360° visibility.
- **Windows are not sliding smoothly:** Check for any debris in the sliding rails. Clean the rails if necessary. Avoid forcing the sliders.

8. Specifications

Detailed specifications for the TIDEWE Hunting Blind (2-3 Person Camouflage model):

Feature	Detail
Brand	TIDEWE
Model Name	BL008-CG-TE-AMZ
Product Dimensions (L x W x H)	58.5" x 58.5" x 66.5" (Floor space: 58.5" x 58.5")
Item Weight	16.5 lbs (approx. 16.9 Pounds)
Occupancy	2-3 Person
Material	300D Polyester, Metal Hubs
Color	Camouflage
Number of Doors	1 (Swing Door)
Number of Windows	10 (1 rectangular, 9 trapezoidal)
Special Features	360° See-Through Design, Pop Up, Quick Setup, Silent Swing Door, Windproof, Detachable Blackout Panel
Included Components	Blind, Carrying bag, Orange warning flags, Resilient straps, Blind nails, Shading curtain



Image: A diagram illustrating the height, hub-to-hub, and floor dimensions for both the 2-3 person and 3-4 person models of the hunting blind.

9. Warranty & Support

9.1. Warranty Information

The TIDEWE Hunting Blind comes with a **1 Year Limited Warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or extreme weather conditions.

9.2. Customer Support

For warranty claims, technical assistance, or any questions regarding your TIDEWE Hunting Blind, please contact TIDEWE customer support through their official website or the retailer where the product was purchased. Please have your proof of purchase and model number ready when contacting support.

10. Storage and Transport

10.1. Takedown Instructions

To fold and store your blind:

1. Ensure the blind is clean and completely dry.
2. Remove all ground stakes and resilient straps.
3. **Step 1:** Grab the five pull rings (hubs) in turn and push them inwards to collapse the blind.
4. **Step 2:** Carefully fold the blind into a compact shape, ensuring the fabric is not pinched or damaged.
5. **Step 3:** Place the folded blind into the carrying bag.



Image: Visual guide demonstrating the three steps for easy installation and three steps for easy takedown of the hunting blind.

10.2. Carrying Bag

The included lightweight carrying bag allows for convenient transport of the blind to and from your hunting location.



Image: A close-up of the black carrying bag provided for the hunting blind, designed for portability.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question