Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Panasonic ES-L551D-K

Panasonic Men's Electric Shaver LAMDASH PRO 5-Blade ES-L551D-K Instruction Manual

Model: ES-L551D-K

1. Introduction

Thank you for purchasing the Panasonic LAMDASH PRO 5-Blade Electric Shaver, model ES-L551D-K. This manual provides essential information for the safe and effective use, maintenance, and care of your new shaver. Please read these instructions thoroughly before use and keep them for future reference.



The Panasonic LAMDASH PRO ES-L551D-K electric shaver in matte black, featuring a sleek design and a 5-blade shaving system.

2. Safety Information

To ensure safe operation, always observe the following precautions:

- Do not use the shaver if the power cord or AC adapter is damaged.
- Keep the shaver and AC adapter out of reach of children.
- Do not disassemble, repair, or modify the shaver yourself. Contact authorized service personnel for repairs.
- Use only the supplied AC adapter for charging.
- Do not use the shaver in a bath or shower while it is connected to the AC adapter for charging.
- Avoid pressing the shaver head too hard against your skin, as this may cause irritation.
- Regularly clean the shaver to maintain hygiene and performance.

3. Package Contents

Verify that all items are included in the package:

- Shaver Body (ES-L551D-K)
- AC Adapter
- Pouch
- Dedicated Oil
- Cleaning Brush



A visual representation of all included accessories: the shaver body, a travel pouch, an AC adapter for charging, a bottle of dedicated oil for maintenance, and a cleaning brush.

4. Setup and Charging

Initial Charging

Before first use, fully charge the shaver. Connect the AC adapter to the shaver and plug it into a power outlet. The

charging indicator will illuminate. A full charge takes approximately 1 hour.

Shaving While Charging

This model allows you to shave even while the shaver is connected to the AC adapter and charging. This feature is convenient if the battery runs low during a shave.



A close-up view of the Panasonic LAMDASH PRO shaver, emphasizing its ability to be used even while connected to the AC adapter for charging. Note: Do not use in wet environments like baths or showers while charging.

5. Operating Instructions


Basic Shaving

1. Ensure the shaver is charged.
2. Press the power button to turn on the shaver.
3. Hold the shaver at a right angle to your skin and move it gently against the direction of beard growth.

4. The 5D flexible head will adapt to your facial contours for a close and comfortable shave.
5. After shaving, press the power button to turn off the shaver.

Key Features

- **5-Blade System:** Equipped with two under-chin trimmer blades and three ultra-thin deep shaving blades for efficient cutting of various beard types.



An exploded view of the 5-blade system, showing two under-chin trimmer blades and three ultra-thin deep shaving blades. This system is designed to capture and cut various beard types effectively.

- **High-Speed Linear Motor:** Delivers approximately 14,000 strokes per minute for powerful and consistent shaving, even through dense beards.



A cutaway view revealing the high-speed linear motor inside the shaver, capable of approximately 14,000 strokes per minute, ensuring powerful and consistent shaving even through dense beards.

- **LAMDASH AI+:** An intelligent sensor detects beard density approximately 233 times per second and automatically adjusts motor power for optimal shaving performance, providing a gentle yet deep shave.



A detailed image of the LAMDASH AI+ sensor chip, which detects beard density approximately 233 times per second and automatically adjusts motor power for optimal shaving performance.

- **5D Flexible Head:** The shaver head moves in five directions to closely follow the contours of your face, including complex areas like under the chin, for a smooth and gentle shave.



An image demonstrating the 5D flexible head of the shaver, which moves in multiple directions (up, down, left, right, and forward/backward) to closely follow facial contours for a smooth and gentle shave.

6. Cleaning and Maintenance

Regular cleaning ensures optimal performance and hygiene of your shaver.

Water Washing

The shaver is designed with an IPX7 waterproof rating, allowing for easy and hygienic cleaning under running water. Simply rinse the shaver head and body under tap water after each use.



The shaver head covered in water droplets, illustrating its IPX7 waterproof rating, which allows for easy and hygienic cleaning under running water.

Sonic Cleaning Mode

For a deeper clean, activate the sonic cleaning mode. This mode uses high-frequency vibrations to dislodge stubborn beard clippings and debris from the blades.

Oiling the Blades

Apply a drop of the dedicated oil to the blades periodically (e.g., once a week) to maintain smooth operation and extend blade life. Turn on the shaver for a few seconds after applying oil to distribute it evenly.

Blade Replacement

For optimal shaving performance, it is recommended to replace the integrated blade set approximately every 1.5 years. The replacement period may vary depending on usage frequency and beard type.



An image showing the process of replacing the integrated blade set of the shaver. The recommended replacement period for the blade set is approximately 1.5 years for optimal performance.

7. Troubleshooting

If you encounter any issues with your shaver, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver fully.
Shaver does not charge.	AC adapter not properly connected or damaged.	Ensure the AC adapter is securely connected. Check for damage.
Poor shaving performance.	Blades are dull or dirty.	Clean the shaver thoroughly. Replace the blade set if necessary.

Problem	Possible Cause	Solution
Motor sound is different or weaker.	Beard clippings accumulated inside the head or battery low.	Clean the shaver. Charge the shaver fully.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Feature	Description
Model Number	ES-L551D-K
Dimensions (H x W x D)	Approx. 18.0 x 7.2 x 5.7 cm (excluding cap)
Weight	Approx. 210g (excluding cap)
Power Source	Rechargeable / AC adapter (approx. 1 hour rapid charge)
Charging System	AC adapter charging
Cleaning Method	Sonic cleaning mode / Water washable (excluding AC adapter)
International Use	Yes (requires separate plug adapter)
Country of Origin	Body: Japan / AC Adapter: China
Blade Material	Stainless Steel
Head Type	Reciprocating
Number of Blades	5
Special Features	LAMDASH AI+

9. Warranty and Support

Warranty

This Panasonic LAMDASH PRO shaver comes with a 12-month manufacturer's warranty from the date of purchase. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, concerns, or issues not covered in this manual, please contact Panasonic customer service. Refer to the contact information provided in your product packaging or on the official Panasonic website for your region.

© Panasonic Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FKGW98GN

More documents and user manuals: **https://manuals.plus/**