Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OUKITEL OUKITEL C3

OUKITEL C3 Android 16 Cell Phone User Manual

Model: OUKITEL C3

1. Introduction

This manual provides essential information for setting up, operating, and maintaining your OUKITEL C3 Android 16 Cell Phone. Please read this guide thoroughly before using your device to ensure proper function and safety.

2. Setup

2.1 What's in the Box

Verify that all items are present in your product package:

- 1x OUKITEL C3 16GB+128GB Cell Phone
- 1x 10W Charger
- 1x Data Cable (Type-C)
- 1x Phone Case
- 1x User Manual
- 1x SIM Card Pin



Image: OUKITEL C3 packaging and included accessories, including the phone, charger, cable, case, and manual.

2.2 Inserting SIM Cards and MicroSD Card

The OUKITEL C3 supports dual SIM cards (Nano-SIM) or one Nano-SIM and one MicroSD card for expanded storage up to 1TB.

1. Locate the SIM card tray on the side of the phone.
2. Insert the provided SIM ejector tool into the small hole next to the tray and press gently until the tray pops out.
3. Place your Nano-SIM card(s) and/or MicroSD card into the designated slots on the tray. Ensure the gold contacts face downwards.
4. Carefully reinsert the tray into the phone.



Image: Close-up of the OUKITEL C3 SIM card tray, showing slots for two Nano SIM cards or one Nano SIM and one TF (MicroSD) card.

2.3 Initial Power On and Setup

1. Press and hold the power button on the side of the phone until the screen turns on.
2. Follow the on-screen prompts to complete the initial setup, including language selection, Wi-Fi connection, and

Google account login.

3. For memory expansion, navigate to **Settings > Memory Expansion**, then select the desired RAM expansion and reboot the device.

3. Operating Your OUKITEL C3

3.1 Android 16 Operating System

Your OUKITEL C3 runs on the latest Android 16 system, offering enhanced security, improved app compatibility, and efficient multitasking. Explore the intuitive interface and customize your experience.



Image: Screenshot of the OUKITEL C3 displaying the Android 16 operating system interface with various app icons.

3.2 Display and Visuals

The device features a 6.52-inch HD waterdrop screen with 540*1200 resolution, 1200:1 contrast, and 450 nits brightness. This provides clear and vibrant visuals for media consumption and daily use.



Image: The OUKITEL C3 phone showcasing its 6.52-inch waterdrop display with a vibrant image.

3.3 Camera Functions

Capture moments with the 13MP main camera and take selfies with the 5MP front camera. The camera app provides various modes and settings for photography and video recording.



Image: Visual representation of the OUKITEL C3's 13MP main camera and 5MP front camera capabilities, showing example photos.

3.4 Battery and Charging

The OUKITEL C3 is equipped with a 5000mAh battery, supporting 10W fast charging. It also features OTG reverse charging, allowing you to charge other devices.



Image: Graphic illustrating the 5000mAh battery capacity of the OUKITEL C3 and its long-lasting performance.

3.5 Connectivity and Navigation

The phone supports 4G dual SIM functionality, Wi-Fi 2.4/5G, and Bluetooth 5.0. For navigation, it integrates GPS, GLONASS, Beidou, and Galileo systems. A 3.5mm audio jack is also included.



Image: Diagram showing the OUKITEL C3's features including dual SIM support, Face ID, GPS navigation, and the 3.5mm headphone jack.

3.6 Security Features

Unlock your phone conveniently and securely using Face ID.

4. Specifications

Operating System	Android 16
RAM	16GB (4GB + 12GB Virtual)
Internal Storage	128GB ROM (Expandable up to 1TB via TF card)
Display Size	6.52 inches
Display Resolution	540*1200 HD

Brightness	450 nits
Main Camera	13MP
Front Camera	5MP
Battery Capacity	5000mAh
Charging	10W Fast Charging, OTG Reverse Charging
Dimensions	9.3mm thickness
Weight	198g
Connectivity	4G Dual SIM, Wi-Fi 2.4/5G, Bluetooth 5.0
Navigation	GPS, GLONASS, Beidou, Galileo
Audio Jack	3.5mm
Security	Face ID
Supported Carriers	T-Mobile (Does not support AT&T and Verizon)

5. Troubleshooting

5.1 Common Issues and Solutions

- **Phone not turning on:** Ensure the battery is charged. Connect the phone to the charger and wait a few minutes before attempting to power on again.
- **Poor network signal:** Check if your SIM card is correctly inserted. Verify that your carrier (T-Mobile) is supported by the device. Move to an area with better network coverage.
- **Apps crashing or freezing:** Close background applications. Clear the cache of the problematic app (Settings > Apps > [App Name] > Storage > Clear Cache). If the issue persists, uninstall and reinstall the app.
- **Battery draining quickly:** Reduce screen brightness. Disable unused features like Wi-Fi, Bluetooth, and GPS when not needed. Close background apps.
- **Storage full:** Delete unnecessary files, photos, and videos. Uninstall unused applications. Consider adding a MicroSD card for additional storage.

6. Maintenance

- Keep the device dry and away from extreme temperatures.
- Use only approved chargers and accessories.
- Clean the screen with a soft, lint-free cloth. Avoid harsh chemicals.
- Regularly back up your data to prevent loss.
- Keep the software updated to the latest version for optimal performance and security.

7. Warranty and Support

Your OUKITEL C3 device comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included in your package or visit the official OUKITEL website.
For technical support or service inquiries, please contact OUKITEL customer service through their official channels.

You can also refer to the OUKITEL Store on Amazon for additional product information and support resources.

8. Product Videos

8.1 OUKITEL C3 Cell Phone Overview

▶ **Watch video online**
OUKITEL C3 Cell Phone -16GB RAM+128GB/TF 1TB ROM Smartphone

Video: An overview of the OUKITEL C3 Cell Phone, highlighting its key features and design. This video is provided by the seller.

8.2 OUKITEL C3 Unboxing

▶ **Watch video online**
OUKITEL C3 16GB+128GB Cell Phones

Video: An unboxing video for the OUKITEL C3 16GB+128GB Cell Phone, showing the contents of the package. This video is provided by the seller.

© 2025 OUKITEL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FKLTRJP6

More documents and user manuals: **https://manuals.plus/**