Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Gotrax GKS MINI

Gotrax GKS Mini Electric Scooter User Manual

Model: GKS MINI

1. Introduction

This manual provides essential information for the safe assembly, operation, and maintenance of your Gotrax GKS Mini Electric Scooter. Please read this manual thoroughly before first use to ensure proper function and safety.





Image 1: Gotrax GKS Mini Electric Scooter. This image displays the scooter's overall design, featuring a black frame with white and yellow accents, and 6-inch wheels.

2. Safety Information

The Gotrax GKS Mini Electric Scooter is designed for children aged 6-12. Always prioritize safety during operation.

- **Certification:** This scooter is UL-2272 and CPC certified for safe riding.
- **Protective Gear:** Always wear a helmet and appropriate protective gear (knee pads, elbow pads) when riding.
- **Supervision:** Adult supervision is recommended, especially for younger riders.
- **Riding Environment:** Ride on smooth, dry surfaces away from traffic. Avoid rough terrain, steep inclines, and wet conditions.
- **Weight Limit:** Do not exceed the maximum weight limit of 120 pounds.
- **Visibility:** The scooter features reflective accents to enhance visibility. For added safety, consider bright clothing.

3. Package Contents

Verify that all items are present in the package:

- Gotrax GKS Mini Electric Scooter (main body, handlebar assembly, front wheel assembly)
- Charger
- User Manual (this document)
- Assembly Tools (screws, Allen wrenches)

4. Assembly Instructions

Assembly typically takes 5-10 minutes. Follow these steps:

1. **Attach Front Wheel:** Securely attach the front wheel assembly to the scooter's deck using the provided screws.
2. **Connect Handlebar:** Connect the handlebar pole to the front wheel assembly. Ensure the handlebar and controller wires are properly matched and connected.
3. **Secure Handlebar:** Fasten the handlebar securely with the remaining screws.

Once assembled, ensure all connections are tight and secure before proceeding to charging and operation.

5. Operating Instructions

5.1. Starting the Scooter

The GKS Mini features a safe, easy-to-use push-start mechanism:

1. Place one foot on the scooter deck.
2. Push off with your other foot to gain an initial speed of at least 1.5 mph.
3. Once moving, press the thumb throttle located on the handlebar to engage the motor and accelerate.



Image 2: Thumb Control Button. This image highlights the thumb-activated throttle on the handlebar, designed for easy acceleration.

5.2. Speed Control

The 150W motor allows the scooter to reach speeds up to 7.5 mph. Release the thumb throttle to reduce speed.

5.3. Braking

The scooter is equipped with a dual braking system for quick and safe stops:

- **Electronic Brake:** The motor automatically brakes when the thumb throttle is released.
- **Rear Foot Brake:** For immediate stopping, press down on the rear fender with your foot.



Image 3: Rear Foot Brake. This image shows the rear fender which doubles as a foot brake for quick stops.

6. Maintenance

6.1. Battery Charging

The lithium-ion battery provides up to 3.75 miles of range. A full charge takes approximately 6 hours. Always use the provided charger.



Image 4: Internal Battery. This diagram illustrates the location of the long-lasting lithium-ion battery within the scooter's deck.

6.2. General Care

- Regularly inspect the scooter for any loose parts or damage.
- Keep the scooter clean and dry. Avoid prolonged exposure to moisture.
- Store the scooter in a cool, dry place when not in use.

7. Specifications

Feature	Specification
Brand	Gotrax
Model Name	GKS Mini

Motor Power	150W
Max Speed	7.5 mph
Max Range	3.75 miles
Charging Time	6 hours
Weight Limit	120 lbs
Item Weight	16.3 lbs
Wheel Size	6 inches
Wheel Type	Solid, Anti-Puncture Rubber
Frame Material	Metal (Iron)
Brake Style	Rear Braking (Electronic + Foot Brake)
Handlebar Type	Fixed



Image 5: Key Features. This infographic visually summarizes the scooter's main specifications, including motor power, weight limit, max speed, range, wheel size, and battery.



Image 6: Riding the Scooter. A child is shown riding the Gotrax GKS Mini Electric Scooter on a paved path, demonstrating its use in an outdoor setting.

8. Warranty and Support

Gotrax offers a 1-year limited warranty on all components of the GKS Mini Electric Scooter. For any concerns or support, please contact Gotrax customer service.

© 2025 Gotrax. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FKN4CQNL

More documents and user manuals: **https://manuals.plus/**